



Nokia ONT

XS-2426X-A Product Guide

3FE-49691-AAAA-TCZZA

Issue 5

December 2022

Legal notice

Nokia is committed to diversity and inclusion. We are continuously reviewing our customer documentation and consulting with standards bodies to ensure that terminology is inclusive and aligned with the industry. Our future customer documentation will be updated accordingly.

This document includes Nokia proprietary and confidential information, which may not be distributed or disclosed to any third parties without the prior written consent of Nokia.

This document is intended for use by Nokia's customers ("You"/"Your") in connection with a product purchased or licensed from any company within Nokia Group of Companies. Use this document as agreed. You agree to notify Nokia of any errors you may find in this document; however, should you elect to use this document for any purpose(s) for which it is not intended, You understand and warrant that any determinations You may make or actions You may take will be based upon Your independent judgment and analysis of the content of this document.

Nokia reserves the right to make changes to this document without notice. At all times, the controlling version is the one available on Nokia's site.

No part of this document may be modified.

NO WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF AVAILABILITY, ACCURACY, RELIABILITY, TITLE, NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, IS MADE IN RELATION TO THE CONTENT OF THIS DOCUMENT. IN NO EVENT WILL NOKIA BE LIABLE FOR ANY DAMAGES, INCLUDING BUT NOT LIMITED TO SPECIAL, DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL OR ANY LOSSES, SUCH AS BUT NOT LIMITED TO LOSS OF PROFIT, REVENUE, BUSINESS INTERRUPTION, BUSINESS OPPORTUNITY OR DATA THAT MAY ARISE FROM THE USE OF THIS DOCUMENT OR THE INFORMATION IN IT, EVEN IN THE CASE OF ERRORS IN OR OMISSIONS FROM THIS DOCUMENT OR ITS CONTENT.

Copyright and trademark: Nokia is a registered trademark of Nokia Corporation. Other product names mentioned in this document may be trademarks of their respective owners.

© 2022 Nokia.

Contents

| | |
|---|-----------|
| About this document | 15 |
| 1 What's new | 21 |
| 1.1 Overview | 21 |
| 1.2 What's new in BBD Release 22.04 | 21 |
| 1.3 What's new in BBD Release 22.03a | 22 |
| 1.4 What's new in BBD Release 22.03 | 22 |
| 1.5 What's new in BBD Release 22.02a | 22 |
| 1.6 What's new in BBD Release 22.02 | 23 |
| 2 ETSI ONT safety guidelines | 25 |
| 2.1 Safety instructions | 25 |
| 2.2 Safety standards compliance | 27 |
| 2.3 Electrical safety guidelines | 27 |
| 2.4 ESD safety guidelines | 28 |
| 2.5 Laser safety guidelines | 28 |
| 2.6 Environmental requirements | 32 |
| 3 ETSI environmental and CRoHS guidelines | 33 |
| 3.1 Environmental labels | 33 |
| 3.2 Hazardous Substances Table (HST) | 35 |
| 3.3 Other environmental requirements | 35 |
| 4 ANSI ONT safety guidelines | 37 |
| 4.1 Safety instructions | 37 |
| 4.2 Safety standards compliance | 39 |
| 4.3 Laser safety guidelines | 41 |
| 4.4 Electrical safety guidelines | 44 |
| 4.5 ESD safety guidelines | 45 |
| 4.6 Environmental requirements | 45 |
| 5 XS-2426X-A unit data sheet | 47 |
| 5.1 Overview | 47 |
| 5.2 XS-2426X-A part numbers and identification | 47 |
| 5.3 XS-2426X-A general description | 50 |
| 5.4 XS-2426X-A software and installation feature support..... | 56 |
| 5.5 XS-2426X-A interfaces and interface capacity | 56 |

| | | |
|----------|---|-----------|
| 5.6 | XS-2426X-A LEDs..... | 59 |
| 5.7 | XS-2426X-A detailed specifications | 61 |
| 5.8 | XS-2426X-A GEM ports and T-CONTs | 62 |
| 5.9 | XS-2426X-A performance monitoring statistics..... | 63 |
| 5.10 | XS-2426X-A functional blocks | 63 |
| 5.11 | XS-2426X-A standards compliance | 64 |
| 5.12 | XS-2426X-A special considerations | 66 |
| 6 | Install or replace an XS-2426X-A indoor ONT..... | 69 |
| 6.1 | Overview | 69 |
| 6.2 | Purpose..... | 69 |
| 6.3 | General | 69 |
| 6.4 | Prerequisites | 69 |
| 6.5 | Recommended tools | 69 |
| 6.6 | Safety information | 70 |
| 6.7 | Install an XS-2426X-A indoor ONT | 71 |
| 6.8 | Wall mount an XS-2426X-A indoor ONT | 74 |
| 6.9 | Replace an XS-2426X-A indoor ONT..... | 80 |
| 6.10 | Connect a CyberPower DTC36U12V3 UPS to XS-2426X-A | 84 |
| 7 | Configure an XS-2426X-A indoor ONT | 89 |
| 7.1 | Overview | 89 |
| | GUI overview | 92 |
| 7.2 | General configuration..... | 92 |
| 7.3 | HGU mode GUI configuration | 92 |
| 7.4 | Logging in to the web-based GUI..... | 92 |
| 7.5 | Viewing overview information..... | 93 |
| 7.6 | XS-2426X-A WebGUI Menu..... | 95 |
| | WAN Configuration | 97 |
| 7.7 | Overview | 97 |
| 7.8 | Configuring WAN Services..... | 97 |
| 7.9 | Viewing WAN Statistics | 102 |
| 7.10 | Configuring TR-069..... | 102 |
| 7.11 | Configuring TR-369..... | 104 |
| 7.12 | Configuring IP Routing | 105 |
| 7.13 | Viewing Optical Module Status..... | 106 |
| 7.14 | Configuring QoS..... | 108 |
| 7.15 | Configuring IPSec Tunnel..... | 110 |

| | | |
|-------------------------------------|---|------------|
| 7.16 | Configuring Upstream (US) Classifier | 112 |
| LAN Configuration | | 119 |
| 7.17 | Overview | 119 |
| 7.18 | Configuring DHCP IPv4..... | 119 |
| 7.19 | Configuring DHCP IPv6..... | 120 |
| 7.20 | Configuring DNS | 122 |
| 7.21 | Viewing LAN Statistics | 123 |
| Wi-Fi Configuration | | 126 |
| 7.22 | Overview | 126 |
| 7.23 | Configuring Wi-Fi Network | 126 |
| 7.24 | Configuring Guest Network | 132 |
| 7.25 | Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points..... | 133 |
| 7.26 | Configuring Wireless 2.4 GHz..... | 137 |
| 7.27 | Configuring Wireless 5 GHz..... | 138 |
| 7.28 | Configuring Wireless Schedules | 140 |
| 7.29 | Viewing Wi-Fi Statistics | 141 |
| Devices..... | | 143 |
| 7.30 | Overview | 143 |
| 7.31 | Viewing Device Information..... | 143 |
| Voice Configuration | | 145 |
| 7.32 | Overview | 145 |
| 7.33 | Configuring Voice Settings | 145 |
| 7.34 | Viewing Voice Status..... | 146 |
| Security Configuration | | 149 |
| 7.35 | Overview | 149 |
| 7.36 | Configuring the Firewall | 149 |
| 7.37 | Configuring the MAC Filter..... | 150 |
| 7.38 | Configuring the IP Filter..... | 152 |
| 7.39 | Configuring the URL Filter..... | 154 |
| 7.40 | Configuring Family Profiles | 155 |
| 7.41 | Configuring DMZ and ALG | 166 |
| 7.42 | Configuring Access Control..... | 167 |
| Advanced Settings..... | | 170 |
| 7.43 | Overview | 170 |
| 7.44 | Configuring Port Forwarding | 170 |
| 7.45 | Configuring Port Triggering | 171 |
| 7.46 | Configuring DDNS..... | 173 |

| | | |
|----------|---|------------|
| 7.47 | Configuring NTP | 174 |
| 7.48 | Configuring USB | 176 |
| 7.49 | Configuring UPNP and DLNA | 177 |
| | Maintenance | 179 |
| 7.50 | Overview | 179 |
| 7.51 | Configuring the Password | 179 |
| 7.52 | Backing Up the Configuration | 181 |
| 7.53 | Restoring the Configuration | 181 |
| 7.54 | Upgrading Firmware..... | 182 |
| 7.55 | Configuring LOID | 184 |
| 7.56 | Configuring SLID | 184 |
| 7.57 | Managing the Device | 185 |
| 7.58 | Diagnosing WAN Connections | 186 |
| 7.59 | Viewing Log Files | 190 |
| 7.60 | Generating a delta configuration file | 191 |
| | Troubleshooting | 193 |
| 7.61 | Troubleshooting..... | 193 |
| 8 | ONT configuration file over OMCI | 195 |
| 8.1 | Overview | 195 |
| 8.2 | Purpose..... | 195 |
| 8.3 | Supported configuration file types..... | 195 |
| 8.4 | ONT configuration file over OMCI | 197 |

List of tables

| | | |
|------------|---|-----|
| Table 1-1 | What's new in BBD Release 22.04 | 21 |
| Table 1-2 | What's new in BBD Release 22.03a | 22 |
| Table 1-3 | What's new in BBD Release 22.03 | 22 |
| Table 1-4 | What's new in BBD Release 22.02a | 22 |
| Table 2-1 | Safety labels..... | 26 |
| Table 4-1 | Safety labels..... | 38 |
| Table 5-1 | Identification of XS-2426X-A indoor ONTs | 47 |
| Table 5-2 | XS-2426X-A power supply ordering information | 48 |
| Table 5-3 | XS-2426X-A UPS ordering information | 49 |
| Table 5-4 | Hardware parts required for XS-2426X-A installations..... | 50 |
| Table 5-5 | XS-2426X-A indoor ONT interface connection capacity | 56 |
| Table 5-6 | XS-2426X-A indoor ONT physical connections..... | 58 |
| Table 5-7 | XS-2426X-A indoor ONT LED descriptions..... | 60 |
| Table 5-8 | XS-2426X-A indoor ONT physical specifications | 61 |
| Table 5-9 | XS-2426X-A dimension data specifications | 61 |
| Table 5-10 | XS-2426X-A indoor ONT power consumption specifications | 62 |
| Table 5-11 | XS-2426X-A indoor ONT environmental specifications..... | 62 |
| Table 5-12 | XS-2426X-A indoor ONT capacity for GEM ports and T-CONTs | 62 |
| Table 5-13 | XS-2426X-A ONT generic performance monitoring statistics | 63 |
| Table 5-14 | XS-2426X-A ONT ONTL2UNI performance monitoring statistics | 63 |
| Table 5-15 | Responsible party contact information | 65 |
| Table 5-16 | XS-2426X-A ONT considerations and limitations..... | 67 |
| Table 7-1 | XS-2426X-A WebGUI Menu..... | 95 |
| Table 7-2 | <i>WAN services</i> parameters | 99 |
| Table 7-3 | <i>TR-069</i> parameters..... | 103 |
| Table 7-4 | <i>TR-369</i> parameters..... | 104 |
| Table 7-5 | <i>IP routing</i> parameters..... | 106 |
| Table 7-6 | <i>Optical module status</i> parameters | 107 |
| Table 7-7 | <i>QoS config</i> parameters | 109 |
| Table 7-8 | <i>IPSec tunnel</i> parameters..... | 112 |
| Table 7-9 | <i>US Classifier - Policy</i> parameters..... | 114 |

| | | |
|------------|--|-----|
| Table 7-10 | <i>US Classifier - Classifier parameters</i> | 115 |
| Table 7-11 | <i>US Classifier - Classifier Rules parameters</i> | 118 |
| Table 7-12 | <i>DHCP IPv4 parameters</i> | 120 |
| Table 7-13 | <i>Static DHCP parameters</i> | 120 |
| Table 7-14 | <i>DHCP IPv6 parameters</i> | 121 |
| Table 7-15 | <i>LAN statistics parameters</i> | 125 |
| Table 7-16 | <i>Add Wi-Fi network parameters</i> | 128 |
| Table 7-17 | <i>Guest network parameters</i> | 132 |
| Table 7-18 | <i><Device> parameters</i> | 135 |
| Table 7-19 | <i>Wireless 2.4 GHz parameters</i> | 137 |
| Table 7-20 | <i>Wireless 5 GHz parameters</i> | 139 |
| Table 7-21 | <i>STA information parameters</i> | 141 |
| Table 7-22 | <i>Neighboring AP parameters</i> | 142 |
| Table 7-23 | <i>Voice Setting parameters</i> | 146 |
| Table 7-24 | <i>Voice status parameters</i> | 147 |
| Table 7-25 | <i>Firewall parameters</i> | 150 |
| Table 7-26 | <i>MAC filter - Ethernet Interface parameters</i> | 151 |
| Table 7-27 | <i>MAC filter - Wi-Fi SSID parameters</i> | 152 |
| Table 7-28 | <i>IP filter parameters</i> | 153 |
| Table 7-29 | <i>URL filter parameters</i> | 155 |
| Table 7-30 | <i>ALG Configuration parameters</i> | 167 |
| Table 7-31 | <i>DMZ Configuration parameters</i> | 167 |
| Table 7-32 | <i>Access control parameters</i> | 169 |
| Table 7-33 | <i>Trusted Network parameters</i> | 169 |
| Table 7-34 | <i>Port forwarding parameters</i> | 171 |
| Table 7-35 | <i>Port triggering parameters</i> | 172 |
| Table 7-36 | <i>DDNS parameters</i> | 174 |
| Table 7-37 | <i>NTP parameters</i> | 175 |
| Table 7-38 | <i>USB parameters</i> | 176 |
| Table 7-39 | <i>Change password parameters</i> | 180 |
| Table 7-40 | <i>LOID config parameters</i> | 184 |
| Table 7-41 | <i>SLID configuration parameters</i> | 185 |
| Table 7-42 | <i>Device management parameters</i> | 186 |

| | | |
|------------|---|------------|
| Table 7-43 | <i>Diagnostics</i> parameters | 187 |
| Table 7-44 | <i>Log</i> parameters | 190 |
| Table 7-45 | <i>Troubleshooting</i> parameters | 194 |
| Table 8-1 | Supported configuration files..... | 196 |
| Table 8-2 | Download configuration files | 197 |

List of figures

| | | |
|-------------|--|----|
| Figure 2-1 | PSE certification | 26 |
| Figure 2-2 | Laser product label | 29 |
| Figure 2-3 | Laser classification label..... | 30 |
| Figure 2-4 | Laser warning labels..... | 31 |
| Figure 3-1 | Products below MCV value label..... | 34 |
| Figure 3-2 | Products above MCV value label | 34 |
| Figure 3-3 | Recycling/take back/disposal of product symbol | 36 |
| Figure 4-1 | Sample safety label on the ONT equipment..... | 39 |
| Figure 4-2 | Sample laser product label showing CDRH 21 CFR compliance..... | 41 |
| Figure 4-3 | Laser product label | 42 |
| Figure 4-4 | Laser classification label..... | 42 |
| Figure 4-5 | Laser warning labels..... | 43 |
| Figure 4-6 | Sample laser product safety label on the ONT equipment | 44 |
| Figure 5-1 | XS-2426X-A ONT | 51 |
| Figure 5-2 | XS-2426X-A indoor ONT physical connections (back) | 57 |
| Figure 5-3 | PON connector (bottom of the ONT) | 58 |
| Figure 5-4 | XS-2426X-A indoor ONT LEDs..... | 59 |
| Figure 5-5 | XS-2426X-A ONT functional block..... | 64 |
| Figure 6-1 | XS-2426X-A ONT connections | 72 |
| Figure 6-2 | ONT to wall mount connection - PON connector..... | 73 |
| Figure 6-3 | ONT in wall mount bracket | 75 |
| Figure 6-4 | XS-2426X-A wall mount bracket..... | 76 |
| Figure 6-5 | Connect the fiber optic cable to ONT | 77 |
| Figure 6-6 | Bottom cover of the ONT without the screws | 78 |
| Figure 6-7 | ONT to wall mount connection..... | 79 |
| Figure 6-8 | Fix the screw at the bottom of bracket..... | 80 |
| Figure 6-9 | XS-2426X-A indoor ONT connections | 81 |
| Figure 6-10 | ONT and UPS..... | 84 |
| Figure 6-11 | Molex 7-pin DC cable..... | 85 |
| Figure 6-12 | Installation of 3EM24378AB cable (7-pin) in Phoenix connector—3MV00807AA UPS 36W | 85 |
| Figure 6-13 | Connecting the AC cord to the wall outlet..... | 86 |

| | | |
|-------------|--|-----|
| Figure 6-14 | Attaching the cable retainer | 87 |
| Figure 7-1 | Login page | 92 |
| Figure 7-2 | Overview table in WAN services page..... | 97 |
| Figure 7-3 | Create New Connection page | 98 |
| Figure 7-4 | WAN Statistics page..... | 102 |
| Figure 7-5 | TR-069 page..... | 103 |
| Figure 7-6 | TR-369 page..... | 104 |
| Figure 7-7 | IP routing page | 105 |
| Figure 7-8 | Optical module status page | 107 |
| Figure 7-9 | QoS config page (L2 Criteria)..... | 108 |
| Figure 7-10 | QoS config page (L3 Criteria)..... | 109 |
| Figure 7-11 | IPSec tunnel page | 111 |
| Figure 7-12 | US Classifier - Policy page | 113 |
| Figure 7-13 | US Classifier - Classifier page | 115 |
| Figure 7-14 | US Classifier - Classifier Rules page | 117 |
| Figure 7-15 | DHCP IPv4 page..... | 119 |
| Figure 7-16 | DHCP IPv6 page | 121 |
| Figure 7-17 | DNS page | 122 |
| Figure 7-18 | LAN statistics page..... | 124 |
| Figure 7-19 | Wi-Fi network page..... | 126 |
| Figure 7-20 | Add Wi-Fi network page | 127 |
| Figure 7-21 | Wi-Fi network - SSID Configuration (2.4 GHz band) page | 129 |
| Figure 7-22 | Wi-Fi network - SSID Configuration (5 GHz band) page | 130 |
| Figure 7-23 | Guest network page | 132 |
| Figure 7-24 | Network map page | 133 |
| Figure 7-25 | <Device> page | 135 |
| Figure 7-26 | Advanced settings - 2.4 GHz tab | 137 |
| Figure 7-27 | Advanced settings - 5 GHz tab | 139 |
| Figure 7-28 | Wireless schedule page..... | 140 |
| Figure 7-29 | Wi-Fi statistics page..... | 141 |
| Figure 7-30 | Devices page | 143 |
| Figure 7-31 | <Device> page | 144 |
| Figure 7-32 | Voice Setting page..... | 145 |

| | | |
|-------------|--|-----|
| Figure 7-33 | <i>Voice status page</i> | 147 |
| Figure 7-34 | <i>Firewall page</i> | 149 |
| Figure 7-35 | <i>MAC filter page</i> | 151 |
| Figure 7-36 | <i>IP filter page</i> | 153 |
| Figure 7-37 | <i>URL filter page</i> | 154 |
| Figure 7-38 | <i>Family profiles (Parental control) page</i> | 155 |
| Figure 7-39 | <i>Add a profile page</i> | 156 |
| Figure 7-40 | <i>Assign devices to family profile</i> | 157 |
| Figure 7-41 | <i>Family profiles table</i> | 158 |
| Figure 7-42 | <i>Family profile configuration page</i> | 158 |
| Figure 7-43 | <i>DMZ and ALG page</i> | 166 |
| Figure 7-44 | <i>Access control page</i> | 168 |
| Figure 7-45 | <i>Port forwarding page</i> | 170 |
| Figure 7-46 | <i>Port triggering page</i> | 172 |
| Figure 7-47 | <i>DDNS page</i> | 173 |
| Figure 7-48 | <i>NTP page</i> | 175 |
| Figure 7-49 | <i>USB page</i> | 176 |
| Figure 7-50 | <i>UPNP and DLNA page</i> | 178 |
| Figure 7-51 | <i>Change password page</i> | 180 |
| Figure 7-52 | <i>Backup and restore page</i> | 181 |
| Figure 7-53 | <i>Backup and restore page</i> | 182 |
| Figure 7-54 | <i>Firmware upgrade page</i> | 182 |
| Figure 7-55 | <i>Example of upgrade status messages</i> | 183 |
| Figure 7-56 | <i>LOID config page</i> | 184 |
| Figure 7-57 | <i>SLID configuration page</i> | 185 |
| Figure 7-58 | <i>Device management page</i> | 186 |
| Figure 7-59 | <i>Diagnostics page</i> | 187 |
| Figure 7-60 | <i>Example of ping results</i> | 189 |
| Figure 7-61 | <i>Example of traceroute results</i> | 189 |
| Figure 7-62 | <i>Log page</i> | 190 |
| Figure 7-63 | <i>Delta CFG Tool page</i> | 191 |
| Figure 7-64 | <i>Troubleshooting page</i> | 193 |

About this document

Purpose

This documentation set provides information about safety, features and functionality, ordering, hardware installation and maintenance, and software installation procedures of this ONT for the current release.

Intended audience

This documentation set is intended for planners, administrators, operators, and maintenance personnel involved in installing, upgrading, or maintaining the ONTs.

The reader must be familiar with general telecommunications principles.

Safety information

For your safety, this document contains safety statements. Safety statements are given at points where risks of damage to personnel, equipment, and operation may exist. Failure to follow the directions in a safety statement may result in serious consequences.

Safety Information Examples



DANGER

Hazard

Danger indicates that the described activity or situation may result in serious personal injury or death; for example, high voltage or electric shock hazards.



WARNING

Equipment Damage

Warning indicates that the described activity or situation may, or will, cause equipment damage or serious performance problems.



CAUTION

Service Disruption

Caution indicates that the described activity or situation may, or will, cause service interruption.

Note: A note provides information that is, or may be, of special interest.

Acronyms and initialisms

The expansions and optional descriptions of most acronyms and initialisms appear in the glossary

Nokia quality processes

Nokia’s ONT manufacturing, testing, and inspecting practices are in compliance with TL 9000 requirements. These requirements are documented in the Fixed Networks Quality Manual 3FQ-30146-6000-QRZZA.

The quality practices adequately ensure that technical requirements and customer end-point requirements are met. The customer or its representatives may be allowed to perform on-site quality surveillance audits, as agreed upon during contract negotiations.

Documents

Documents are available using ALED or OLCS.

To download a ZIP file package of the customer documentation

- 1 _____
Navigate to <http://customer.nokia.com/s/> and enter your user name and password. If you are a new user and require access to this service, please contact your Nokia sales representative.
- 2 _____
Select **Products**.
- 3 _____
Type your product name in the **Find and select a product** field and click the search icon.
Select a product.
- 4 _____
Click **Downloads: ALED** to go to the Electronic Delivery: Downloads page.
- 5 _____
Select **Documentation** from the list.
- 6 _____
Select a release from the list.
- 7 _____
Follow the on-screen directions to download the file.

END OF STEPS _____

To access individual documents

Individual PDFs of customer documents are also accessible through the Nokia Support Portal website.

-
- 1 _____
Navigate to <http://customer.nokia.com/s/> and enter your user name and password. If you are a new user and require access to this service, please contact your Nokia sales representative.
 - 2 _____
Select **Products**.
 - 3 _____
Type your product name in the **Find and select a product** field and click the search icon.
Select a product.
 - 4 _____
Click **Documentation: Doc Center** to go to the product page in the Doc Center.
 - 5 _____
Select a release from the **Release** list and click **SEARCH**.
 - 6 _____
Click on the PDF icon to open or save the file.

END OF STEPS _____

Procedures with options or substeps

When there are options in a procedure, they are identified by letters. When there are required substeps in a procedure, they are identified by roman numerals.

Example of options in a procedure

At [Step 1](#), you can choose option a or b. At [Step 2](#), you must do what the step indicates.

- 1 _____
This step offers two options. You must choose one of the following:
 - a. This is one option.
 - b. This is another option.
- 2 _____
You must perform this step.

END OF STEPS _____

Example of required substeps in a procedure

At [Step 1](#), you must perform a series of substeps within a step. At [Step 2](#), you must do what the step indicates.

1 _____

This step has a series of substeps that you must perform to complete the step. You must perform the following substeps:

- a. This is the first substep.
- b. This is the second substep.
- c. This is the third substep.

2 _____

You must perform this step.

END OF STEPS _____

Multiple PDF document search

You can use Adobe Reader Release 6.0 and later to search multiple PDF files for a common term. Adobe Reader displays the results in a single display panel. The results are grouped by PDF file, and you can expand the entry for each file.

Note:The PDF files in which you search must be in the same folder.

To search multiple PDF files for a common term

1 _____

Open Adobe Acrobat Reader.

2 _____

Choose **Edit**→**Search** from the Acrobat Reader main menu. The Search PDF panel displays.

3 _____

Enter the search criteria.

4 _____

Select **All PDF Documents In**.

5 _____

Select the folder in which to search using the drop-down menu.

6 _____

Click **Search**.

Acrobat Reader displays the search results. You can expand the entries for each document by clicking on the + symbol.

END OF STEPS _____

Technical support

For details, refer to the [Nokia Support portal \(https://customer.nokia.com/support/s/\)](https://customer.nokia.com/support/s/).

For ordering information, contact your Nokia sales representative.

How to comment

To comment on this document, go to the [Online Comment Form \(https://documentation.nokia.com/comments/\)](https://documentation.nokia.com/comments/) or e-mail your comments to the [Comments Hotline \(mailto:comments@nokia.com\)](mailto:comments@nokia.com).

1 What's new

1.1 Overview

1.1.1 Purpose

This chapter provides information of the feature and document changes applicable to this guide.

1.1.2 Contents

| | |
|--|----|
| 1.1 Overview | 21 |
| 1.2 What's new in BBD Release 22.04 | 21 |
| 1.3 What's new in BBD Release 22.03a | 22 |
| 1.4 What's new in BBD Release 22.03 | 22 |
| 1.5 What's new in BBD Release 22.02a | 22 |
| 1.6 What's new in BBD Release 22.02 | 23 |

1.2 What's new in BBD Release 22.04

Table 1-1, "What's new in BBD Release 22.04" (p. 21) lists the new features and enhancements added to the XS-2426X-A product guide in Issue 5.

Table 1-1 What's new in BBD Release 22.04

| Feature/enhancement | Description | See |
|------------------------------|---|--|
| Documentation changes | | |
| General description | Updated the general description section. | Section 5.3 "XS-2426X-A general description" (p. 50) |
| Remove Wi-Fi point | Added information to remove the Wi-Fi point from your network. | Section 7.25 "Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points" (p. 133) |
| Guest network | Added Configuring Guest Network | 7.24 "Configuring Guest Network" (p. 132) |
| Delta CFG tool | Added Generating a delta configuration file | 7.60 "Generating a delta configuration file" (p. 191) |
| SLID configuration | Updated the description and limitation for SLID mode parameter. | Section 7.56 "Configuring SLID" (p. 184) |

1.3 What's new in BBD Release 22.03a

Table 1-2, "What's new in BBD Release 22.03a" (p. 21) lists the new features and enhancements added to the XS-2426X-A product guide in Issue 4.

Table 1-2 What's new in BBD Release 22.03a

| Feature/enhancement | Description | See |
|------------------------------|--|--|
| Documentation changes | | |
| General description | Updated the general description section. | Section 5.3 "XS-2426X-A general description" (p. 50) |

1.4 What's new in BBD Release 22.03

Table 1-3, "What's new in BBD Release 22.03" (p. 22) lists the new features and enhancements added to the XS-2426X-A product guide in Issue 3.

Table 1-3 What's new in BBD Release 22.03

| Feature/enhancement | Description | See |
|--------------------------------|---|--|
| New Feature Enhancement | | |
| UPS ordering information | Added UPS ordering information table | Table 5-3, "XS-2426X-A UPS ordering information" (p. 49) |
| UPS installation | Added a procedure to connect a CyberPower DTC36U12V3 UPS to an ONT | Section 6.10 "Connect a CyberPower DTC36U12V3 UPS to XS-2426X-A" (p. 84) |
| General description | Updated the general description section with bridged WAN and VLAN binding support information | Section 5.3 "XS-2426X-A general description" (p. 50) |

1.5 What's new in BBD Release 22.02a

Table 1-4, "What's new in BBD Release 22.02a" (p. 22) lists the new features and enhancements added to the XS-2426X-A product guide in Issue 2.

Table 1-4 What's new in BBD Release 22.02a

| Feature/enhancement | Description | See |
|-----------------------------------|---|---|
| New Feature Enhancement | | |
| New menu layout | Updated the guide as per the new menu layout in the WebGUI. | Chapter Chapter 7, "Configure an XS-2426X-A indoor ONT" |
| Documentation changes | | |
| Power supply ordering information | Updated power supply ordering information table with new power supply information | Table Table 5-2, "XS-2426X-A power supply ordering information" (p. 48) |

1.6 What's new in BBD Release 22.02

The product guide is a new guide in BBD Release 22.02, issue 1. In future releases, this chapter will provide tables of the feature and document changes applicable to this guide.

2 ETSI ONT safety guidelines

This chapter provides information about the mandatory regulations that govern the installation and operation of the optical network terminals (ONTs).

2.1 Safety instructions

This section describes the safety instructions that are provided in the ONT customer documentation and on the equipment.

2.1.1 Safety instruction boxes

The safety instruction boxes are provided in the ONT customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger box.




Possibility of personal injury.

The Danger box indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of the Warning box.



Possibility of equipment damage.

Possibility of data loss.

The Warning box indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution box.



CAUTION

Service Disruption

Possibility of service interruption.

Service interruption.

The Caution box indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note box.



Note: Information of special interest.

The Note box provides information that assists the personnel working with ONTs. It does not provide safety-related instructions.

2.1.2 Safety-related labels

The ONT equipment is labeled with the specific safety instructions and compliance information that is related to a variant of the ONT. Observe the instructions on the safety labels.

The following table provides sample safety labels on the ONT equipment.

Table 2-1 Safety labels

| Description | Label text |
|----------------------|---|
| ESD warning | Caution: This assembly contains an electrostatic sensitive device. |
| Laser classification | Class 1 laser product |
| PSE marking | These power supplies are Japan PSE certified and compliant with Japan VCCI emissions standards. |

Figure 2-1, “PSE certification” (p. 26) shows the PSE certification.

Figure 2-1 PSE certification

| | |
|-------------|--|
| Warning | This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual. |
| 警告 | VCCI準拠クラスB機器（日本） この機器は、Information Technology EquipmentのVoluntary Control Council for Interference (VCCI)の規格に準拠したクラスB製品です。この機器をラジオやテレビ受信機の近くで使用した場合、混信が発生する恐れがあります。本機器の設置および使用に際しては、取扱説明書に従ってください。 |

19841

2.2 Safety standards compliance

This section describes the ONT compliance with the European safety standards.

2.2.1 EMC, EMI, and ESD compliance

The ONT equipment complies with the following EMC, EMI, and ESD requirements:

- EN301-489 v1.9.1 wide band data transmission standards for 2.4GHz bands
- EN 300-386 V1.5.1: Electromagnetic Compatibility and Radio Spectrum Matters (ERM): Telecommunications Network Equipment; Electromagnetic Compatibility (EMC) requirements; Electrostatic Discharge (ESD) requirements
- EN 55022 (2006): Class B, Information Technology Equipment, Radio Disturbance Characteristics, limits and methods of measurement
- EN 55024 (2010): Information Technology Equipment, Immunity Characteristics, limits and methods of measurement
- European Council Directive 2004/108/EC
- EN 300-386 V1.4.1: 2008
- EN 55022:2006 Class B (ONTs)

2.2.2 Equipment safety standard compliance

The ONT equipment complies with the requirements of EN 62368-1, Safety of Information Technology Equipment for use in a restricted location (per R-269).

2.2.3 Environmental standard compliance

The ONT equipment complies with the EN 300 019 European environmental standards.

2.2.4 Laser product standard compliance

For most ONTs, the ONT equipment complies with EN 60825-1 and IEC 60825-2 for laser products. If there is an exception to this compliance regulation, you can find this information in the standards compliance section of the unit data sheet in this Product Guide.

2.2.5 Resistibility requirements compliance

The ONT equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to over voltage and over currents.

2.2.6 Acoustic noise emission standard compliance

The ONT equipment complies with EN 300 753 acoustic noise emission limit and test methods.

2.3 Electrical safety guidelines

This section provides the electrical safety guidelines for the ONT equipment.

 **Note:** The ONTs comply with the U.S. National Electrical Code. However, local electrical authorities have jurisdiction when there are differences between the local and U.S. standards.

The ONTs comply with BS EN 61140.

2.3.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

2.3.2 Cabling

The following are the guidelines regarding cables used for the ONT equipment:

- All cables must be approved by the relevant national electrical code.
- The cables for outdoor installation of ONTs must be suitable for outdoor use.
- POTS wiring run outside the subscriber premises must comply with the requirements of local electrical codes. In some markets, the maximum allowed length of the outside run is 140 feet (43 m). If the outside run is longer, NEC requires primary protection at both the exit and entry points for the wire.

2.3.3 Protective earth

Earthing and bonding of the ONTs must comply with the requirements of local electrical codes.

2.4 ESD safety guidelines

The ONT equipment is sensitive to ESD. Operations personnel must observe the following ESD instructions when they handle the ONT equipment.



CAUTION

Service Disruption

This equipment is ESD sensitive. Proper ESD protections should be used when you enter the TELCO Access portion of the ONT.

During installation and maintenance, service personnel must wear wrist straps to prevent damage caused by ESD.

2.5 Laser safety guidelines

Observe the following instructions when you perform installation, operations, and maintenance tasks on the ONT equipment.

Only qualified service personnel who are extremely familiar with laser radiation hazards should install or remove the fiber optic cables and units in this system.



DANGER

Hazard

There may be invisible laser radiation at the fiber optic cable when the cable is removed from the connector. Avoid direct exposure to the laser beam.

Observe the following danger for laser hazard. Eyes can be damaged when they are exposed to a laser beam. Take necessary precautions before you plug in the optical modules.



DANGER

Hazard

Possibility of equipment damage. Risk of eye damage by laser radiation.

2.5.1 Laser classification


The ONT is classified as a Class 1 laser product based on its transmit optical output.

Laser warning labels

The following figures show the labels related to laser product, classification and warning.

The following figure shows a laser product label.

Figure 2-2 Laser product label



18455

Figure 2-3, “Laser classification label” (p. 30) shows a laser classification label. Laser classification labels may be provided in other languages.

Figure 2-3 Laser classification label






Figure 2-4, “Laser warning labels” (p. 31) shows a laser warning label and an explanatory label for laser products. Labels and warning may be provided in other languages. The explanatory label provides the following information:

- A warning that calls attention to the invisible laser radiation
- An instruction against staring into the beam or viewing directly with optical instruments
- Wavelength
- Normal output power
- Maximum output power


Figure 2-4 Laser warning labels



Laser Warning Label



Laser Warning Label



Laser Warning Label

18993

2.5.2 Transmit optical output

The maximum transmit optical output of an ONT is +9 dBm.

2.5.3 Normal laser operation

In normal operation, fiber cable laser radiation is always off until it receives signal from the line terminal card.

Eyes can be damaged when they exposed to a laser beam. Operating personnel must observe the instructions on the laser explanatory label before plugging in the optical module.



DANGER

Hazard

Risk of eye damage by laser radiation.

2.5.4 Location class

Use cable supports and guides to protect the receptacles from strain.

2.6 Environmental requirements

See the ONT technical specification documentation for more information about temperature ranges.

During operation in the supported temperature range, condensation inside the ONT caused by humidity is not an issue. To avoid condensation caused by rapid changes in temperature and humidity, Nokia recommends:

- The door of the ONT not be opened until temperature inside and outside the enclosure has stabilized.
- If the door of the ONT must be opened after a rapid change in temperature or humidity, use a dry cloth to wipe down the metal interior to prevent the risk of condensation.
- When high humidity is present, installation of a cover or tent over the ONT helps prevent condensation when the door is opened.

3 ETSI environmental and CRoHS guidelines

This chapter provides information about the ETSI environmental China Restriction of Hazardous Substances (CRoHS) regulations that govern the installation and operation of the optical line termination (OLT) and optical network termination (ONT) systems. This chapter also includes environmental operation parameters of general interest.

3.1 Environmental labels

This section describes the environmental instructions that are provided with the customer documentation, equipment, and location where the equipment resides.

3.1.1 Overview

CRoHS is applicable to Electronic Information Products (EIP) manufactured or sold and imported in the territory of the mainland of the People's Republic of China. EIP refers to products and their accessories manufactured by using electronic information technology, including electronic communications products and such subcomponents as batteries and cables.

3.1.2 Environmental related labels

Environmental labels are located on appropriate equipment. The following are sample labels.

Products below Maximum Concentration Value (MCV) label

[Figure 3-1, "Products below MCV value label" \(p. 34\)](#) shows the label that indicates a product is below the maximum concentration value, as defined by standard SJ/T11363-2006 (Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products). Products with this label are recyclable. The label may be found in this documentation or on the product.

Figure 3-1 Products below MCV value label



18986

Products containing hazardous substances above Maximum Concentration Value (MCV) label

Figure 3-2, “Products above MCV value label” (p. 34) shows the label that indicates a product is above the maximum concentration value, as defined by standard SJ/T11363-2006 (Requirements for Concentration Limits for Certain Hazardous Substances in Electronic Information Products). The number contained inside the label indicates the Environment-Friendly User Period (EFUP) value. The label may be found in this documentation or on the product.

Figure 3-2 Products above MCV value label



Together with major international telecommunications equipment companies, Nokia has determined it is appropriate to use an EFUP of 50 years for network infrastructure equipment and an EFUP of 20 years for handsets and accessories. These values are based on manufacturers' extensive practical experience of the design, manufacturing, maintenance, usage conditions, operating

environments, and physical condition of infrastructure and handsets after years of service. The values reflect minimum values and refer to products operated according to the intended use conditions. See 3.2 “Hazardous Substances Table (HST)” (p. 34) for more information.

3.2 Hazardous Substances Table (HST)

This section describes the compliance of the OLT and ONT equipment to the CRoHS standard when the product and sub assemblies contain hazardous substances beyond the MCV value. This information is found in this user documentation where part numbers for the product and sub assemblies are listed. It may be referenced in other OLT and ONT documentation.

In accordance with the People’s Republic of China Electronic Industry Standard Marking for the Control of Pollution Caused by Electronic Information Products (SJ/T11364-2006), customers may access the Nokia Hazardous Substance Table, in Chinese, from the following location <http://www.nokia-sbell.com.cn/wwwroot/images/upload/private/1/media/ChinaRoHS.pdf>

3.3 Other environmental requirements

Observe the following environmental requirements when handling the P-OLT or ONT equipment.

3.3.1 ONT environmental requirements

See the ONT technical specification documentation for more information about temperature ranges.

3.3.2 Storage

According to ETS 300-019-1-1 - Class 1.1, storage of ONT equipment must be in Class 1.1, weather-protected, temperature-controlled locations.

3.3.3 Transportation

According to EN 300-019-1-2 - Class 2.3, transportation of the ONT equipment must be in packed, public transportation with no rain on packing allowed.

3.3.4 Stationary use

According to EN 300-019-1-3 - Class 3.1/3.2/3.E, stationary use of ONT equipment must be in a temperature-controlled location, with no rain allowed, and with no condensation allowed.

3.3.5 Material content compliance

European Union (EU) Directive 2002/95/EC, “Restriction of the use of certain Hazardous Substances” (RoHS), restricts the use of lead, mercury, cadmium, hexavalent chromium, and certain flame retardants in electrical and electronic equipment. This Directive applies to electrical and electronic products placed on the EU market after 1 July 2006, with various exemptions, including an exemption for lead solder in network infrastructure equipment. Nokia products shipped to the EU after 1 July 2006 comply with the EU RoHS Directive.

Nokia has implemented a material/substance content management process. The process is described in: Nokia process for ensuring RoHS Compliance (1AA002660031ASZZA). This ensures compliance with the European Union Directive 2011/65/EU on the Restriction of the Use of Certain

Hazardous Substances in Electrical and Electronic Equipment (RoHS2). With the process equipment is assessed in accordance with the Harmonised Standard EN50581:2012 (CENELEC) on Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances.

3.3.6 End-of-life collection and treatment

Electronic products bearing or referencing the symbol shown in [Figure 3-3, “Recycling/take back/disposal of product symbol” \(p. 35\)](#), when put on the market within the European Union (EU), shall be collected and treated at the end of their useful life, in compliance with applicable EU and local legislation. They shall not be disposed of as part of unsorted municipal waste. Due to materials that may be contained in the product, such as heavy metals or batteries, the environment and human health may be negatively impacted as a result of inappropriate disposal.

i **Note:** In the European Union, a solid bar under the symbol for a crossed-out wheeled bin indicates that the product was put on the market after 13 August 2005.

Figure 3-3 Recycling/take back/disposal of product symbol



At the end of their life, the OLT and ONT products are subject to the applicable local legislations that implement the European Directive 2012/19EU on waste electrical and electronic equipment (WEEE).

There can be different requirements for collection and treatment in different member states of the European Union.

In compliance with legal requirements and contractual agreements, where applicable, Nokia will offer to provide for the collection and treatment of Nokia products bearing the logo shown in [Figure 3-3, “Recycling/take back/disposal of product symbol” \(p. 36\)](#) at the end of their useful life, or products displaced by Nokia equipment offers. For information regarding take-back of equipment by Nokia, or for more information regarding the requirements for recycling/disposal of product, contact your Nokia account manager or Nokia take back support at sustainability.global@nokia.com.

4 ANSI ONT safety guidelines

This chapter provides information about the mandatory regulations that govern the installation and operation of the optical network terminals or units (ONTs or ONUs) in the North American or ANSI market.

4.1 Safety instructions

This section describes the safety instructions that are provided in the ONT customer documentation and on the equipment.

4.1.1 Safety instruction boxes in customer documentation

The safety instruction boxes are provided in the ONT customer documentation. Observe the instructions to meet safety requirements.

The following is an example of the Danger box.



Possibility of personal injury.

The Danger box indicates that the described activity or situation may pose a threat to personal safety. It calls attention to a situation or procedure which, if not correctly performed or adhered to, may result in death or serious physical harm.

Do not proceed beyond a Danger box until the indicated conditions are fully understood and met.

The following is an example of the Warning box.



Possibility of equipment damage.

Possibility of data loss.

The Warning box indicates that the described activity or situation may, or will, cause equipment damage, loss of data, or serious performance problems. It identifies a possible equipment-damaging situation or provides essential information to avoid the degradation of system operations or data.

Do not proceed beyond a warning until the indicated conditions are fully understood and met.

The following is an example of the Caution box.



CAUTION

Service Disruption

Possibility of service interruption.

Service interruption.

The Caution box indicates that the described activity or situation may, or will, cause service interruption.

Do not proceed beyond a caution until the indicated conditions are fully understood and met.

The following is an example of the Note box.



Note: Information of special interest.

The Note box provides information that assists the personnel working with ONTs. It does not provide safety-related instructions.

4.1.2 Safety-related labels

The ONT equipment is labeled with specific safety compliance information and instructions that are related to a variant of the ONT. Observe the instructions on the safety labels.


The following table provides examples of the text in the various ONT safety labels.

Table 4-1 Safety labels

| Description | Label text |
|--|---|
| UL compliance | Communication service equipment US listed. Type 3R enclosure - Rainproof. |
| TUV compliance | Type 3R enclosure - Rainproof. |
| ESD warning | Caution: This assembly contains electrostatic sensitive device. |
| Laser classification | Class 1 laser product |
| Laser product compliance | This laser product conforms to all applicable standards of 21 CFR 1040.10 at date of manufacture. |
| FCC standards compliance | Tested to comply with FCC standards for home or office use. |
| CDRH compliance | Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 |
| Operation conditions | This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. |
| Canadian standard compliance (modular ONT) | This Class A digital apparatus complies with Canadian ICES-003. |
| Canadian standard compliance (outdoor ONT) | This Class B digital apparatus complies with Canadian ICES-003. |
| CE marking | There are various CE symbols for CE compliance. |

The following table shows a sample safety label on the ONT equipment.

Figure 4-1 Sample safety label on the ONT equipment



18533

4.2 Safety standards compliance

This section describes the ONT compliance with North American safety standards.



WARNING

Equipment Damage

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

4.2.1 EMC, EMI, and ESD standards compliance

The ONT equipment complies with the following requirements:

- Federal Communications Commission (FCC) CFR 47, Part 15, Subpart B, Class A requirements for OLT equipment
- GR-1089-CORE requirements, including:
 - Section 3 Electromagnetic Interference, Emissions Radiated and Conducted
 - Section 3 Immunity, Radiated and Conducted
 - Section 2 ESD Discharge Immunity: System Level Electrostatic Discharge and EFT Immunity: Electrically Fast Transients

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

4.2.2 Equipment safety standard compliance

The ONT equipment complies with the requirements of IEC6236-8, Outdoor ONTs to “Communication Service Equipment” (CSE) and Indoor ONTs to Information Technology Equipment (ITE).

4.2.3 Environmental standards compliance

The ONT equipment complies with the following standards:

- GR-63-CORE (NEBS): requirements related to operating, storage, humidity, altitude, earthquake, office vibration, transportation and handling, fire resistance and spread, airborne contaminants, illumination, and acoustic noise
- GR-487-CORE: requirements related to rain, chemical, sand, and dust
- GR-487 R3-82: requirements related to condensation
- GR-3108: Requirements for Network Equipment in the Outside Plant (OSP)
- TP76200: Common Systems Equipment Interconnections Standards

4.2.4 Laser product standards compliance

The ONT equipment complies with 21 CFR 1040.10 and CFR 1040.11, except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007” or to 21 CFR 1040.10 U.S. Center for Devices and Radiological Health (CDRH) of the Food and Drug Administration (FDA) Laser Notice 42 for ONTs containing Class 1 Laser modules certified by original manufactures.


Per CDRH 21 CFR 10.40.10 (h) (1) (iv) distributors of Class 1 laser products, such as Nokia ONTs shall leave the following Laser Safety cautions with the end user.

a) “Class 1 Laser Product”

b) “Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.”

[Figure 4-2, “Sample laser product label showing CDRH 21 CFR compliance” \(p. 41\)](#) shows a laser product label.

Figure 4-2 Sample laser product label showing CDRH 21 CFR compliance



4.2.5 Resistibility requirements compliance

The ONT equipment complies with the requirements of ITU Recommendation K.21 for resistibility of telecommunication equipment installed in customer premises to over voltage and over currents.

4.3 Laser safety guidelines

Only qualified service personnel who are extremely familiar with laser radiation hazards should install or remove the fiber optic cables and units in this system.

Observe the following warnings when you perform installation, operations, and maintenance tasks on the ONT equipment.



There may be invisible laser radiation at the fiber optic cable when the cable is removed from the connector. Avoid direct exposure to beam.

Observe the following danger for a laser hazard. Eyes can be damaged when they are exposed to a laser beam. Take necessary precautions before you plug in the optical modules.



Possibility of equipment damage. Risk of eye damage by laser radiation.

Per CDRH 21 CFR 10.40.10 (h) (1) (iv) distributors of Class 1 laser products, such as Nokia ONTs shall leave the following Laser Safety cautions with the end user.


- a) "Class 1 Laser Product"
- b) "Caution – Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure."

4.3.1 Laser warning labels

The following figures show sample labels related to laser product, classification and warning.

Figure 4-3, "Laser product label" (p. 42) shows a laser product label.


Figure 4-3 Laser product label



18455

Figure 4-4, “Laser classification label” (p. 42) shows a laser classification label. Laser classification labels may be provided in other languages.

Figure 4-4 Laser classification label




18992


Figure 4-5, “Laser warning labels” (p. 43) shows a laser warning label and an explanatory label for laser products. Explanatory labels may be provided in other languages. The explanatory label provides the following information:

- A warning that calls attention to the invisible laser radiation
- An instruction against staring into the beam or viewing directly with optical instruments
- Wavelength
- Normal output power
- Maximum output power


Figure 4-5 Laser warning labels



Laser Warning Label



Laser Warning Label



Laser Warning Label

18993


4.3.2 Laser classification

The ONT is classified as a Class 1 laser product based on its transmit optical output.

For Class 1 laser products, lasers are safe under reasonably foreseeable conditions of operation, including the use of optical instruments for intrabeam viewing.

[Figure 4-6, "Sample laser product safety label on the ONT equipment" \(p. 44\)](#) shows a sample laser product safety label on the ONT equipment.

Figure 4-6 Sample laser product safety label on the ONT equipment



18532

4.3.3 Transmit optical output

The maximum transmit optical output of an ONT is +5 dBm.

4.3.4 Normal laser operation

In normal operation, fiber cable laser radiation is always off until it receives signal from the line terminal card.

Operating personnel must observe the instructions on the laser explanatory label before plugging in the optical module.



DANGER

Hazard

Risk of eye damage by laser radiation.

4.3.5 Location class

Use cable supports and guides to protect the receptacles from strain.

4.4 Electrical safety guidelines

This section provides the electrical safety guidelines for the ONT equipment.



Note: The ONTs comply with the U.S. National Electrical Code. However, local electrical authorities have jurisdiction when there are differences between the local and U.S. standards.

4.4.1 Power supplies

The use of any non-Nokia approved power supplies or power adapters is not supported or endorsed by Nokia. Such use will void any warranty or support contract with Nokia. Such use greatly increases the danger of damage to equipment or property.

4.4.2 Cabling

The following are the guidelines regarding cables used for the ONT equipment:

- Use only cables approved by the relevant national electrical code.
- Use cables suitable for outdoor use for outdoor installation of ONTs.
- The ONTs have been evaluated for use with external POTS wiring without primary protection that may not exceed 140 ft (43 m) in reach. However, the power cable must not exceed 100 ft (31 m).

4.4.3 Protective earth

Earthing and bonding of the ONTs must comply with the requirements of NEC article 250 or local electrical codes.

4.5 ESD safety guidelines

The ONT equipment is sensitive to ESD. Operations personnel must observe the following ESD instructions when they handle the ONT equipment.



CAUTION

Service Disruption

This equipment is ESD sensitive. Proper ESD protections should be used when entering the TELCO Access portion of the ONT.

During installation and maintenance, service personnel must wear wrist straps to prevent damage caused by ESD.

Nokia recommends that you prepare the site before you install the ONT equipment. In addition, you must control relative humidity, use static dissipating material for furniture or flooring, and restrict the use of air conditioning.

4.6 Environmental requirements

See the ONT technical specification documentation for temperature ranges for ONTs.

During operation in the supported temperature range, condensation inside the ONT caused by humidity is not an issue. To avoid condensation caused by rapid changes in temperature and humidity, Nokia recommends:

- The door of the ONT not be opened until temperature inside and outside the enclosure has stabilized.
- If the door of the ONT must be opened after a rapid change in temperature or humidity, use a dry cloth to wipe down the metal interior to prevent the risk of condensation.

-
- When high humidity is present, installation of a cover or tent over the ONT helps prevent condensation when the door is opened.

5 XS-2426X-A unit data sheet

5.1 Overview

5.1.1 Purpose

5.1.2 Contents

| | |
|--|----|
| 5.1 Overview | 47 |
| 5.2 XS-2426X-A part numbers and identification | 47 |
| 5.3 XS-2426X-A general description | 50 |
| 5.4 XS-2426X-A software and installation feature support | 56 |
| 5.5 XS-2426X-A interfaces and interface capacity | 56 |
| 5.6 XS-2426X-A LEDs | 59 |
| 5.7 XS-2426X-A detailed specifications | 61 |
| 5.8 XS-2426X-A GEM ports and T-CONTs | 62 |
| 5.9 XS-2426X-A performance monitoring statistics | 63 |
| 5.10 XS-2426X-A functional blocks | 63 |
| 5.11 XS-2426X-A standards compliance | 64 |
| 5.12 XS-2426X-A special considerations | 66 |

5.2 XS-2426X-A part numbers and identification

Table 5-1, “Identification of XS-2426X-A indoor ONTs” (p. 47) provides part numbers and identification information for the XS-2426X-A indoor ONT.

Table 5-1 Identification of XS-2426X-A indoor ONTs

| Ordering kit part number | Provisioning number | Description | CLEI Code | CPR | ECI/ Bar code |
|--------------------------|---------------------|--|-----------|-----|---------------|
| 3FE 49690 AA | 3FE 49691 AA | NAR, Molex PS, US Plug, XGS-PON, 2xPOTS, 3xGE+1x10GE, Wi-Fi 6, 4x4 + 4x4 Includes one USB 3.0 Type A port and a 12V 3A wall mounted AC/DC power adapter with 2-pin US input plug. | — | — | — |
| 3FE 49691 AA | 3FE 49691 AA | NAR, Molex PS, US Plug, XGS-PON, 2xPOTS, 3xGE+1x10GE, Wi-Fi 6, 4x4 + 4x4 Includes one USB 3.0 Type A port ONT only. | — | — | — |

Table 5-1 Identification of XS-2426X-A indoor ONTs (continued)

| Ordering kit part number | Provisioning number | Description | CLEI Code | CPR | ECI/ Bar code |
|-----------------------------------|---------------------|--|-----------|-----|---------------|
| 3FE 49690 AB | 3FE 49691 AB | Canada, US Plug, Wi-Fi GPON RGW, 2xPOTS, 3xGE, 1x10GE, 1x USB, WiFi-6 4x4 + 4x4 US 2-pin AC/ 8-pin Molex DC. | — | — | — |
| 3FE 49690 BA | 3FE 49691 BA | EU Plug, Molex PS. Wi-Fi GPON RGW, 2xPOTS, 3xGE, 1x10GE, 1x USB, WiFi-6 4x4 + 4x4 2-Pin, Wall-mounted, 12V. | — | — | — |
| 3FE 49690 CA | 3FE 49691 CA | UK Plug, Molex PS, Wi-Fi GPON RGW, 2xPOTS, 3xGE, 1x10GE, 1x USB, WiFi-6 4x4 + 4x4 3-Pin, Wall-mounted, 12V. | — | — | — |
| 3FE 49690 DA Customer-specific | 3FE 49691 DA | AU Plug, Wall-mounted, 12V. XGS-PON, 2xPOTS, 3xGE+1x10GE, Wi-Fi 6, 4x4 + 4x4. | — | — | — |
| 3FE 49690 DB Customer-specific | 3FE 49691 DB | AU Plug, Wall-mounted, 12V. XGS-PON, 2xPOTS, 3xGE+1x10GE, Wi-Fi 6, 4x4 + 4x4. | — | — | — |
| 3FE 49690 EA | 3FE 49691 EA | Japan, Molex PS, JP Plug, XGS-PON, 2xPOTS, 3xGE+1x10GE, Wi-Fi 6, 4x4 + 4x4 Includes one USB 3.0 Type A port and a 12V 3A wall-mounted AC/DC power adapter with 2-pin JP input plug. | — | — | — |

Table 5-2, “XS-2426X-A power supply ordering information” (p. 48) provides the power supply information for the XS-2426X-A ONT. For more information on power supplies, see the **Nokia ONT Power Supply and UPS Guide**.

Table 5-2 XS-2426X-A power supply ordering information

| ONT part numbers | Power information (Model No./Manufacture Part Number) | Power information | Customer category or country compliance tested for | Notes |
|--|--|--|--|---------------------|
| Kit: 3FE 49690 AA EMA: 3FE 49691 AA | FUHUA:UES36WU-120300SPA/ UE211006GWZF2RI HONOR:ADS-40FKJ-12N 12036EPCU/ 9040108111201203R | 12V/3A mounted AC/DC Power Adapter with 2-Pin US input Plug, Molex output plug | ANSI municipality US, Canada FCC/UL IEC62368 | 2-pin US input plug |
| Kit: 3FE 49690 AB EMA: 3FE 49691 AB | FUHUA:UES36WU-120300SPA/ UE211006GWZF2RI HONOR:ADS-40FKJ-12N 12036EPCU/ 9040108111201203R | 12V/3A mounted AC/DC Power Adapter with 2-Pin US input Plug, Molex output plug | ANSI municipality US, Canada FCC/UL IEC62368 | 2-pin US input plug |

Table 5-2 XS-2426X-A power supply ordering information (continued)

| ONT part numbers | Power information (Model No./Manufacture Part Number) | Power information | Customer category or country compliance tested for | Notes |
|--|---|---|--|------------------------|
| Kit: 3FE 49690 BA EMA: 3FE 49691 BA | FUHUA:UES36WV-120300SPA/ UE211006GWZF1RI HONOR:ADS-40FKJ-12N 12036EPG/ 9040108111202203R | 12V/3A mountedAC/DC PowerAdapter with2-Pin EU inputPlug, Molexoutput plug | CE certified | 2-pin EU input plug |
| Kit: 3FE 49690 CA EMA: 3FE 49691 CA | FUHUA:UES36WB-120300SPA/ UE211006GWZF3RI HONOR:ADS-40FKJ-12N 12036EPB/ 9040108111206202R | 12V/3A mountedAC/DC PowerAdapter with3-Pin UK inputPlug, Molexoutput plug | UKCA certified | 3-pin UK input plug |
| Kit: 3FE 49690 DA EMA: 3FE 49691 DA | HONOR:ADS-36FKJ-12N 12036EPSA-H/ 903610810003203R | 12V/3A mountedAC/DC PowerAdapter with2-Pin AU inputPlug, Molexoutput plug | RCM certified | 2-pin AU input plug |
| Kit: 3FE 49690 DB EMA: 3FE 49691 DB | HONOR:ADS-36FKJ-12N 12036EPSA-H/ 903610810003203R | 12V/3A mountedAC/DC PowerAdapter with2-Pin AU inputPlug, Molexoutput plug | RCM certified | 2-pin AU input plug |
| Kit: 3FE 49690 EA EMA: 3FE 49691 EA | FUHUA:UES36WU-120300SPA/ UE211006GWZF5RI HONOR:ADS-36FKJ-12 12036EPC/ 9036108111207201R | 12V/3A mounted AC/DC Power Adapter with 2-Pin JP input Plug, Molex output plug | Japan PSE certificate | 2-pin JP input plug |

Table 5-3 XS-2426X-A UPS ordering information

| Power/UPS model | Power UPS and cabling part number information | Customer category or country compliance tested for | Notes |
|----------------------------|--|--|--|
| CyberPower DTC36U12V3-G | Recommended 36W UPS for ANSI municipal operators and utilities: (1) Part number: 3MV00555AA UPS: 36W CyberPower UPS DTC36U12V3-G (2) Part numbers: 3EM24378AA (ONT DC power and alarms cable 8 ft) 3EM24378AB (ONT DC power and alarms cable 25 ft) (3) Part number: 1AF17581ACAA Battery: Battery, 12 V, 7.8 Ah | ANSI municipality United States, Canada | UPS provides 8 hours of support AC power cord included with UPS. |

Table 5-4, “Hardware parts required for XS-2426X-A installations” (p. 49) lists the hardware parts required for mounting an XS-2426X-A ONT.

Table 5-4 Hardware parts required for XS-2426X-A installations

| Part | Description |
|-----------------------------------|---|
| ONT unit | The XS-2426X-A ONT. |
| Wall mount bracket (3FE 49987 AA) | The wall mount bracket is fastened to a wall. The XS-2426X-A ONT is seated in the wall mount bracket. With white color, 1 pcs per box. |
| Wall mount bracket (3FE 49987 AB) | The wall mount bracket is fastened to a wall. The XS-2426X-A ONT is seated in the wall mount bracket. With white color, 24 pcs per box. |
| Mounting screws | Two screws are required to mount the wall mount bracket. The recommended screw is a M4 or #6 screw with a pan head style of screw head. |

5.3 XS-2426X-A general description


XS-2426X-A indoor ONTs provide the subscriber interface for the network by terminating the PON interface and converting it to user interfaces that directly connect to subscriber devices.

The XS-2426X-A has built-in Wi-Fi 802.11 b/g/n/ac/ax networking with triple play capability and can provide triple play services with voice, video and data.

The ONT is compatible with all existing subscriber equipment, including analog phones with both tone and rotary dial capabilities, cordless phones, modems, fax machines, and caller ID boxes (Type I, Type II, and Type III).

The ONT can be placed on a flat surface, such as a desk or shelf and on a wall with bracket.

Figure 5-1 XS-2426X-A ONT



36995

XS-2426X-A indoor ONTs provide the following functions:

- Supports 802.1x port authentication configured via OMCI.
- Dual-band concurrent 4x4 802.11b/g/n/ac/ax 2.4 GHz and 4x4 802.11ac/ax MU-MIMO 5 GHz
- Supports 802.11b/g/n/ac/ax 4x4 Wireless 2.4 GHz MIMO; Channel bandwidth 20, 40 MHz, auto
- Supports 802.11ac/ax 4x4 Wireless 5 GHz Mu-MIMO; Channel bandwidth 20, 40, 80, 160 MHz, auto
- Three Gigabit standard RJ-45 1000/100/10 Mbps, auto negotiating Ethernet ports and MDI/MDIX auto sensing, one 10 Gigabit Ethernet port RJ-45 10G/5G/2.5G/1G/100M auto-negotiating
- Two POTS ports with RJ-11 connectors
- One USB 3.0 Type A port
- XGS-PON Uplink, G.9807.1, G.988 series standard compliant
- 512 MB NAND Flash with bad block management, 1 GB DDR3 RAM, pin2pin compatible design for possible upgrade of RAM/Flash
- Three RJ-45 1000/100/10 Mbps Ethernet ports with auto negotiation and MDI/MDIX auto sensing
- WLAN on/off push button
- WPS on/off push button
- Reset button
- Triple-Play services, including voice, video and high speed Internet access
- Support for fax services

-
- Built-in layer 2 switch; Line Rate L2 traffic
 - IP video distribution
 - Wavelength: 1577 nm downstream; 1270 nm upstream
 - Supports WBF filter. The GPON ONTs can co-exist with XGS-PON ONTs in the same PON.
 - Line rate: 9.953 Gb/s downstream and upstream
 - 4 inner antennas for 2.4G, 4 inner antennas for 5G
 - Optics that support received signal strength indication (RSSI)
 - 64/128 WEP encryption
 - WPA, WPA-PSK/TKIP
 - WPA2, WPA2-PSK/AES
 - WPA3, WPA3-SAE
 - VLAN tagging/detagging and marking/remarking of IEEE 802.1p per Ethernet port.
 - Dying gasp support
 - Voice Services via Session Initiation Protocol (SIP)
 - Multiple voice Code
 - DTMF dialing
 - Echo cancellation (G.168)
 - Fax mode configuration (T.30/T.38)
 - Caller ID, call waiting, call hold, 3-way calling, call transfer, message waiting
 - Forward Error Correction (FEC)
 - Support for multiple SSIDs (private and public instances); contact your Nokia representative for further details.
 - Conductive power: 250 mW/24 dBm (2.4 GHz); 500 mW/27 dBm (5 GHz)
 - Maximum effective isotropic radiated power (EIRP): 500 mW/27 dBm (2.4 GHz); 1000 mW/30 dBm (5 GHz)
 - Ethernet-based Point-to-Point (PPPoE)
 - DHCP client/server
 - DNS server/client
 - DDNS
 - Port forwarding
 - Network Address Translation (NAT)
 - Network Address Port Translation (NAPT)
 - UPnP IGD2.0 support
 - ALG
 - IGMP snooping and proxy (v2/v3)
 - Traffic classification and QoS capability
 - OMCI/TR-069 Web GUI configuration

-
- Performance monitoring and alarm reporting
 - Remote software image downloading and activation
 - IP/MAC/URL filter
 - Multi-level firewall and ACL
 - iPerf3 UDP speed test support
 - Supports bridged forwarding from LAN to WAN with three modes (transparent mode, tunnel mode and VLAN-binding mode)
 - Supports bridged WAN and VLAN binding
 - Ethernet ports on AP/Beacons inherit the configuration from the root devices

5.3.1 TR-069 parameter support

The XS-2426X-A ONT supports the following TR-069 features:

- Host object
- Port forwarding
- Optical parameters
- Object support for Wi-Fi parameters
- Statistics and troubleshooting
- Diagnostic parameters

Host object support

The ONT provides host object support for: InternetGatewayDevice.LANDevice.Hosts.Host.

Port forwarding support

The ONT supports the port forwarding of objects via TR-069:

- Application Name
- WAN Port
- LAN Port
- Internal Client
- Protocol
- Enable Mapping
- WAN Connection List

These port forwarding parameters are also supported in the GUI. For more information, see [Table 7-34, “Port forwarding parameters” \(p. 171\)](#) in [Chapter 7, “Configure an XS-2426X-A indoor ONT”](#).

Optical parameters support

The ONT supports the reading of optical parameters via TR-069:

- Laser bias current
- Voltage

- Temperature
- Received signal levels
- Lower thresholds

These optical parameters are also supported in the GUI. For more information, see [Table 7-6, “Optical module status parameters”](#) (p. 107) in [Chapter 7, “Configure an XS-2426X-A indoor ONT”](#).

Object support for Wi-Fi parameters

The ONT supports the status retrieval and configuration of the following Wi-Fi parameters via TR-069:

- Channel
- SSID
- Password for WPA
- Tx power (transmission rate in percentage of maximum transmit power)
- WPS

These TR-069 object parameters are also supported in the GUI. For more information, see [Table 7-19, “Wireless 2.4 GHz parameters”](#) (p. 137) and [Table 7-20, “Wireless 5 GHz parameters”](#) (p. 139) in [Chapter 7, “Configure an XS-2426X-A indoor ONT”](#).

Statistics and troubleshooting support

The ONT supports TR-069 statistics and troubleshooting for LAN, WAN, and WiFi.

Diagnostic parameter support

The ONT supports the following TR-069 diagnostic parameters:

- TR-143
- IP ping
- Traceroute

These diagnostic parameters are also supported in the GUI. For more information, see the [Procedure 7.10 “Configuring TR-069”](#) (p. 102) in [Chapter 7, “Configure an XS-2426X-A indoor ONT”](#).

5.3.2 TR-069 authentication using TLS and CA certificates

XS-2426X-A ONTs support TLS as well as ACS authentication using SHA-256 pre-installed certificates.

If the URL is set to the HTTPS format, by default, the connection will use TLS without authentication mode. The ONT can also authenticate the ACS using a pre-installed CA certificate.

The XS-2426X-A ONTs support TLSv1.3 for TR069. The ONT supports certification download from ACS.

5.3.3 TR-104 parameter extension support for voice service

A vendor-specific attribute has been added to the TR-104 Voice Service object structure to enable the ACS to configure the name of the embedded GSIP XML file to be selected.

The TR-104 Voice Service Object is:
InternetGatewayDevice.Services.VoiceService.{i}.Capabilities.SIP.

The vendor-specific attribute is: X_ALU-COM_XML_File_Name_Path.

5.3.4 TR-104 voice-related alarms

The XS-2426X-A ONT supports the following four TR-104 voice-related alarms per FXS port.

These alarms represent SIP registration failures with an alarm level of MAJOR.

- SIPREGDNS: domain name could not be resolved
- SIPREGAUTH: authentication failed
- SIPREGTO: re-transmissions timed out
- SIPREGERR: error response from the registration server

5.3.5 TR-104 parameters for FX line testing

New attributes have been added to the TR-104 Voice Service object structure to enable the ACS to perform line tests. The ONT supports the following electrical line tests:

- Hazardous potential
- Foreign electrical motive force
- Resistive faults
- Receiver off-hook test
- Ringers test

5.3.6 TR-111 support

The XS-2426X-A ONT supports TR-111, which extends the WAN Management Protocol defined in TR-069 to enhance the ability to remotely manage LAN devices.

The device-gateway association enables an ACS to identify the associated gateway through which a device is connected.

A connect request via the NAT gateway enables an ACS to initiate a TR-069 session with a device that is operating behind a NAT gateway.

5.3.7 TR-157 support

The ONT can support LXC container for third party software components on ONTs with minimal 512 M memory. These software components are managed by ACS with the parameters defined in TR-157.

The TR-157 objects:

- Manage each software component via SoftwareModules.DeploymentUnit.{i}
- Set software component execution environment via SoftwareModules.ExecEnv.{i}

- Run software component and get the execution status via SoftwareModules.ExecutionUnit.{i}

i **Note:** The device reserves and limits to 64 MB RAM and 32 MB flash in total for all of the third party applications. The maximum CPU load created or provided to the third party application is limited to approximately 30%. Underlying non-priority processes may still use the remaining memory on a temporary basis.

Nokia can assist to review specific applications, taking into account the actual memory load of the current hardware, current and projected software evolution over time, and the projected use by a third party application of the software.

5.4 XS-2426X-A software and installation feature support

For information on installing or replacing the XS-2426X-A see [Chapter 6, "Install or replace an XS-2426X-A indoor ONT"](#).

For information on the following topics, see the **Nokia ONT Product Overview Guide**:

- ONT and MDU general descriptions of features and functions
- Ethernet interface specifications
- POTS interface specifications
- RSSI specifications
- Wi-Fi specifications
- ONT optical budget
- SLID entry via Ethernet port
- ONT management using an ONT interface

5.5 XS-2426X-A interfaces and interface capacity

[Table 5-5, "XS-2426X-A indoor ONT interface connection capacity"](#) (p. 56) describes the supported interfaces and interface capacity for XS-2426X-A indoor ONTs.

Table 5-5 XS-2426X-A indoor ONT interface connection capacity

| ONT type and model | Maximum capacity | | | | | | | | | | |
|--------------------|------------------|---------------------|---------------|--------------------|-----------------|------|-----|-------|-------|-------------|----------------|
| | POTS | 10G/5G/2.5G/1G/100M | 100/10 BASE-T | 1000/100/10 BASE-T | RF video (CATV) | MoCA | USB | VDSL2 | E1/T1 | Local craft | XGS-PON SC/APC |
| XS-2426X-A | 2 | 1 | — | 3 | — | — | 1 | — | — | — | 1 |


Notes:

1. The XS-2426X-A ONTs provide Wi-Fi service that is enabled and disabled using a Wi-Fi on/off switch.

5.5.1 XS-2426X-A connections and components


Figure 5-2, “XS-2426X-A indoor ONT physical connections (back)” (p. 56) shows the physical connections for XS-2426X-A indoor ONTs.

Figure 5-2 XS-2426X-A indoor ONT physical connections (back)



37135

Figure 5-3 PON connector (bottom of the ONT)



37485

Table 5-6, “XS-2426X-A indoor ONT physical connections” (p. 58) describes the physical connections for XS-2426X-A indoor ONTs.

Table 5-6 XS-2426X-A indoor ONT physical connections

| Connection ¹ | Print Letters | Description |
|-------------------------|------------------------------|--|
| POTS port | TEL1 TEL2 | This connection is provided through an RJ-11 port. One POTS connection is supported. The POTS port supports voice services. |
| Ethernet ports | LAN1 LAN2 LAN3 10GE | This connection is provided through Ethernet RJ-45 connectors. Up to three 1000/100/10 Base-T Ethernet interfaces and one 10G/5G/2.5G/1G/100M interface are supported. The Ethernet ports can support both data and in-band video services on all four interfaces. |
| Power input | POWER | This connection is provided through the power connector. A power cable fitted with a Molex connector is used to make the connection. |
| Reset button | RESET | Pressing the Reset button for less than 10 seconds reboots the ONT; pressing the Reset button for 10 seconds resets the ONT to the factory defaults, except for the LOID and SLID. |
| WLAN button | WLAN | Wi-Fi service is compliant with IEEE 802.11 standards and is enabled and disabled using the WLAN button. |
| WPS button | WPS | The Wi-Fi Protected Setup (WPS) button enables and disables the WPS. |
| On/Off button | ON/OFF | This button turns the ONT on or off. |

Table 5-6 XS-2426X-A indoor ONT physical connections (continued)

| Connection ¹ | Print Letters | Description |
|-------------------------|---------------|--|
| USB port | USB | This connection is provided through 1 USB port on the side of the ONT. The ONT supports external USB hard drives that can be made accessible to all LAN devices. |
| Fiber optic port | | The SC/APC fiber optic port is located at bottom of the ONT and provides the connection for the fiber optic cable. |


Notes:

1. The primary path for the earth ground for these ONTs is provided by the 12V Return signal in the power connector.

5.6 XS-2426X-A LEDs

Figure 5-4, “XS-2426X-A indoor ONT LEDs” (p. 59) shows the XS-2426X-A indoor ONT LEDs.

Figure 5-4 XS-2426X-A indoor ONT LEDs



36997

Table 5-7, “XS-2426X-A indoor ONT LED descriptions” (p. 60) provides LED descriptions for XS-2426X-A indoor ONTs.

Table 5-7 XS-2426X-A indoor ONT LED descriptions

| Indicator | LED color and behavior | LED behavior description |
|-----------|------------------------|---|
| Power | Off | No power |
| | Green solid | Power on out of mains supply, no battery alarms |
| | Blinking green | Software update |
| | Blinking red | No battery, battery alarm |
| | Red solid | Light failed on startup (for example corrupt flash), or self test failed on startup, or self test failed during regular operation or when executed over OMCI |
| | Amber Solid | Device operating in battery |
| | Blinking amber [Slow] | Low battery |
| | Blinking amber [Fast] | Loopback detected |
| PON | Off | No fiber connected or no Rx power (the power in dBm of the received signal) |
| | Solid Green | ONT has been configured on the OLT and is in service (UP) |
| | Flashing Green | ONT is attempting to range with OLT |
| | solid Red | XGS-PON is down or no link connected. |
| INTERNET | Green solid | HSI WAN is connected: a) the device has an IP address assigned from IPCP, DHCP, or static; b) the session is dropped due to idle timeout but the PON link is still present, or transmit and receive traffic is ongoing. |
| | Green Flashing | PPPoE or DHCP connection is in progress. |
| | Off (Dark) | HSI WAN is not connected: a) there is no physical interface connection; b) the session has been dropped for reasons other than idle timeout. |
| TEL | Green Solid | Phone is off hook and VoIP service is build up. |
| | Flashing Green | Phone is in 'call in' or 'talking' condition |
| | Red | VoIP service is out of service |
| | Off | All phones are on hook, VoIP service is not build up |
| WPS | Green Solid | Wi-Fi protected setup link is up (negotiation and auto-configuration successful) |
| | Green Flashing | Wi-Fi protected setup link activity (negotiation and auto-configuration ongoing) |
| | Red Solid | Wi-Fi protected setup processing exception or multiple peers using WPS simultaneously |
| | Red fast flashing 4 hz | WPS session overlap detected |
| | Off | Wi-Fi protected setup link down or no link connected (negotiation has not started or has failed) |
| WLAN | Green solid | Wi-Fi enabled for at least one radio frequency (RF) |
| | Off (dark) | WLAN is down |

Table 5-7 XS-2426X-A indoor ONT LED descriptions (continued)

| Indicator | LED color and behavior | LED behavior description |
|---|------------------------|--|
| LAN/RJ-45 (Executed on the RJ-45 connectors) | Green Solid | LAN link is active |
| | Off | LAN link is OFF or has LOS (line of sight) transmission issue. |
| USB | Green solid | At least one device is connected to the USB port |
| | Green flashing | There is traffic activity on at least one device connected to the USB port |
| | Off | No device is connected to the USB port |

Notes:

1. Specific customers may have a different definition.

5.7 XS-2426X-A detailed specifications

The following table lists the physical specifications for XS-2426X-A indoor ONTs.

Table 5-8 XS-2426X-A indoor ONT physical specifications

| Description | Specification |
|---|-------------------|
| Depth | 6.88 in. (175 mm) |
| Width | 3.34 in. (85 mm) |
| Height (including antenna) | 8.89 in. (226 mm) |
| Weight [within ± 0.5 lb (0.23 kg)] (net weight of ONT) | 3.04 lbs (1.38Kg) |

[Table 5-9, “XS-2426X-A dimension data specifications” \(p. 61\)](#) lists the dimension data specifications for XS-2426X-A ONT

Table 5-9 XS-2426X-A dimension data specifications

| Dimension | Specification |
|---|--|
| Packet size supported | Less than 2000 jumbo frames |
| Number of IP addresses supported (or ranges) | In LAN network, the supported range is: <ul style="list-style-type: none"> • IPv4: 192.168.0.2 ~ 192.168.0.253 (default) • IPv6: no limitation |
| Number of supported Wi-Fi clients (per radio, per device, per mesh) | 128 per radio, 256 per device, 256 clients supported |
| Number of supported beacons /APs in a mesh | 6 (including the device) |

Table 5-9 XS-2426X-A dimension data specifications (continued)

| Dimension | Specification |
|--|---|
| Number of supported WAN interfaces | Supports 6 WAN connections: WAN - Router: <ul style="list-style-type: none"> • Connection Type: IPoE • Service: INTERNET • WAN IP Mode: DHCP |
| Number of supported VLANs | Supports 6 VLANs. Supports only untagged packets in upstream. |
| Number of priority queues, and overall buffer size | 64 priority queues. Max 20MB for WAN and 6MB for LAN |
| Number of multicast groups (DAACL entries) | 64 |

Table 5-10, “XS-2426X-A indoor ONT power consumption specifications” (p. 62) lists the power consumption specifications for XS-2426X-A indoor ONT.

Table 5-10 XS-2426X-A indoor ONT power consumption specifications

| Mnemonic | Maximum power (Not to exceed) | Condition | Minimum power | Condition |
|------------|-------------------------------|--|---------------|---|
| XS-2426X-A | 36 W | 2 POTS 5REN, 4 1000/100/10 Base-T Ethernet, WI-Fi operational, USB operational | 11.93W | Wi-Fi beacon, other interface/service not provisioned |

Table 5-11, “XS-2426X-A indoor ONT environmental specifications” (p. 62) lists the environmental specifications for XS-2426X-A indoor ONT.

Table 5-11 XS-2426X-A indoor ONT environmental specifications

| Mounting method | Temperature range and humidity | Altitude |
|------------------|---|--|
| On desk or shelf | Operating: 23°F to 113°F (-5°C to 45°C) ambient temperature 90% humidity at 40°C | Contact your Nokia technical support representative for more information |
| | Storage: -4°F to 158°F (-20°C to 70°C) | |

5.8 XS-2426X-A GEM ports and T-CONTs

Table 5-12, “XS-2426X-A indoor ONT capacity for GEM ports and T-CONTs” (p. 62) lists the maximum number of supported T-CONTs and GEM ports. See the appropriate release Customer Release Notes for the most accurate list of supported devices.

Table 5-12 XS-2426X-A indoor ONT capacity for GEM ports and T-CONTs

| ONT or MDU | Maximum | Notes |
|-----------------------|---------|-------|
| Package P ONTs | | |

Table 5-12 XS-2426X-A indoor ONT capacity for GEM ports and T-CONTs (continued)

| ONT or MDU | Maximum | Notes |
|-------------------------------------|---------|--|
| GEM ports per indoor or outdoor ONT | 64 | 256 are supported in hardware, 64 GEM ports are available for service provision, and 2 are reserved for multicast and debugging. |
| T-CONTs per indoor or outdoor ONT | 8 | 32 are supported in hardware, 8 are available for service provision, and 1 is reserved for OMCI. |

5.9 XS-2426X-A performance monitoring statistics

The following section identifies the supported performance monitoring statistics for the XS-2426X-A. A check mark indicates the statistic is supported on that ONT. An empty cell indicates the statistic is not supported. A cell without a check mark indicates the counter is not applicable to that type of ONT. The following tables are categorized by supported counters types:

- [Table 5-13, “XS-2426X-A ONT generic performance monitoring statistics” \(p. 63\)](#) provides statistics for generic ONT type counters
- [Table 5-14, “XS-2426X-A ONT ONTL2UNI performance monitoring statistics” \(p. 63\)](#) provides statistics for ONTL2UNI type counters

Table 5-13 XS-2426X-A ONT generic performance monitoring statistics

| ONT | Generic statistics | |
|------------|--------------------|--------------------|
| | CPU | Memory utilization |
| XS-2426X-A | ✓ | ✓ |

Table 5-14 XS-2426X-A ONT ONTL2UNI performance monitoring statistics


| ONT | ONTL2UNI statistics | | | | | | |
|------------|---------------------|-------|----------|-------------|--------------------|-------------|--------------------|
| | FRAMES | BYTES | MCFRAMES | DSDRPD-FRMS | DSCRCER-ROR-FRAMES | USDRPD-FRMS | USCRCER-ROR-FRAMES |
| XS-2426X-A | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ |

5.10 XS-2426X-A functional blocks

XS-2426X-A indoor ONTs are single-residence ONTs that support Wireless (Wi-Fi) service. Wi-Fi service on these ONTs is compliant with the IEEE 802.11 standard and enabled or disabled using a WLAN button. In addition to the Wi-Fi service, these ONTs transmit Ethernet packets to four RJ-45 Ethernet ports and voice traffic to two RJ-11 POTS ports. These ONTs also feature fiber optic, USB, and power connectors.

[Figure 5-5, “XS-2426X-A ONT functional block” \(p. 64\)](#) shows the functional blocks for XS-2426X-A indoor ONT.

Figure 5-5 XS-2426X-A ONT functional block



37136

5.11 XS-2426X-A standards compliance

XS-2426X-A indoor ONTs are compliant with the following standards:

- CE marking for European standards for health, safety, and environmental protection
- EN 300-328 v1.9.1 wide band data transmission standards for 2.4GHz bands
- G.984 support GPON interface (framing)
- G.984.2 (Amd1, class B+) for GPON
- G.984.3 support for activation and password functions
- G.984.3 support for AES with operator enable/disable on per port-ID level
- G.984.3 support for dynamic bandwidth reporting
- G.984.3 support for FEC in both upstream and downstream directions
- G.984.3 support for multicast using a single GEM Port-ID for all video traffic
- G.984.4 and G.983.2 support for ONT management and provisioning

- IEEE 802.1p for traffic prioritization
- IEEE 802.1q for VLANs
- IEEE 802.3 (2012)
- IEEE 802.11b/g/n/ac/ax for Wi-Fi
- ITU-T G.711, G.722, G.723, G.726, G.729
- SIP RFC 3261

5.11.1 Responsible party

The following lists the party in the US responsible for this ONT.

Table 5-15 Responsible party contact information

| | | |
|--------------------|---|------------------------------|
| Legal Company name | Nokia Solutions and Networks OY | Nokia of America Corporation |
| Offices | Offices Nokia (https://www.nokia.com/contact-us/offices/#north-america) | |
| Support | Business Support Nokia (https://www.nokia.com/networks/business-support/) | |
| Other contacts | Contact us Nokia (https://www.nokia.com/contact-us/) | |

5.11.2 Energy-related products standby and off modes compliance

Hereby, Nokia declares that the XS-2426X-A ONTs are in compliance with the essential requirements and other relevant provisions of Directive 2009/125/EC together with Commission Regulation (EC) No 1275/2008 and Commission Regulation (EC) No 801/2013.

The XS-2426X-A ONTS qualify as equipment with high network availability (HiNA) functionality. Since the main purpose of XS-2426X-A ONTs is to provide network functionality with HiNA 7 days /24 hours, the modes Off/Standby, Power Management, and Networked Standby are inappropriate.

For information about the type and number of network ports, see 5.5 “XS-2426X-A interfaces and interface capacity” (p. 56) in this chapter.

For information about power consumption, see 5.7 “XS-2426X-A detailed specifications” (p. 61) in this chapter.

5.11.3 FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

5.11.4 FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



CAUTION

Service Disruption

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

5.12 XS-2426X-A special considerations

XS-2426X-A is a package P ONT.

5.12.1 Wi-Fi service

XS-2426X-A indoor ONTs feature Wi-Fi service as well as voice and data services. Wi-Fi is a wireless networking technology that uses radio waves to provide wireless HSI and network connections. This ONT complies with the IEEE 802.11 standards, which the Wi-Fi Alliance defines as the basis for Wi-Fi technology.

Wi-Fi physical features

XS-2426X-A indoor ONTs have the following physical features that assist in providing Wi-Fi service:

- 1 WLAN button for enabling and disabling Wi-Fi service
- 1 Wi-Fi Protected Setup (WPS) push button for adding WPS-enabled wireless devices
- 4 internal antennas: 4x4 for 2.4G and 4x4 for 5G

Wi-Fi standards and certifications

The Wi-Fi service on XS-2426X-A indoor ONTs supports the following IEEE standards and Wi-Fi Alliance certifications:

- Certified for IEEE 802.11ac/b/g/n/standards
- WPA support including WPA-PSK
- Certified for WPA2-Personal
- Certified for WPA2-Enterprise
- Certified for WPA3-Personal
- Certified for WPA3-Enterprise

Wi-Fi GUI features

XS-2426X-A indoor ONTs have HTML-based Wi-Fi configuration GUIs.

5.12.2 XS-2426X-A ONT considerations and limitations

Table 5-16, “XS-2426X-A ONT considerations and limitations” (p. 66) lists the considerations and limitations for Package P XS-2426X-A ONTs.

Table 5-16 XS-2426X-A ONT considerations and limitations

| Considerations and limitations |
|---|
| Call History Data collection (ONTCALLHST) is supported, except for the following parameters: RTP packets (discarded), far-end RTCP and RTCP-XR participation, RTCP average and peak round trip delay, MOS, average jitter, number of jitter-buffer over-runs and under runs. |
| Some voice features are configurable on a per-ONT basis, including Call Waiting, Call Hold, 3-Way Calling, and Call Transfer. |
| The following voice features / GSIP parameters are configurable on a per-Client/ per-ONT basis (not per-Subscriber): <ul style="list-style-type: none"> • Enable Caller ID and Enable Caller Name ID • Digitmap and the associated Interdigit and Critical timers and Enter key parameters • Warmline timer is enabled per subscriber, but the warmline timer value is configured per ONT and must have a lower value than the Permanent time • Miscellaneous timers: Permanent, Timed-release, Reanswer, Error-tone, and CW-alert timers • Features / functions: Message waiting mode, WMWI refresh interval, DTMF volume level • Service Codes for the following features: CW, Call Hold and Warmline |
| These feature items are only supported in the mesh root device or when the ONT works as a standalone device. <ul style="list-style-type: none"> • Domain group/isolation • SoftGRE • QoS/Rate Limit per SSID and LAN port |

Table 5-16 XS-2426X-A ONT considerations and limitations (continued)

| Considerations and limitations |
|--|
| <p>The assumptions and limitations of iPerf as fallback of TR-143 on Cortina are:</p> <ul style="list-style-type: none"> • Maximum throughput that is achieved is 8Gbps upstream and 8Gbps downstream with IPoE WAN with more than three parallel threads (-P option). • Iperf3 does not support latency. So latency is filled based on the ping output. • Iperf on PPPoE is not supported. • Iperf support on NWCC, USP and MobileApp is not supported (only ACS is supported). • Iperf supports UDP protocol only. • Iperf speed test duration is not configurable. The default behavior is applied. • Port number configured at server and client should be same. By default, its 5201. Configuring port number -1 and 0 is allowed, but the request to perform test is rejected. Port parameter validation against well known ports is not to be done (like UDP port 67/68) to keep configuration and implementation simple. • Error is returned when iperf protocol is set to TCP and speed test is triggered as UDP protocol alone is supported. • Modifying speedtest and iperf configuration when speedtest is in progress is not allowed. • When speedtest configurable parameters are modified, ONT is set DiagnosticState to None and to clear the result. • Parallel execution of speed test is not supported. • Parallel execution of speedtest while ACS TR-143 test is in progress is not supported. • Parallel execution of ACS TR-143 while speedtest is in progress is not supported. • If any CPU intensive tasks are performed during speedtest, it may slow down the performance of speedtest (or) ONT may hang. So, sending any other data/control traffic during speedtest will result in low speedtest throughput. • The parameter <code>X_ALU-COM_Iperf.BlockSize</code> needs to be configured with an appropriate value according to the bandwidth profiles. BlockSize takes values below 5m,10m,50m,100m,500m,1g,2g,5g and 10g. By default, the BlockSize is 10g. |

6 Install or replace an XS-2426X-A indoor ONT

6.1 Overview

6.1.1 Purpose

This chapter provides the steps to:

- Install an XS-2426X-A indoor ONT
- Replace an XS-2426X-A indoor ONT

6.1.2 Contents

| | |
|--|----|
| 6.1 Overview | 69 |
| 6.2 Purpose | 69 |
| 6.3 General | 69 |
| 6.4 Prerequisites | 69 |
| 6.5 Recommended tools | 69 |
| 6.6 Safety information | 70 |
| 6.7 Install an XS-2426X-A indoor ONT | 71 |
| 6.8 Wall mount an XS-2426X-A indoor ONT | 74 |
| 6.9 Replace an XS-2426X-A indoor ONT | 80 |
| 6.10 Connect a CyberPower DTC36U12V3 UPS to XS-2426X-A | 84 |

6.2 Purpose

This chapter provides the steps to install a XS-2426X-A indoor ONT.

6.3 General

The steps listed in this chapter describe mounting and cabling for a XS-2426X-A indoor ONT.

6.4 Prerequisites

You need all required cable items before beginning the installation.

6.5 Recommended tools

You need the following tools for the installation:

- #2 Phillips screwdriver

- 1/4 in. (6 mm) flat blade screwdriver
- Wire strippers
- Fiber optic splicing tools
- RJ-45 cable plug crimp tool
- Voltmeter or multimeter
- Optical power meter
- Drill and drill bits
- Paper clip

6.6 Safety information

Read the following safety information before installing the unit.



DANGER

Hazard

Hazardous electrical voltages and currents can cause serious physical harm or death. Always use insulated tools and follow proper safety precautions when connecting or disconnecting power circuits.

Make sure all sources of power are turned off and have no live voltages present on feed lines or terminals. Use a voltmeter to measure for voltage before proceeding.

Always contact the local utility company before connecting the enclosure to the utilities.



WARNING

Equipment Damage

This equipment is ESD sensitive. Proper ESD protections should be used when removing the fiber access cover of the indoor ONT.



CAUTION

Service Disruption

Keep indoor ONTs out of direct sunlight. Prolonged exposure to direct sunlight can damage the unit.



Note: Observe the local and national laws and regulations that may be applicable to this installation.

This device complies with Innovation, Science and Economic Development Canada's (ISED) license-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

To satisfy ISED Canada RF exposure requirements, a separation distance of 20 cm or more should be maintained between the antenna of this device and persons during device operation. To ensure compliance, operations at closer than this distance is not recommended.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage;
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectriques ubi, même si le brouillage est susceptible d'encompromettre le fonctionnement.

Les antennes installées doivent être situées de façon à ce que la population ne puisse y être exposée à une distance de moins de 20 cm. Installer les antennes de façon à ce que le personnel ne puisse s'approcher à 20 cm ou moins de la position centrale de l'antenne.

Observe the following:

- The indoor ONT should be installed in accordance with the applicable requirements of the NEC or CEC. Local authorities and practices take precedent when there is conflict between the local standard and the NEC or CEC.
- The indoor ONT must be installed by qualified service personnel.
- Indoor ONTs must be installed with cables that are suitably rated and listed for indoor use.
- See the detailed specifications in the [Chapter 5, "XS-2426X-A unit data sheet"](#) for the temperature ranges of these ONTs.

6.7 Install an XS-2426X-A indoor ONT

Use this procedure to install a XS-2426X-A indoor ONT.

1

Place the indoor ONT unit on a flat surface, such as a desk or shelf.




Note: The XS-2426X-A cannot be stacked with another ONT or with other equipment. The ONT mounting requirements are:

- Allow a minimum 100 mm clearance above the top cover.
- Allow a minimum 50 mm clearance from the side vents.
- Do not place any heat source directly above the top cover or below the bottom cover.

2


Review the connection locations, as shown in below figure.

Figure 6-1 XS-2426X-A ONT connections



37135

Figure 6-2 ONT to wall mount connection - PON connector



37485

3



Fiber cables transmit invisible laser light. To avoid eye damage or blindness, never look directly into fibers, connectors, or adapters.



Be careful to maintain a bend radius of no less than 1.5 in. (3.8 cm) when connecting the fiber optic cable. Too small of a bend radius in the cable can result in damage to the optic fiber.

Connect the fiber optic cable with SC/APC adapter to the SC/APC connector on the bottom of the ONT.

i **Note:** Fiber cable preparation varies depending on the type and size of the inside or outside plant fiber cable being spliced to the SC/APC fiber optic pigtail cable. The maximum supported fiber optical width within the cable runway is 3mm.


-
- 4 _____
Connect the Ethernet cables to the RJ-45 ports.
 - 5 _____
Route the POTS cable directly to the RJ-11 port as per local practices.
 - 6 _____
Connect the power cable to the power connector.
 - 7 _____
Power up the ONT unit by using the power switch.
 - 8 _____
If used, enable the Wi-Fi service.
 - a. Locate the WLAN button on the ONT; see [Figure 6-1, "XS-2426X-A ONT connections" \(p. 72\)](#) for location of the WLAN button.
 - b. Press the WLAN button to change the status of the Wi-Fi service.
 - 9 _____
Verify the ONT LEDs, voltage status, and optical signal levels; see the **Nokia ONT Hardware and Cabling Installation Guide**.
 - 10 _____
Activate and test the services; see the **Nokia ONT Hardware and Cabling Installation Guide**.
 - 11 _____
If necessary, reset the ONT.
 - a. Locate the Reset button on a XS-2426X-A indoor ONT as shown in [Figure 6-6, "Bottom cover of the ONT without the screws" \(p. 78\)](#).
 - b. Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the ONT.

END OF STEPS _____

6.8 Wall mount an XS-2426X-A indoor ONT

This chapter provides the steps to mount an XS-2426X-A indoor ONT on a wall using a wall mount bracket. The XS-2426X-A indoor ONT is shipped without the wall mount bracket. The wall mount bracket must be ordered separately.

Figure 6-3 ONT in wall mount bracket



37488

6.8.1 Recommended tools

See section 6.5 “Recommended tools” (p. 69) for the recommended tools.


6.8.2 Procedure

Use this procedure to mount an XS-2426X-A ONT on a wall.

1

Mount the ONT on a wall using the wall mount bracket, as shown in [Figure 6-4, “XS-2426X-A wall mount bracket”](#) (p. 76).


Figure 6-4 XS-2426X-A wall mount bracket



37484

- a. Determine the location of the two anchor holes for the wall mount bracket. The bracket can be used as a template for marking and drilling the holes.
It is recommended to use a level to ensure that the ONT unit is installed properly.
- b. Drill two holes 35 mm (2.36 in.) depth into the wall and with the centers spaced 60 mm.
- c. Loosen the bottom screw of the XS-2426X-A ONT and remove the bottom cover.
- d. Connect the fiber optic cable with SC/APC adapter to the SC/APC connector on the bottom of XS-2426X-A ONT.


Figure 6-5 Connect the fiber optic cable to ONT



37485

- e. Put back the bottom cover of the ONT without the screws.


Figure 6-6 Bottom cover of the ONT without the screws



37486

- f. Install the ONT into the wall mount bracket by lifting the unit above the bracket and sliding it downward onto the bottom ledge of the bracket. See [Figure 6-7, “ONT to wall mount connection”](#) (p. 79).


Figure 6-7 ONT to wall mount connection



37487

- g. Connect the cables.
- h. The original screw is replaced by a longer screw to fix the ONT with the bracket together firmly when the ONT is deployed on the wall. The longer screw is attached in the mounting bracket.

Figure 6-8 Fix the screw at the bottom of bracket



37489

END OF STEPS

6.9 Replace an XS-2426X-A indoor ONT

Use this procedure to replace a XS-2426X-A indoor ONT.

1

Deactivate the ONT services at the P-OLT.

If you are using the SLID feature, this step is not required. The ONT and the services can remain in service (IS).

- a. Use the RTRV-ONT command to verify the ONT status and the associated services. Record the serial number or the SLID of the ONT displayed in the command output.

Example:

```
RTRV-ONT::ONT-1-1-1-1-1;
```

- b. If the ONT is in service, place the ONT in OOS state.


Example:

ED-ONT::ONT-1-1-1-1-1;

2

If used, disable the Wi-Fi service by pressing the WLAN button; see the following figure for the location of the WLAN button.

Figure 6-9 XS-2426X-A indoor ONT connections



37135

3

Power down the unit by using the on/off power switch.

4

Disconnect the POTS, Ethernet, and power cables from the ONT; see the image for the connector locations on the XS-2426X-A indoor ONT.

5



DANGER

Hazard

Fiber cables transmit invisible laser light. To avoid eye damage or blindness, never look directly into fibers, connectors, or adapters.

Disconnect the fiber optic cables. See [Figure 6-2, "ONT to wall mount connection - PON connector" \(p. 73\)](#).

- a. Remove the bottom cover of the ONT and unplug the fiber optic cable with SC/APC connector from the bottom of the ONT.
- b. Attach a fiber dust cover to the end of the SC/APC connector.

6

Replace the old ONT with a new ONT on a flat surface, such as a desk or shelf.

7



DANGER

Hazard

Fiber cables transmit invisible laser light. To avoid eye damage or blindness, never look directly into fibers, connectors, or adapters.



WARNING

Equipment Damage

Be careful to maintain a bend radius of no less than 1.5 in. (3.8 cm) when connecting the fiber optic cable. Too small of a bend radius in the cable can result in damage to the optic fiber.

Connect the fiber optic cable with SC/APC adapter into the SC/APC connector on the bottom of the ONT. See [Figure 6-2, "ONT to wall mount connection - PON connector" \(p. 73\)](#).



Note: Fiber cable preparation varies depending on the type and size of the inside or outside plant fiber cable being spliced to the SC/APC fiber optic pigtail cable.

8

Connect the Ethernet cables directly to the RJ-45 ports; see [Figure 6-9, "XS-2426X-A indoor ONT connections" \(p. 81\)](#) for the location of the RJ-45 ports.

9

Connect the POTS cable directly to the RJ-11 port as per local practices; see [Figure 6-9, "XS-2426X-A indoor ONT connections" \(p. 81\)](#) for the location of the RJ-11 ports.

10



Fiber optic cables transmit invisible laser light. To avoid eye damage or blindness, never look directly into fibers, connectors, or adapters.

If required, have approved service personnel who are trained to work with optic fiber clean the fiber optic connection. See the **Nokia ONT Configuration, Management, and Troubleshooting Guide** for more information about fiber optic handling, inspection, and cleaning.

11

Connect the power cable to the power connector.

12

Power up the unit by using the power switch.

13

If used, enable the Wi-Fi service by pressing the WLAN button; see [Figure 6-9, “XS-2426X-A indoor ONT connections” \(p. 81\)](#) for the location of the WLAN button.

14

If used, configure the SLID; see the **Nokia ONT Configuration, Management, and Troubleshooting Guide** for more information.



Note: A new SLID or the old SLID may be used with the replacement ONT.

If a new SLID is used, the new SLID must also be programmed at the P-OLT using TL1 or a network manager.

If the old SLID is used, no changes need to be made at the P-OLT; see the operations and maintenance documentation for the OLT for more details.

15

Verify the ONT LEDs, voltage status, and optical signal levels; see the **Nokia ONT Hardware and Cabling Installation Guide**.

16

Activate and test the services; see the **Nokia ONT Hardware and Cabling Installation Guide**.

17

If necessary, reset the ONT.

Insert the end of a straightened paper clip or other narrow object into the hole in the Reset button to reset the ONT.

END OF STEPS

6.10 Connect a CyberPower DTC36U12V3 UPS to XS-2426X-A

Use this procedure to connect to an UPS to a XS-2426X-A.

Before starting this procedure, ensure that the following items are available:

- Battery for the CyberPower UPS DTC36U12V3
- Cable to connect the UPS to the ONT
- UPS AC power cable

1


Place the indoor ONT unit and the UPS on a flat surface, such as a desk.

2

Plug the cable into the UPS connector on the ONT and the output connector on the UPS, as shown in [Figure 6-10, "ONT and UPS" \(p. 83\)](#). The battery pack is inside of the UPS.


The following figure shows an example ONT and UPS. The position of the connections may differ for each ONT model.

Figure 6-10 ONT and UPS




The connector for the 6 foot 3EM24378AA cable matches the socket for the 36W UPS Cyberpower DTC36U12V3.

Figure 6-11 Molex 7-pin DC cable



The 25 foot 3EM24378AB cable has one open end and must be terminated by the Phoenix connector provided with the UPS. Figure 6-12, “Installation of 3EM24378AB cable (7-pin) in Phoenix connector—3MV00807AA UPS 36W” (p. 85) shows the 7-pin assignments for the Cyberpower DTC36U12V3.

Figure 6-12 Installation of 3EM24378AB cable (7-pin) in Phoenix connector—3MV00807AA UPS 36W




If only 8 hours of emergency support calls is needed, go to [Step 3](#).

3

Plug the UPS power AC power cable into an AC wall outlet, as shown in [Figure 6-13](#), “Connecting the AC cord to the wall outlet” (p. 86).

The following figure shows an example ONT and UPS. The position of the connections may differ for each ONT model.


Figure 6-13 Connecting the AC cord to the wall outlet



37664

- 4 _____
Place the indoor ONT at desired location within appropriate distance of the UPS.
- 5 _____
Attach a cable retainer to the UPS power AC cord and the power cable, as shown in [Figure 6-14, "Attaching the cable retainer" \(p. 87\)](#).

Figure 6-14 Attaching the cable retainer



28472

END OF STEPS

7 Configure an XS-2426X-A indoor ONT

7.1 Overview

7.1.1 Purpose

This chapter describes the WebGUI configuration procedures.

7.1.2 Contents

| | |
|---|-----|
| 7.1 Overview | 89 |
| GUI overview | 92 |
| 7.2 General configuration | 92 |
| 7.3 HGU mode GUI configuration | 92 |
| 7.4 Logging in to the web-based GUI | 92 |
| 7.5 Viewing overview information | 93 |
| 7.6 XS-2426X-A WebGUI Menu | 95 |
| WAN Configuration | 97 |
| 7.7 Overview | 97 |
| 7.8 Configuring WAN Services | 97 |
| 7.9 Viewing WAN Statistics | 102 |
| 7.10 Configuring TR-069 | 102 |
| 7.11 Configuring TR-369 | 104 |
| 7.12 Configuring IP Routing | 105 |
| 7.13 Viewing Optical Module Status | 106 |
| 7.14 Configuring QoS | 108 |
| 7.15 Configuring IPSec Tunnel | 110 |
| 7.16 Configuring Upstream (US) Classifier | 112 |
| LAN Configuration | 119 |
| 7.17 Overview | 119 |
| 7.18 Configuring DHCP IPv4 | 119 |
| 7.19 Configuring DHCP IPv6 | 120 |
| 7.20 Configuring DNS | 122 |

| | |
|---|-----|
| 7.21 Viewing LAN Statistics | 123 |
| Wi-Fi Configuration | 126 |
| 7.22 Overview | 126 |
| 7.23 Configuring Wi-Fi Network | 126 |
| 7.24 Configuring Guest Network | 132 |
| 7.25 Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points | 133 |
| 7.26 Configuring Wireless 2.4 GHz | 137 |
| 7.27 Configuring Wireless 5 GHz | 138 |
| 7.28 Configuring Wireless Schedules | 140 |
| 7.29 Viewing Wi-Fi Statistics | 141 |
| Devices | 143 |
| 7.30 Overview | 143 |
| 7.31 Viewing Device Information | 143 |
| Voice Configuration | 145 |
| 7.32 Overview | 145 |
| 7.33 Configuring Voice Settings | 145 |
| 7.34 Viewing Voice Status | 146 |
| Security Configuration | 149 |
| 7.35 Overview | 149 |
| 7.36 Configuring the Firewall | 149 |
| 7.37 Configuring the MAC Filter | 150 |
| 7.38 Configuring the IP Filter | 152 |
| 7.39 Configuring the URL Filter | 154 |
| 7.40 Configuring Family Profiles | 155 |
| 7.41 Configuring DMZ and ALG | 166 |
| 7.42 Configuring Access Control | 167 |
| Advanced Settings | 170 |
| 7.43 Overview | 170 |
| 7.44 Configuring Port Forwarding | 170 |
| 7.45 Configuring Port Triggering | 171 |
| 7.46 Configuring DDNS | 173 |

| | | |
|------|---------------------------------------|-----|
| 7.47 | Configuring NTP | 174 |
| 7.48 | Configuring USB | 176 |
| 7.49 | Configuring UPNP and DLNA | 177 |
| | Maintenance | 179 |
| 7.50 | Overview | 179 |
| 7.51 | Configuring the Password | 179 |
| 7.52 | Backing Up the Configuration | 181 |
| 7.53 | Restoring the Configuration | 181 |
| 7.54 | Upgrading Firmware | 182 |
| 7.55 | Configuring LOID | 184 |
| 7.56 | Configuring SLID | 184 |
| 7.57 | Managing the Device | 185 |
| 7.58 | Diagnosing WAN Connections | 186 |
| 7.59 | Viewing Log Files | 190 |
| 7.60 | Generating a delta configuration file | 191 |
| | Troubleshooting | 193 |
| 7.61 | Troubleshooting | 193 |

GUI overview

This section provides an overview of the XS-2426X-A WebGUI.

7.2 General configuration

Refer to the configuration information provided with your OLT for the software configuration procedure for the device.

For HTTP/ HTTPS configuration procedures, refer to the **Nokia ONT Configuration, Management, and Troubleshooting Guide**.

7.3 HGU mode GUI configuration

Use the procedures below to use the web-based GUI for the XS-2426X-A in HGU mode. This mode is preset at delivery.

A home gateway unit (HGU) is a home networking device, used as a gateway to connect devices in the home through fiber to the Internet. An HGU provides a variety of features for the home network including routing and firewall capability. By using the HGU, users can connect all smart equipment in their home, including personal computers, set-top boxes, mobile phones, and other consumer electronics devices, to the Internet.

7.4 Logging in to the web-based GUI

1

Open a web browser and enter the IP address of the ONT in the address bar.

The *Login* page displays.

Figure 7-1 Login page



The default gateway IP address must be same as the one printed on the device label. You can connect to this IP address using your web browser after connecting your PC to one of Ethernet ports of the ONT. The static IP address of your PC must be in the same default gateway subnet as the ONT.

2



CAUTION

Service Disruption

If you forget the current username and password, press the **Reset** button for 10 seconds to reset the values to the default username and password provided at startup.

Pressing the **Reset** button for less than 10 seconds reboots the device.

Pressing the **Reset** button for 10 seconds resets the device to the factory defaults, except for the LOID and SLID.

Enter your username and password in the *Login* page, as shown in [Figure 7-1, "Login page" \(p. 92\)](#).

The superadmin account is meant for the operator and is unique per device. Contact your Nokia representative to obtain the superadmin password for device.

The default end-user account name and the default password for this account are printed on the device label.

3

Click **Sign in**. The *Overview* page displays.



Note: To help protect the security of your Internet connection, the application displays a pop-up reminder to change both the Wi-Fi password and the ONT password.


To increase password security, use a minimum of 10 characters, consisting of a mix of numbers and upper and lower case letters.

END OF STEPS

7.5 Viewing overview information

1

Click **Overview** from the left pane. The Overview page displays the following cards.



END OF STEPS

7.5.1 Wi-Fi Points

Displays information about the status of the Wi-Fi points and connection to the internet. The status of the internet connection is defined by the presence of an IP address on the internet service.

7.5.2 Service Overview

Displays the active status of the triple-play services.

Internet

The internet service represents the presence of a WAN IP address for the routed network that has the internet attached to it. The WAN IP icon shows the WAN IP address (IPv4 and/or IPv6).

WiFi

Shows the status of the WiFi service. Its online or offline state is indicated by the presence of a WAN IP address for the service. The WAN IP icon shows the WAN IP address (IPv4 and/or IPv6).

Voice

The voice service state is defined by the registration status of the voice service (online/offline).

7.5.3 Wi-Fi Networks

Displays a network card per activated single or dual band Wi-Fi network containing the bands supported, the name of the network and the type of network (bridge or routed).

7.5.4 Connected Clients

Displays the total number of online and offline clients connected to this device (single device or mesh system).

7.6 XS-2426X-A WebGUI Menu

The following table lists the main menu and sub-menu options in the XS-2426X-A WebGUI:

Table 7-1 XS-2426X-A WebGUI Menu

| Main Menu | Sub-menu | Procedure Reference |
|-----------|-----------------------|--|
| Overview | - | 7.5 "Viewing overview information" (p. 93) |
| WAN | WAN services | 7.8 "Configuring WAN Services" (p. 97) |
| WAN | WAN statistics | 7.9 "Viewing WAN Statistics" (p. 102) |
| WAN | TR-069 | 7.10 "Configuring TR-069" (p. 102) |
| WAN | TR-369 | 7.11 "Configuring TR-369" (p. 104) |
| WAN | IP routing | 7.12 "Configuring IP Routing" (p. 105) |
| WAN | Optical module status | 7.13 "Viewing Optical Module Status" (p. 106) |
| WAN | QoS config | 7.14 "Configuring QoS" (p. 108) |
| WAN | IPSec tunnel | 7.15 "Configuring IPSec Tunnel" (p. 110) |
| WAN | US classifier | 7.16 "Configuring Upstream (US) Classifier" (p. 112) |
| LAN | DHCP IPv4 | 7.18 "Configuring DHCP IPv4" (p. 119) |
| LAN | DHCP IPv6 | 7.19 "Configuring DHCP IPv6" (p. 120) |
| LAN | DNS | 7.20 "Configuring DNS" (p. 122) |
| LAN | LAN statistics | 7.21 "Viewing LAN Statistics" (p. 123) |
| Wi-Fi | Wi-Fi networks | 7.23 "Configuring Wi-Fi Network" (p. 126) |
| Wi-Fi | Network map | 7.25 "Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points" (p. 133) |
| Wi-Fi | Advanced settings | 7.26 "Configuring Wireless 2.4 GHz" (p. 137) 7.27 "Configuring Wireless 5 GHz" (p. 138) |
| Wi-Fi | Wireless schedule | 7.28 "Configuring Wireless Schedules" (p. 140) |
| Wi-Fi | Wi-Fi statistics | 7.29 "Viewing Wi-Fi Statistics" (p. 141) |
| Devices | - | 7.31 "Viewing Device Information" (p. 143) |
| Voice | Voice setting | 7.33 "Configuring Voice Settings" (p. 145) |
| Voice | Voice status | 7.34 "Viewing Voice Status" (p. 146) |
| Security | Firewall | 7.36 "Configuring the Firewall" (p. 149) |
| Security | MAC filter | 7.37 "Configuring the MAC Filter" (p. 150) |

Table 7-1 XS-2426X-A WebGUI Menu (continued)

| Main Menu | Sub-menu | Procedure Reference |
|-------------------|--------------------|---|
| Security | IP filter | 7.38 "Configuring the IP Filter" (p. 152) |
| Security | URL filter | 7.39 "Configuring the URL Filter" (p. 154) |
| Security | Family profiles | 7.40 "Configuring Family Profiles" (p. 155) |
| Security | DMZ and ALG | 7.41 "Configuring DMZ and ALG" (p. 166) |
| Security | Access control | 7.42 "Configuring Access Control" (p. 167) |
| Advanced settings | Port forwarding | 7.44 "Configuring Port Forwarding" (p. 170) |
| Advanced settings | Port triggering | 7.45 "Configuring Port Triggering" (p. 171) |
| Advanced settings | DDNS | 7.46 "Configuring DDNS" (p. 173) |
| Advanced settings | NTP | 7.47 "Configuring NTP" (p. 174) |
| Advanced settings | USB | 7.48 "Configuring USB" (p. 176) |
| Advanced settings | UPNP and DLNA | 7.49 "Configuring UPNP and DLNA" (p. 177) |
| Maintenance | Change password | 7.51 "Configuring the Password" (p. 179) |
| Maintenance | Backup and restore | 7.52 "Backing Up the Configuration" (p. 181) 7.53 "Restoring the Configuration" (p. 181) |
| Maintenance | Firmware upgrade | 7.54 "Upgrading Firmware" (p. 182) |
| Maintenance | LOID config | 7.55 "Configuring LOID" (p. 184) |
| Maintenance | SLID configuration | 7.56 "Configuring SLID" (p. 184) |
| Maintenance | Device management | 7.57 "Managing the Device" (p. 185) |
| Maintenance | Diagnostics | 7.58 "Diagnosing WAN Connections" (p. 186) |
| Maintenance | Log | 7.59 "Viewing Log Files" (p. 190) |
| Troubleshooting | - | 7.61 "Troubleshooting" (p. 193) |

WAN Configuration

7.7 Overview

This section describes the WAN configuration procedures that can be performed from the following sub-menu options under the **WAN** menu:

| Sub-menu | Procedure |
|------------------------------|--|
| WAN services | 7.8 "Configuring WAN Services" (p. 97) |
| WAN statistics | 7.9 "Viewing WAN Statistics" (p. 102) |
| TR-069 | 7.10 "Configuring TR-069" (p. 102) |
| TR-369 | 7.11 "Configuring TR-369" (p. 104) |
| IP routing | 7.12 "Configuring IP Routing" (p. 105) |
| Optical module status | 7.13 "Viewing Optical Module Status" (p. 106) |
| Qos config | 7.14 "Configuring QoS" (p. 108) |
| IPSec tunnel | 7.15 "Configuring IPSec Tunnel" (p. 110) |
| US classifier | 7.16 "Configuring Upstream (US) Classifier" (p. 112) |

7.8 Configuring WAN Services

1

Click **WAN**→**WAN services** in the left pane. The *WAN services* page displays the existing WAN connections in the *Overview* table. You can click on a connection to modify the connection configuration.

Figure 7-2 Overview table in WAN services page

The screenshot shows the WAN / WAN services page. At the top right, there is a refresh icon and an "Add +" button. Below this is an "Overview" section containing a table with the following data:

| Service Name | Connection mode | Enable/Disable status | Service | IP address |
|--------------------------------|-----------------|-----------------------|------------------------|-------------|
| 1_TR069_INTERNET_OTHER_R_VID_0 | Route | Enable | TR-069, Internet, IPTV | 192.85.1.20 |

2

Click **Add +** to create a WAN connection. The *Create New Connection* page displays.

Figure 7-3 Create New Connection page

← WAN / WAN services / **1_TR069_INTERNET_OTHER_R_VID_0** Refresh Delete Save

WAN connection list: 1_TR069_INTERNET_OTHER_R_VID_0

Enabled:

Connection type: IPoE

IP mode: IPv4

NAT:

TR-069:

Internet:

IPTV:

Enable VLAN:

VLAN ID: 0

VLAN PRI: 0

WAN IP mode: DHCP

Manual DNS:

DHCP option 50 persistent:

Enable DHCP option 60:

Enable DHCP option 61:

Enable DHCP option 77:

Enable DHCP option 90:

3

Configure the following parameters:

Table 7-2 WAN services parameters

| Field | Description |
|---------------------|---|
| WAN connection list | Select a WAN connection from the list. |
| Enabled | Select the toggle button to enable the WAN connection. |
| Connection type | Select a connection type from the list: <ul style="list-style-type: none"> • IPoE • PPPoE |
| Connection mode | Select the connection mode of the WAN connection from the list: <ul style="list-style-type: none"> • Route Mode • Bridge Mode |
| IP mode | This field is applicable only if the connection mode is Route Mode . Select an IP mode from the list: <ul style="list-style-type: none"> • IPv4 • IPv4 & IPv6 • IPv6 When the IP mode IPv4 & IPv6 or IPv6 is selected, you need to configure Address method , Enabled prefix delegation and Prefix type . |
| NAT | Select the toggle button to enable NAT. This option is applicable only if the connection mode is Route Mode . |
| TR-069 | Select the toggle button to enable TR-069. This option is applicable only if the connection mode is Route Mode . |
| VOIP | Select the toggle button to enable VoIP. This option is applicable only if the connection type is IPoE and the connection mode is Route Mode . |
| Internet | Select the toggle button to enable Internet. This option is applicable only if the connection mode is Route Mode . |
| IPTV | Select the toggle button to enable IPTV. |
| Enable VLAN | Select the toggle button to enable VLAN. This option is applicable only if the connection mode is Route Mode . |
| VLAN mode | Select a VLAN mode from the list: <ul style="list-style-type: none"> • VLAN binding • Tunnel • Transparent This option is applicable only if the connection mode is Bridge Mode . |

Table 7-2 WAN services parameters (continued)

| Field | Description |
|--------------------|---|
| VLAN ID | Enter the VLAN ID. Allowed values: 2 to 4094 In the bridge mode, this option is applicable only if the VLAN mode is Tunnel or VLAN binding . |
| VLAN PRI | Enter the VLAN PRI. VLAN priority allows to assign a priority to outbound packets containing the specified VLAN ID. Allowed values: 0 to 7 In the bridge mode, this option is applicable only if the VLAN mode is VLAN binding . |
| LAN port binding | Select the toggle button next to the LAN to enable it. Select the toggle button next to the PVID to enable it. This option is not applicable if the VLAN mode is Tunnel or Transparent . |
| SSID port binding | Select the toggle button next to the SSID to enable it. Select the toggle button next to the PVID to enable it. This option is not applicable if the VLAN mode is Tunnel or Transparent . |
| WAN IP mode | Select an IP mode from the list: <ul style="list-style-type: none"> • DHCP • PPPoE This option is visible only if you select PPPoE as the connection type. • Static |
| Manual DNS | If the selected IP mode is IPv4 and the WAN IP mode is DHCP , enter the Domain Name Server (DNS) to be configured manually. |
| IPv4 Address | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the static IPv4 address. |
| Netmask | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the netmask. |
| Gateway | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the gateway IP address. |
| Pri DNS | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the primary Domain Name Server (DNS). |
| Sec DNS | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the secondary Domain Name Server (DNS). |
| Ter DNS | If the selected IP mode is IPv4 or IPv4&IPv6 and the WAN IP mode is Static , enter the tertiary Domain Name Server (DNS). |
| Connection trigger | Select the connection trigger type from the list. The default option is Always On . |
| Username | Enter the username to log in to the configuration server. This option is applicable only if the WAN IP mode is PPPoE . |
| Password | Enter the password to log in to the configuration server. Allowed values are limited to numbers, letters and special characters ! # + , - . / : = @ _ . This option is applicable only if the WAN IP mode is PPPoE . |

Table 7-2 WAN services parameters (continued)

| Field | Description |
|---------------------------|---|
| Keep alive time | The PPPoE connection type triggers one heartbeat each, at the configured time interval to keep the session online. Allowed values: 5 to 60 seconds This option is applicable only if the WAN IP mode is PPPoE . |
| Keep alive retry | Configure the number of retries to check the Keep Alive status of the PPPoE session after time-out. Allowed values: 1 to 10. This option is applicable only if the WAN IP mode is PPPoE . |
| Echo value | Indicates the number of times the device sends messages to the server to check if the IP address is available or not. This option is applicable only if the WAN IP mode is PPPoE . |
| Address method | If the selected IP mode is IPv6 or IPv4&IPv6 , select the address method from the list: <ul style="list-style-type: none"> • AutoConfigured • DHCPv6 • DHCPv6_PD • DHCPv6_NA • Static |
| Enable prefix delegation | If the selected address method is AutoConfigured , select the toggle button to enable inclusion of the Identity Association (IA) for Prefix Delegation option in Solicit messages. |
| Prefix type | Displays mechanism through which the prefix was assigned or most recently updated. |
| IP Address (v6) | If the selected address method is Static , enter the IPv6 address. |
| Gateway (v6) | If the selected address method is Static , enter the gateway IPv6 address. |
| IPv6 address prefix | If the selected address method is Static , enter the IPv6 address prefix. |
| Pri DNS (v6) | If the selected address method is Static , enter the primary DNS IP address. |
| Sec DNS (v6) | If the selected address method is Static , enter the secondary DNS IP address. |
| DHCP option 50 persistent | Select the toggle button to enable DHCP Option 50 persistent. |
| Enable DHCP option 60 | Select the toggle button to enable DHCP Option 60 (vendor class identifier). |
| Enable DHCP option 61 | Select the toggle button to enable DHCP Option 61 (client identifier). |
| Enable DHCP option 77 | Select the toggle button to enable DHCP Option 77 (user class information). |
| Enable DHCP option 90 | Select the toggle button to enable DHCP Option 90 (authentication information). |

4

Click **Save**. The connection is listed in the *Overview* table of the *WAN services* page.


END OF STEPS

7.9 Viewing WAN Statistics

1

Click **WAN**→**WAN statistics** in the left pane. The *WAN Statistics* page displays the following information for WAN ports.

Figure 7-4 WAN Statistics page



WAN / **WAN statistics**

Overview

| Service Name | Connection mode | Enable/Disable status | Service | IP address |
|--------------------------------|-----------------|-----------------------|------------------------|-------------|
| 1_TR069_INTERNET_OTHER_R_VID_0 | Route | Enable | TR-069, Internet, IPTV | 192.85.1.20 |

END OF STEPS

7.10 Configuring TR-069

1

Click **WAN**→**TR-069** in the left pane. The *TR-069* page displays.

Figure 7-5 TR-069 page

2

Configure the following parameters:

Table 7-3 TR-069 parameters

| Field | Description |
|-----------------------------|--|
| Enable | Select the toggle button to enable CWMP function. |
| Periodic inform enable | Select the toggle button to enable periodic inform updates. |
| Periodic inform interval(s) | Enter the time between periodic inform updates, in seconds. |
| URL | Enter the URL of the auto-configuration server. |
| Username | Enter the username to log in to the ONT. |
| Password | Enter the password to log in to the ONT. |
| Connect request username | Enter the username to log in to the auto-configuration server. |
| Connect request password | Enter the password to log in to the auto-configuration server. |

3

Click **Save**.

END OF STEPS

7.11 Configuring TR-369

i **Note:** The TR-369 configuration option is available only if the TR-181 data model is active.

1

Click **WAN**→**TR-369** in the left pane. The *TR-369* page displays.

Figure 7-6 TR-369 page

2

Configure the following parameters:

Table 7-4 TR-369 parameters

| Field | Description |
|------------------------|--|
| Enable TR369/USP | Select the toggle button to enable TR-369/USP and click Save . |
| Controller endpoint ID | Enter the controller endpoint ID. |
| MTP Protocol | Select the MTP protocol from the list (currently only MQTT is supported). |

Table 7-4 TR-369 parameters (continued)

| Field | Description |
|----------------|---|
| Transport | Select the transport option from the list: <ul style="list-style-type: none"> • TCP/IP • TLS |
| Broker address | Enter the broker IP address. |
| Broker port | Enter the broker port number. |
| Username | Enter the username to authenticate with MQTT broker. |
| Password | Enter the password to authenticate with MQTT broker. |

3

Click **Save**.

END OF STEPS

7.12 Configuring IP Routing

1

Click **WAN**→**IP routing** in the left pane. The *IP routing* page displays.

Figure 7-7 IP routing page

2

Configure the following parameters:

Table 7-5 IP routing parameters

| Field | Description |
|------------------------|--|
| Enable IP routing | Select the toggle button to enable IP routing. |
| Destination IP address | Enter the destination IP address. |
| Destination netmask | Enter the destination netmask. |
| Gateway | Enter the gateway IP address. |
| IPv4 interface | Select an IPv4 interface from the list. |
| Forwarding policy | Select a forwarding policy from the list: |

3

Click **Add**. The IP route is added to the *IP routing table*.

END OF STEPS

7.13 Viewing Optical Module Status

1

Click **WAN**→**Optical module status** in the left pane. The *Optical module status* page displays the following information.

Figure 7-8 Optical module status page

WAN / **Optical module status** 5

| | |
|--|--------------|
| Serial Number | ALCLF995738E |
| Laser bias current <small>ONT ANI-ONT-Side Optical Measurements</small> | 42964 uA |
| Optics module voltage <small>ONT ANI-ONT-Side Optical Measurements</small> | 3295000 uV |
| Optics module temperature <small>ONT ANI-ONT-Side Optical Measurements</small> | 54.90 °C |
| Rx optics signal level at 1577 nm <small>ONT ANI-ONT-Side Optical Measurements</small> | -20.57 dBm |
| Tx optics signal level at 1270 nm <small>ONT ANI-ONT-Side Optical Measurements</small> | 5.97 dBm |
| Lower <small>ONT ANI-ONT-Side Optical threshold</small> | -29 dBm |
| Upper <small>ONT ANI-ONT-Side Optical threshold</small> | -9 dBm |

Table 7-6 Optical module status parameters

| Field | Description |
|---|---|
| Serial Number | Indicates the serial number |
| Laser bias current (ONT ANI-ONT-Side Optical Measurements) | Laser bias current, measured in uA |
| Optics module voltage (ONT ANI-ONT-Side Optical Measurements) | Optics module voltage, measured in V |
| Optics module temperature (ONT ANI-ONT-Side Optical Measurements) | Optics module temperature, measured in C |
| Rx optics signal level at 1577 nm (ONT ANI-ONT-Side Optical Measurements) | Received optics signal level at 1577 nm, measured in dBm |
| Tx optics signal level at 1270 nm (ONT ANI-ONT-Side Optical Measurements) | Transmitted optics signal level at 1270 nm, measured in dBm |
| Lower (ONT ANI-ONT-Side Optical Threshold) | Lower optical threshold, measured in dBm |
| Upper (ONT ANI-ONT-Side Optical Threshold) | Upper optical threshold, measured in dBm |

END OF STEPS

7.14 Configuring QoS

1

Click **WAN**→**QoS config** in the left pane. The *QoS config* page displays.

Figure 7-9 QoS config page (L2 Criteria)

The screenshot shows the 'WAN / QoS config' page. At the top right, there is a refresh icon and an 'Add' button. The page is divided into three main sections:

- Type:** A dropdown menu currently set to 'L2 Criteria'.
- Classification criteria:** This section contains:
 - Source Mac:** An empty text input field.
 - Exclude:** A toggle switch currently turned off.
 - Interface:** A dropdown menu currently set to 'Select option'.
- Classification row:** This section contains:
 - DSCP remark:** A greyed-out text input field.
 - Range 0-63:** A greyed-out text input field.
 - 802.1p Remark:** An empty text input field.
 - Range 0-7:** An empty text input field.
 - Forwarding policy:** An empty text input field.
 - Range 1-7:** An empty text input field.

Figure 7-10 QoS config page (L3 Criteria)

The screenshot shows the 'WAN / QoS config' page with the following fields and values:

- Type: L3 Criteria
- Classification criteria:
 - Protocol: None
 - Application: Customer Setting
 - Source IP: (empty)
 - Source IP Mask: (empty)
 - Dest IP: (empty)
 - Dest IP mask: (empty)
 - Source Port: (empty)
 - Source Port Max: (empty)
 - Destination Port: (empty)
 - Dest Port Max: (empty)
 - 802.1p: (empty)
 - Interface: Select option

2

Configure the following parameters:

Table 7-7 QoS config parameters

| Field | Description |
|-------------------------------------|---|
| Type | Select a QoS service layer type from the list: <ul style="list-style-type: none"> • L2 Criteria • L3 Criteria |
| Classification criteria (L2) | |
| Source MAC | Enter the source MAC address. |
| Exclude | Select the toggle button to exclude the source MAC address. |
| Interface | Select an interface from the list. |
| Classification criteria (L3) | |
| Protocol | Select a protocol from the list. |
| Exclude | Select the toggle button to exclude the protocol. |
| Application | Select an application from the list or select Custom Settings and enter an application name. |

Table 7-7 QoS config parameters (continued)

| Field | Description |
|---------------------------|---|
| Source IP | Enter the source IP address. |
| Exclude | Select the toggle button to exclude the source IP address. |
| Source IP mask | Enter the source IP address netmask. |
| Destination IP | Enter the destination IP address. |
| Exclude | Select the toggle button to exclude the destination IP address. |
| Destination IP mask | Enter the destination IP address netmask. |
| Source port | Enter the source port number. |
| Exclude | Select the toggle button to exclude the source port. |
| Source port max | Enter the values for the source port max (highest port number) |
| Destination port | Enter the destination port number. |
| Exclude | Select the toggle button to exclude the destination port. |
| Destination port max | Enter the values for the destination port max (highest port number) |
| Classification row | |
| DSCP remark | Enter the value for the DSCP remark (applicable only for L3 criteria). Allowed values: 0 to 63 |
| 802.1p Remark | Enter the value for the 802.1p remark. Allowed values: 0 to 7 |
| Forwarding policy | Enter the number for the forwarding policy. Allowed values: 1 to 7 |

3 _____

Click **Add** to add a QoS policy.

END OF STEPS _____

7.15 Configuring IPSec Tunnel

1 _____

Click **WAN**→**IPSec tunnel** in the left pane. The *IPSec tunnel* page displays.

Figure 7-11 IPsec tunnel page

WAN / IPsec tunnel ↻

IPsec enable

Tunnel name

WAN interface

Remote endpoint
undefined

PreShared key

Peer subnet

Peer subnet mask

Local subnet

Local subnet mask

LAN interface

| | |
|-------|--------------------------|
| LAN 1 | <input type="checkbox"/> |
| LAN 2 | <input type="checkbox"/> |
| LAN 3 | <input type="checkbox"/> |
| LAN 4 | <input type="checkbox"/> |

SSID

| | |
|--------|--------------------------|
| SSID 2 | <input type="checkbox"/> |
| SSID 3 | <input type="checkbox"/> |
| SSID 4 | <input type="checkbox"/> |
| SSID 6 | <input type="checkbox"/> |
| SSID 7 | <input type="checkbox"/> |
| SSID 8 | <input type="checkbox"/> |

Allowed MAC addresses

Connection status

2

Configure the following parameters:

Table 7-8 IPsec tunnel parameters

| Field | Description |
|-----------------------|--|
| IPSec enable | Select the toggle button to enable IPsec tunnel. |
| Tunnel name | Select an existing tunnel from the list. |
| WAN interface | Select a WAN interface from the list. |
| Remote endpoint | Enter the IP address or FQDN of the remote endpoint. |
| PreShared key | Enter the preshared key. |
| Peer subnet | Enter the peer subnet. |
| Peer subnet mask | Enter the peer subnet mask. |
| Local subnet | Enter the local subnet. |
| Local subnet mask | Enter the local subnet mask. |
| LAN interface | Select the corresponding toggle button to enable the LAN1, LAN2, LAN3 or LAN4 interface. |
| SSID | Select the corresponding toggle button to enable SSID2, SSID3, SSID4, SSID6, SSID7 or SSID8. |
| Allowed MAC addresses | Enter the allowed MAC addresses. |
| Connection status | Displays the status of the connection: <ul style="list-style-type: none"> • Disconnected • Connected |

3

Click **Save**.

END OF STEPS

7.16 Configuring Upstream (US) Classifier

The US Classifier feature is used to create policies, classifiers, and classifier rules for upstream traffic handling. This feature is available to admin users (super users) only.

A policy defines an action to be performed on a set of LAN or WAN packets. A policy can be created at any time and then subsequently assigned to one or more classifiers.

A classifier is used to select key fields for which the classifier rules will be written. A classifier can be created at any time and then subsequently assigned to one or more classifier rules.

A classifier rule is used to assign actions to a group of packets based on a set of parameters. A classification rule must be created against a pre-defined classifier.

Up to 16 policies can be created, with up to 8 classifiers and 32 classifier rules.

1

Click **WAN**→**US Classifier** in the left pane and select the **Policy** tab.
All classifier policies are displayed in the policy table in the page.

Figure 7-12 US Classifier - Policy page

WAN / US classifier

Policy Classifier Classifier Rules

Tunnel Type Select option

Tunnel Interface Select option

VLAN id 0-4093

VLAN Tag hex

VLAN Priority 0-7

IP TOS/DSCP 0-63 0

Drop

Save Reset

| Name | Tunnel Type | Tunnel Interface | VLAN id | VLAN Tag | VLAN Priority | IP TOS/DSCP | Drop | No. of Rules | Delete |
|------|-------------|------------------|---------|----------|---------------|-------------|--------------------------|--------------|--------|
| 1 | | | | | | | <input type="checkbox"/> | | Delete |

2

Configure the following parameters:

Table 7-9 US Classifier - Policy parameters

| Field | Description |
|------------------|--|
| Tunnel Type | The tunnel type is set to GRE and cannot be modified. |
| Tunnel Interface | Select a tunnel interface from the list: <ul style="list-style-type: none"> • No Tunnel • GRE Tunnel • LAN traffic |
| VLAN ID | Enter a VLAN ID. Allowed values: 0 to 4093 |
| VLAN Tag | This field is not configurable. The VLAN tag is set to 8100 (hexadecimal). Determines the VLAN tag used inside the GRE tunnel. |
| VLAN Priority | Enter a VLAN priority level. A lower number indicates a higher priority. Allowed values: 0 to 7 |
| IP TOS/DSCP | This field is not configurable. All tunnel packets are generated with a default DSCP value (usually 0). Allowed values: 0 to 63 |
| Drop | Select the toggle button to enable dropping of the packets. |

3

Click **Save**. The policy is added to the policies table.

To delete a policy, click **Delete** next to the policy entry in the table. A policy can only be deleted if it is not associated with any classifier rules.

4

Select the **Classifier** tab.

All classifiers are displayed in the classifier table in the page.

Figure 7-13 US Classifier - Classifier page

5 _____
 Configure the following parameters:

Table 7-10 US Classifier - Classifier parameters

| Field | Description |
|------------|--|
| Interface | Select an interface from the list; for example, None, LAN, 2.4G SSID, or 5G SSID. The option None indicates that all interfaces are selected. |
| Source MAC | Select the toggle button to enter a source MAC address. |
| Source IP | Select the toggle button to enter a source IP address. |

Table 7-10 US Classifier - Classifier parameters (continued)

| Field | Description |
|------------------|--|
| Source Port | Select the toggle button to enter a source port. |
| Protocol | Select the toggle button to enter a protocol. |
| Destination MAC | Select the toggle button to enter a destination MAC address. |
| Destination IP | Select the toggle button to enter a destination IP address. |
| Destination Port | Select the toggle button to enter a destination port. |
| Priority | Select a priority level from 1 to 8. The lower the number, the higher the priority. Only one classifier can be created with the same priority. |

6

Click **Save**. The US classifier is listed in the classifiers table.

To delete a classifier, click **Delete** next to the classifier entry in the table. A classifier can only be deleted if it is not associated with any classifier rules.

7

Select the **Classifier Rules** tab.

All classifier rules are displayed in the classifier rules table in the page.

Figure 7-14 US Classifier - Classifier Rules page

WAN / **US classifier** ↻

Policy Classifier Classifier Rules

Policy

Classifier

Interface

Source Mac

Destination MAC

Source IP

Destination IP

Source Port

Destination Port

IP protocol type

0-254

| Name | Interface | Source MAC | Source IP | Source Port | Destination MAC | Destination IP | Destination Port | IP Protocol | Policy | Classifier | Delete |
|------|-----------|------------|-----------|-------------|-----------------|----------------|------------------|-------------|--------|------------|---------------------------------------|
| 1 | | | | | | | | | | | <input type="button" value="Delete"/> |

8

Configure the following parameters:

Table 7-11 US Classifier - Classifier Rules parameters

| Field | Description |
|------------------|--|
| Policy | Select a policy from the list. |
| Classifier | Select a classifier from the list. |
| Interface | Select an interface from the list; for example, None, LAN, 2.4G SSID, 5G SSID. |
| Source MAC | Enter a source MAC address. |
| Destination MAC | Enter a destination MAC address. |
| Source IP | Enter a source IP address. |
| Destination IP | Enter a destination IP address. |
| Source Port | Enter a source port. |
| Destination Port | Enter a destination port. |
| IP Protocol Type | Enter a value between 0 and 254. |

9

Click **Save**. The rule is added to the classifier rules table.

To delete a classifier rule, click **Delete** next to the classifier rule entry in the table.

END OF STEPS

LAN Configuration

7.17 Overview

This section describes the LAN configuration procedures that can be performed from the following sub-menu options under the **LAN** menu:

| Sub-menu | Procedure |
|-----------------------|--|
| DHCP IPv4 | 7.18 "Configuring DHCP IPv4" (p. 119) |
| DHCP IPv6 | 7.19 "Configuring DHCP IPv6" (p. 120) |
| DNS | 7.20 "Configuring DNS" (p. 122) |
| LAN statistics | 7.21 "Viewing LAN Statistics" (p. 123) |

7.18 Configuring DHCP IPv4

1

Click **LAN**→**DHCP IPv4** in the left pane. The *DHCP IPv4* page displays.

Figure 7-15 DHCP IPv4 page

2

Configure the following LAN parameters:

Table 7-12 DHCP IPv4 parameters

| Field | Description |
|-----------------------|--|
| IPv4 address | Enter the IPv4 address of the ONT. |
| Subnet mask | Enter the subnet mask of the ONT. |
| DHCP enable | Select the toggle button to enable DHCP. If this toggle button is not enabled, the DHCP functionality cannot be used. you need not configure DHCP start IP address, DHCP end IP address and DHCP lease time if this toggle button is not enabled. |
| DHCP start IP address | Enter the starting range of the DHCP IP address. |
| DHCP end IP address | Enter the ending range of the DHCP IP address. |
| DHCP lease time | Enter the DHCP lease time (in minutes). Allowed values: 5 to 129600 minutes or 0 for 1 day |
| Primary DNS | Enter the primary DNS IP address. |
| Secondary DNS | Enter the secondary DNS IP address. |

3

Click **Save**.

4

Configure the Static DHCP parameters.

Table 7-13 Static DHCP parameters

| Field | Description |
|--------------|---|
| MAC address | Enter the hexadecimal MAC address to associate with the LAN. |
| IPv4 address | Enter the IPv4 address to associate with the bound MAC address. |

5

Click **Add**. Repeat steps 4 and 5 for all MAC addresses to be bound.

END OF STEPS

7.19 Configuring DHCP IPv6

1

Click **LAN**→**DHCP IPv6** in the left pane. The *DHCP IPv6* page displays.

Figure 7-16 DHCP IPv6 page

2

Configure the following parameters:

Table 7-14 DHCP IPv6 parameters

| Field | Description |
|------------------------------------|--|
| IPv6 LAN Host Configuration | |
| DNS Server | Select a DNS server from the list. |
| Prefix Config | Select a prefix configuration option from the list: <ul style="list-style-type: none"> • WAN Connection (prefix is obtained from the WAN), or • Static (enables you to enter the prefix) |
| Interface | This field displays if you select the WAN Connection option from the Prefix Config list. Select a WAN connection interface from the list. |
| DHCPv6 Server Pool | |
| DHCP Start IP Address | Enter the starting range of the DHCP IP address. |
| DHCP End IP Address | Enter the ending range of the DHCP IP address. |

Table 7-14 DHCP IPv6 parameters (continued)

| Field | Description |
|--|--|
| Obtain address information through DHCP IPv6 | Select the toggle button to enable address information retrieval through DHCP. |
| Obtain other information through DHCP IPv6 | Select the toggle button to enable retrieval of other information through DHCP. |
| Maximum interval for periodic RA messages | Enter the maximum interval (in seconds) for periodic Router Advertisement messages. Allowed values: 4 to 1800 seconds |
| Minimum interval for periodic RA messages | Enter the minimum interval (in seconds) for periodic Router Advertisement messages. Allowed values: 4 to 1800 seconds |

3

Click **Save**.


END OF STEPS

7.20 Configuring DNS

1

Click **LAN**→**DNS** in the left pane. The *DNS* page displays.

Figure 7-17 DNS page



2

Configure the following parameters:

- a. Select the **DNS proxy** toggle button to enable the DNS proxy and click **Save**.
- b. Configure the following:
 1. Enter the domain name in the Domain Name field
 2. Enter the domain IP address in the IPv4 Address field.
 3. Click **Add**.
- c. Configure the following:
 1. Enter the origin domain name in the Origin Domain field
 2. Enter the new domain name in the New Domain field.
 3. Click **Add** to associate an origin domain with a new domain.

The *DNS* table displays the configured domain names and the associated IPv4 address.

END OF STEPS

7.21 Viewing LAN Statistics

1

Click **LAN**→**LAN statistics** in the left pane. The *LAN statistics* page displays the following information.

Figure 7-18 LAN statistics page

LAN / LAN statistics ↻

SSID name NOKIA-B1D1 ▾

LAN wireless info

| | |
|----------------------------|----------|
| Wireless status | On |
| Wireless channel | 1 |
| Wireless encryption status | WPA2-PSK |
| Wireless Rx packets | 0 |
| Wireless Tx packets | 15 |
| Wireless Rx bytes | 0 |
| Wireless Tx bytes | 870 |
| Power transmission(mW) | 2831 |

LAN ethernet info

| | |
|----------------------|-------------------|
| Ethernet status | Up |
| Ethernet IP address | 192.168.18.1 |
| Ethernet subnet mask | 255.255.255.0 |
| Ethernet MAC address | e2-8d-8a-b1-b1-d4 |
| Ethernet Rx packets | 369860 |
| Ethernet Tx packets | 1714342 |
| Ethernet Rx bytes | 43344372 |
| Ethernet Tx bytes | 1397716434 |

| Info | LAN 1 | LAN 2 |
|--------------------------------|-------------|-------------|
| Status | Up | Down |
| Duplex mode | Full Duplex | Half Duplex |
| Max bit rate | 1000 | Auto |
| Bytes Sent | 77808124 | 0 |
| Bytes received | 2428470 | 0 |
| Packets sent | 95505 | 0 |
| Packets received | 20717 | 0 |
| Errors sent | 0 | 0 |
| Unicast packets sent | 0 | 0 |
| Unicast packets received | 0 | 0 |
| Discard packets sent | 0 | 0 |
| Discard packets received | 0 | 0 |
| Multicast packets sent | 0 | 0 |
| Multicast packets received | 2734 | 0 |
| Broadcast packets sent | 0 | 0 |
| Broadcast packets received | 0 | 0 |
| Unknown photo packets received | 0 | 0 |
| CRC errors received | 0 | 0 |

Table 7-15 LAN statistics parameters

| Field | Description |
|-------------------|---|
| SSID name | Select an SSID from the list. |
| LAN Wireless info | Displays the wireless status, wireless channel, encryption status, received and transmitted bytes and packets and power transmission in mW. |
| LAN Ethernet info | Displays the Ethernet status IP address, subnet mask, MAC address, received and transmitted bytes and packets. |
| Info | Displays the information of each such as status, duplex mode, maximum bit rate, packets received and sent, CRC errors, and so on. |

END OF STEPS

Wi-Fi Configuration

7.22 Overview

This section describes the Wi-Fi configuration procedures that can be performed from the following sub-menu options under the **Wi-Fi** menu:


| Sub-menu | Procedure |
|-------------------|--|
| Wi-Fi networks | 7.23 "Configuring Wi-Fi Network" (p. 126) |
| Network map | 7.25 "Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points" (p. 133) |
| Advanced settings | 7.26 "Configuring Wireless 2.4 GHz" (p. 137) 7.27 "Configuring Wireless 5 GHz" (p. 138) |
| Wireless schedule | 7.28 "Configuring Wireless Schedules" (p. 140) |
| Wi-Fi statistics | 7.29 "Viewing Wi-Fi Statistics" (p. 141) |

7.23 Configuring Wi-Fi Network

1

Click **Wi-Fi**→**Wi-Fi network** in the left pane. The *Wi-Fi network* page displays the existing Wi-Fi networks. You can click **Detail** on a network to view the network details.

Figure 7-19 Wi-Fi network page



2

Click **Add Wi-Fi network +** to create a Wi-Fi network. The *Add Wi-Fi network* page displays.

Figure 7-20 Add Wi-Fi network page

Add Wi-Fi network ×

Please select a preferred network type from the options below.

Multi Band
Recommended - intelligently routes your devices on 2.4 GHz and 5 GHz bands based on usage, speed, coverage and distance.

2.4 GHz

5 GHz

Next

3

Configure the following parameters:

Table 7-16 Add Wi-Fi network parameters

| Field | Description |
|-----------|---|
| Multiband | Select this option to configure a multiband wireless network. This option is recommended your devices on 2.4 GHz or 5 GHz bands based on usage, speed, coverage and distance. |
| 2.4 GHz | Select this option to configure a 2.4 GHz wireless network. |
| 5 GHz | Select this option to configure a 5 GHz wireless network. |

4 _____

Click **Next**.

5 _____

Enter the name of your network in the Name field and click **Save**.

6 _____

Enter the password for the network in the Password field and click **Save**.

The Wi-Fi network is created and is displayed as a card in the **Enabled** tab of the *Wi-Fi networks* page.

 **Note:** You can click the ellipsis icon on the card of your Wi-Fi network and select **Edit** to edit and save the network name and password.

7 _____

Click **Detail** to view and edit the SSID configuration for your network.

Figure 7-21 Wi-Fi network - SSID Configuration (2.4 GHz band) page

The screenshot shows the 'SSID configuration' page for a network named 'ALHN-98AB'. The page includes the following fields and controls:

- SSID name:** ALHN-98AB
- Enable SSID:**
- Band type:** 2.4 GHz
- SSID index:** 1
- Broadcast the Wi-Fi network:**
- Guest Mode:** Disabled
- Isolation:**
- MAX users:** 128
- Encryption mode:** WPA/WPA2 Personal
- WPA version:** WPA/WPA2
- WPA Encryption Mode:** TKIP/AES
- Wi-Fi Key:** [Redacted]
- Enable WPS:**
- WPS Mode:** PBC
- WPS connect:**
- Domain Grouping:**

Figure 7-22 Wi-Fi network - SSID Configuration (5 GHz band) page

8

Configure the following parameters:

| Field | Description |
|-----------------------------|---|
| SSID name | Displays the SSID name. |
| Enable SSID | Select the toggle button to enable SSID. |
| Band type | Displays the band type. |
| SSID index | Displays the SSID index. |
| Broadcast the Wi-Fi network | Select the toggle button to enable broadcasting of the Wi-Fi network. |
| Guest Mode | Indicates whether guest mode is enabled or disabled. When a particular SSID is enabled with Guest Mode, LAN devices connected to the SSID can only connect to the Internet. Such devices cannot see or communicate with other LAN devices. |
| Isolation | Select the toggle button to enable isolation. |
| MAX users | Enter the maximum number of users. |

| Field | Description |
|---------------------|--|
| Encryption Mode | <p>In case of 2.4 GHz band type, select an encryption mode from the list:</p> <ul style="list-style-type: none"> • WPA/WPA2 Personal • WPA3 Personal • WPA2/WPA3 Personal • WPA/WPA2 Enterprise • WPA3 Enterprise • Open <p>In case of 5 GHz band type, select an encryption mode from the list:</p> <ul style="list-style-type: none"> • WPA2-AES • WPA2+WPA • WPA3-AES • WPA2+WPA3-AES • WPA/WPA2 Enterprise • WPA3 Enterprise • NONE-OPEN |
| WPA version | <p>Select a WPA version from the list:</p> <ul style="list-style-type: none"> • WPA2 • WPA/WPA2 • WPA3 • WPA2/WPA3 <p>This parameter is visible only if the band type is 2.4 GHz.</p> |
| WPA Encryption Mode | <p>Select a WPA encryption mode from the list:</p> <ul style="list-style-type: none"> • AES • TKIP/AES <p>This parameter is visible only if the band type is 2.4 GHz.</p> |
| Wi-Fi Key | Enter the Wi-Fi key. |
| Enable WPS | Select the toggle button to enable WPS . |
| WPS Mode | <p>Select the required WPS mode from the list:</p> <ul style="list-style-type: none"> • PBC • STA PIN • AP PIN |
| Domain Grouping | Select the toggle button to enable domain grouping. |

Notes:

1. When Encryption Mode is set to “WPA/WPA2 Enterprise”, the following options are no longer available: WPA encryption mode, WPA key, Enable WPS, WPS mode.
2. When Encryption Mode is set to “WPA/WPA2 Enterprise”, the following options become available: Primary RADIUS server, port and password; RADIUS accounting port.


9 _____
 Click **Save**.

END OF STEPS _____

7.24 Configuring Guest Network

1 _____
 Click **Wi-Fi**→**Guest network** in the left pane. The *Guest network* page displays the network details.

Figure 7-23 Guest network page



2 _____
 Configure the following parameters:

Table 7-17 Guest network parameters

| Field | Description |
|----------------------|---|
| Name | Enter the name for guest network. |
| Password | Enter a password for guest network. Click Save . |
| Enable guest network | Select this toggle button to enable guest WiFi. Enabling the Guest SSID creates a multiband network (2.4GHz and 5GHz). Atleast one 2.4GHz and one 5GHz SSID index must be available to enable Guest network. After enabling the Guest Network a new WiFi card can be seen in WiFi networks page and Overview page with Guest SSID details. |


- 3 Share the QR code for others to join the guest network.

END OF STEPS

7.25 Viewing Network Map, Adding Wi-Fi Points and Removing Wi-Fi Points

- 1 Click **WiFi**→**Network map** in the left pane. The *Network map* page displays the Wi-Fi points added to the network.

Figure 7-24 Network map page



- 2 Perform the following steps to add a Wi-Fi point:
 - a. Click **Add Wi-Fi point** at the top right corner of the *Device Info* page. A message displays that it is recommended to use the Nokia Wi-Fi mobile app to add a Wi-Fi point.
 - b. To add a Wi-Fi point using the WebGUI, click **Continue with WebGUI**.

Add Wi-Fi point

We recommend using the Nokia Wi-Fi app to add a new device as it provides detailed onboarding information.



- c. In the *Add Wi-Fi point* page, enter the serial number and click **Add**.

Add Wi-Fi point

Serial Number



The Wi-Fi point is displayed in the *Detected* or *Not detected* list of the *Onboarding Status* panel in the *Device Info* page.

3

Click on a Wi-Fi point to view the device details. The *<Device>* page displays the details of the selected device in the network, including connection status.

Figure 7-25 <Device> page




Table 7-18 <Device> parameters

| Field | Description |
|-------------------|---|
| Device name | Name on the device |
| Serial number | Serial number of the device |
| MAC address | MAC address of the device |
| IP address | IP address of the device |
| Software version | Software version of the device (displays only for a root device) |
| Hardware version | Hardware version of the device (displays only for a root device) |
| Boot version | Boot version of the device (displays only for a root device) |
| Uptime | Amount of time the device has run since last reset in hours, minutes, and seconds (displays only for a root device) |
| Chipset | Chipset of the device (displays only for a root device) |
| Vendor | Name of the vendor (displays only for a root device) |
| Onboarding status | Onboarding status of the device in the Wi-Fi network (displays only for an extender device) |
| Backhaul status | Backhaul status of the device (displays only for an extender device) |
| Location nickname | Name of the location of the device (displays only for an extender device) |

4 Click **LED Light** to enable the LED light on the device.

5 Perform any of the following, as applicable:


- **Reboot the device:**
 1. Click **Reboot**. A message displays asking if you want reboot the device.
 2. Click **OK** to reboot the ONT. The device reboots and displays the login page.
- **Reset the device to factory default settings:**
 1. Click **Factory default**. A message displays asking if you want to reset the system configuration to the factory default settings.
 2. Click **OK** to reset the ONT to the factory default settings.

END OF STEPS

7.25.1 Remove Wi-Fi points

To remove Wi-Fi points, perform the following:

1. Click any extender device and the following *Network map* page is displayed.



2. Ensure to power off the extender and wait for few minutes to get the extender in offline status and click **Remove** to permanently remove the Wi-Fi point from your network.

When the extender is in powered on state, a message is displayed to power off the extender and then remove it permanently.

The Wi-Fi point is removed from your network. If you want to use the Wi-Fi point on a different network, factory reset it first.

7.26 Configuring Wireless 2.4 GHz

- 1 _____
 Click **Wi-Fi**→**Advanced settings** in the left pane. The *Advanced settings* page displays.
- 2 _____
 Select the **2.4 GHz** tab to configure the wireless 2.4 GHz parameters.

Figure 7-26 Advanced settings - 2.4 GHz tab

- 3 _____
 Configure the following parameters:

Table 7-19 Wireless 2.4 GHz parameters

| Field | Description |
|--------|---|
| Enable | Select the toggle button to enable Wireless (2.4 GHz). |
| Mode | Select a wireless mode from the list: <ul style="list-style-type: none"> • Auto (b/g/n/ax) • b/g/n • b • g • n • b/g • g/n • n/ax |

Table 7-19 Wireless 2.4 GHz parameters (continued)

| Field | Description |
|-------------------|---|
| Channel bandwidth | Select the bandwidth range from the list: <ul style="list-style-type: none"> • Auto (auto-assigns the bandwidth range) • 20 MHz • 40 MHz |
| Channel | Select a channel from the list or select Auto to auto-assign the channel. |
| Transmit power | Select a percentage for the transmitting power from the list: <ul style="list-style-type: none"> • 12% • 25% • 50% • 100% |
| WMM | Select an option from the list to enable or disable wireless multimedia: <ul style="list-style-type: none"> • Enable • Disable |
| Enable MU-MIMO | Select an option from the list to enable or disable MU-MIMO: <ul style="list-style-type: none"> • Enable • Disable |
| Total max users | Enter the maximum number of users. |

4 _____
 Click **Save**.

END OF STEPS _____

7.27 Configuring Wireless 5 GHz

1 _____
 Click **Wi-Fi**→**Advanced settings** in the left pane. The *Advanced settings* page displays.

2 _____
 Select the **5 GHz** tab to configure the wireless 5 GHz parameters.

Figure 7-27 Advanced settings - 5 GHz tab

3

Configure the following parameters:

Table 7-20 Wireless 5 GHz parameters

| Field | Description |
|-------------------|---|
| Enable | Select this toggle button to enable WiFi. |
| Channel bandwidth | Select the bandwidth range from the list: <ul style="list-style-type: none"> • 20 MHz • 40 MHz • 80 MHz • 160 MHz • Auto |
| Channel | Select a channel from the list or select Auto to auto-assign the channel. |
| Transmit power | Select a percentage for the transmitting power from the list: <ul style="list-style-type: none"> • 12% • 25% • 50% • 100% |
| WMM | Select Enable or Disable from the list to enable or disable WiFi multimedia. |
| Enable MU-MIMO | Select the toggle button to enable MU-MIMO. This can be enabled when multiple users are trying to access the wireless network. When this parameter is enabled, multiple users can access router functions without the congestion. |
| Total max users | Enter the total number of MAX users. The maximum users allowed is 128. |


4 _____
Click **Save**.

END OF STEPS _____

7.28 Configuring Wireless Schedules

1 _____
Click **Wi-Fi**→**Wireless schedule** in the left pane. The *Wireless schedule* page displays.

Figure 7-28 Wireless schedule page



2 _____
Select the **Enable Scheduling** toggle button to turn off the wireless signal for the configured period.

i **Note:** The ONT stores the settings of the current wireless signal and restores with the same settings when Wi-Fi is enabled or disabled until the programmed wireless signal rule is triggered. The stored value is restored if the active wireless signal schedule rule is deleted.

3 _____
Click **Add new +** to add a scheduling rule.


- 4 _____
 Enter a start time and end time for the period during which you want to turn off the wireless signal.
- 5 _____
 Select **Everyday** or **Individual Days** from the list.
- 6 _____
 If you select **Individual Days**, select the checkboxes for the desired days.
 The Recurrence Pattern shows the rules created to date.
- 7 _____
 If required, click **Add new +** to add more rules.

END OF STEPS _____

7.29 Viewing Wi-Fi Statistics

- 1 _____
 Click **Wi-Fi**→**Wi-Fi statistics** in the left pane. The *Wi-Fi statistics* page displays.

Figure 7-29 Wi-Fi statistics page



- 2 _____
 Select the **STA information** tab to display STA parameters.

Table 7-21 STA information parameters

| Field | Description |
|---------------------|---|
| MAC address | Indicates the MAC address of the Ethernet connection. |
| SSID name | Indicates the name of each SSID. |
| Channel | Indicates the channel number. |
| Connection duration | Indicates the connection duration. |

Table 7-21 STA information parameters (continued)

| Field | Description |
|------------|---|
| Wi-Fi mode | Indicates the Wi-Fi mode. |
| RSSI (dBm) | Indicates the received signal strength. |

3

Select the **Neighboring AP** tab to display Neighboring AP parameters.

Table 7-22 Neighboring AP parameters

| Field | Description |
|---------------------|---|
| Index | Name of the index. |
| SSID name | Name of each SSID. |
| MAC address | MAC address of the Ethernet connection. |
| Channel | Channel number. |
| RSSI (dBm) | Received signal strength in dBm. |
| Authentication mode | Authentication mode. |
| Wi-Fi mode | Indicates the Wi-Fi mode |
| Network type | Indicates the network type |

Click **Scan** to scan for neighboring access points.

4

Select the **WLAN statistics** tab to display WLAN statistics.

END OF STEPS

Devices

7.30 Overview


This section describes how to view device information from the **Device** menu.

7.31 Viewing Device Information

1

Click **Devices** in the left pane. The *Devices* page displays the devices.


Figure 7-30 *Devices* page



2

Click the arrow next to a device to view the device details. The *Device Info* page displays the details of the selected device in the network, including connection status.

Figure 7-31 <Device> page



END OF STEPS

Voice Configuration

7.32 Overview

This section describes the voice configuration procedures that can be performed from the following sub-menu options under the **Voice** menu:

| Sub-menu | Procedure |
|----------------------|--|
| Voice setting | 7.33 "Configuring Voice Settings" (p. 145) |
| Voice status | 7.34 "Viewing Voice Status" (p. 146) |

7.33 Configuring Voice Settings

1

Click **Voice**→**Voice Setting** in the left pane. The *Voice Setting* page displays.

Figure 7-32 Voice Setting page

2

Configure the following parameters:

Table 7-23 Voice Setting parameters

| Field | Description |
|-----------------------|---|
| Outbound Proxy | Enter the outbound proxy details. |
| Outbound Proxy Port | Enter the outbound proxy port. |
| Proxy Server | Enter the proxy server details. |
| Proxy Server Port | Enter the proxy server port. |
| Proxy Server | Enter the proxy server details. |
| Proxy Server Port | Enter the proxy server port. |
| Registrar Server | Enter the registrar server details. |
| Registrar Server Port | Enter the registrar server port. |
| User Agent Domain | Enter the user agent domain details. |
| User Agent Port | Enter the user agent port. |
| DTMF Mode | Select a DTMF mode from the list. |
| FAXT38 | Select True or False from the list. |
| POTS Line | Select a POTS line from the list. |
| Enable | Select the toggle button to enable. |
| Directory Number | Enter the directory number. |
| Auth User Name | Enter the authentication username. |
| Auth Password | Enter the authentication password. |
| URI | Enter the URI. |

3

Click **Save**.

END OF STEPS

7.34 Viewing Voice Status

1

Click **Voice** → **Voice status** in the left pane. The *Voice status* page displays the following information:

Figure 7-33 Voice status page

Table 7-24 Voice status parameters

| Field | Description |
|-------------------------------|---|
| POTS 1 registration status | Indicates if POTS 1 is registered or not. If POTS 1 is registered, the status displays as Registered. The status is empty if no voice service is provisioned. |
| POTS 2 registration status | Indicates if POTS 2 is registered or not. If POTS 2 is registered, the status displays as Registered. The status is empty if no voice service is provisioned. |
| POTS 1 line state | Indicates the line in POTS 1. The default is Disabled. |
| POTS 2 line state | Indicates the line in POTS 2. The default is Disabled. |
| Softswitch line 1 | Proxy IP address; blank if the line is not registered. |
| Softswitch line 2 | Proxy IP address; blank if the line is not registered. |
| Telephone line 1 phone number | Phone number configured for a telephone line 1. |
| Telephone line 2 phone number | Phone number configured for a telephone line 2. |

Table 7-24 Voice status parameters (continued)

| Field | Description |
|----------------------------------|--|
| Line 1 registration error code | SIP standard error code for the registration status; for example, 401, 403, 503. This field is blank if the registration is OK. |
| Line 2 registration error code | SIP standard error code for the registration status. This field is blank if the registration is OK. |
| Line 1 registration error reason | SIP standard error reason for the register status. This field is blank if the registration is OK. |
| Line 2 registration error reason | SIP standard error reason for the register status. This field is blank if the registration is OK. |
| User agent IP | IP address of the user agent. |

END OF STEPS

Security Configuration

7.35 Overview

This section describes the security configuration procedures that can be performed from the following sub-menu options under the **Security** menu:

| Sub-menu | Procedure |
|-----------------|---|
| Firewall | 7.36 "Configuring the Firewall" (p. 149) |
| MAC filter | 7.37 "Configuring the MAC Filter" (p. 150) |
| IP filter | 7.38 "Configuring the IP Filter" (p. 152) |
| URL filter | 7.39 "Configuring the URL Filter" (p. 154) |
| Family profiles | 7.40 "Configuring Family Profiles" (p. 155) |
| DMZ and ALG | 7.41 "Configuring DMZ and ALG" (p. 166) |
| Access control | 7.42 "Configuring Access Control" (p. 167) |

7.36 Configuring the Firewall

1

Click **Security**→**Firewall** in the left pane. The *Firewall* page displays.

Figure 7-34 Firewall page

Security / Firewall

Security level

High: Traffic denied inbound and minimally permit common service outbound.
Low: All outbound traffic and pinhole-defined inbound traffic is allowed.
Off: All inbound and outbound traffic is allowed.

Attack Protection

Save

2

Configure the following parameters.

Table 7-25 Firewall parameters

| Field | Description |
|-------------------|--|
| Security level | Select the security level from the list: <ul style="list-style-type: none"> • High: Pre-routing and application services are not supported. UDP Port 8000 can be used to access the services. For example, FTP can use 8021 and Telnet can use 8023. Regular UDP cannot be used. RG access is permitted via the LAN side but not via the WAN side. • Low: All outbound traffic and pinhole-defined inbound traffic is allowed. Pre-routing is supported: port forwarding, DMZ, host application, and host drop. Also supported are application services: DDNS, DHCP, DNS, H248, IGMP, NTP client, SSH, Telnet, TFTP, TR-069, and VoIP. The following types of ICMP messages are permitted: echo request and reply, destination unreachable, and TTL exceeded. Other types of ICMP messages are blocked. DNS proxy is supported from LAN to WAN but not from WAN to LAN. • Off: All inbound and outbound traffic is allowed. No firewall security is in effect. |
| Attack Protection | Select Enable or Disable from the list to enable or disable protection against DoS or DDoS attacks. Default value: Enable . |

3 _____
 Click **Save**.

END OF STEPS _____

7.37 Configuring the MAC Filter

1 _____
 Click **Security**→**MAC filter** in the left pane. The *MAC filter* page displays.

Figure 7-35 MAC filter page

2

Configure the following parameters:

Table 7-26 MAC filter - Ethernet Interface parameters

| Field | Description |
|---------------------------|--|
| Ethernet Interface | |
| MAC filter mode | Select the MAC filter mode from the list: <ul style="list-style-type: none"> • Blocked • Allowed |
| LAN port | Select the toggle button to enable any of the LAN ports. |
| MAC address | Select a MAC address from the list or enter the MAC address in the text field. |

3

Click **Save**.

4

Configure the following parameters:

Table 7-27 MAC filter - Wi-Fi SSID parameters

| Field | Description |
|-------------------|---|
| Wi-Fi SSID | |
| MAC filter mode | Select the MAC filter mode from the list: <ul style="list-style-type: none">• Blocked• Allowed |
| SSID select | Select the SSID from the list. |
| Enabled | Select the toggle button to enable the MAC filter. |
| MAC address | Select a MAC address from the list or enter the MAC address in the text field. |

5 _____

Click **Save**.

END OF STEPS _____

7.38 Configuring the IP Filter

1 _____

Click **Security**→**IP filter** in the left pane. The *IP filter* page displays.

Figure 7-36 IP filter page

2

Configure the following parameters:

Table 7-28 IP filter parameters

| Field | Description |
|-------------------|---|
| Enable IP filter | Select the toggle button to enable an IP filter. |
| Mode | Select an IP filter mode from the list: <ul style="list-style-type: none"> • Drop for upstream • Drop for downstream |
| Internal client | Select an internal client from the list: <ul style="list-style-type: none"> • Custom Settings: uses the IP address input below • IP: uses the connecting devices' IP to the ONT |
| Local IP address | Enter the local IP address. |
| Local subnet mask | Enter the local subnet mask. |

Table 7-28 IP filter parameters (continued)

| Field | Description |
|--------------------|--|
| Remote IP address | Enter the remote IP address. |
| Remote subnet mask | Enter the remote subnet mask. |
| Protocol | Select an application protocol or select ALL from the list. |

3

Click **Save**.

END OF STEPS

7.39 Configuring the URL Filter

i **Note:** You can add up to 100 URL filters.

1

Click **Security**→**URL filter** in the left pane. The *URL filter* page displays.

Figure 7-37 URL filter page

Security / **URL filter**

URL filter
Please select the type of filter and then configure the URL. Support upto 100 URL filters.

Enable URL filter

URL filter type: Block

URL address:

Port number:
The default port number is 80

Add filter +

i **Note:** You cannot use URL filtering for HTTPS. The URL is encrypted when using HTTPS.

2

Configure the following parameters:

Table 7-29 URL filter parameters

| Field | Description |
|-------------------|---|
| Enable URL filter | Select the toggle button to enable the URL filter. |
| URL filter type | Select a URL filter type from the list: <ul style="list-style-type: none">• Block• Allow |
| URL address | Enter the URL address. |
| Port number | Enter the port number. Default value: 80 |

3

Click **Add filter +** to add the URL filter.


END OF STEPS

7.40 Configuring Family Profiles

1

Click **Security**→**Family profiles (Parental control)** from the left pane. The *Family profiles (Parental control)* page displays.

Figure 7-38 Family profiles (Parental control) page




2

Click **Add profile +** to add a profile with parental controls.

3

In the *Add a profile* page, enter a name for the profile and click **Add**.

Figure 7-39 Add a profile page



Add a profile X

Name

eg. Alex


Cancel Add

4

In the *Select the devices used by <profile>* page, select the check box next to the device name and click **Save** to assign the device to the profile.

i **Note:** A device can be assigned to only one profile. Unassigned devices are added to the *Home* profile.

Figure 7-40 Assign devices to family profile



The new profile name is listed in the table in the *Family profiles (Parental control)* page.

Figure 7-41 Family profiles table

The screenshot shows a table titled "Security / Family profiles (Parental control)" with a refresh icon and an "Add profile +" button. The table lists four profiles: Home, Client_1, Client_2, and profile_3. Each profile has columns for Device, Schedules, Bedtime, Blocked websites, and Visit attempts (blocked sites). The Home profile has 0 in all columns. Client_1 has 1 device, 2 schedules, 3 bedtime, 4 blocked websites, and 0 visit attempts. Client_2 has 1 device, 1 schedule, 2 bedtime, 1 blocked website, and 0 visit attempts. profile_3 has 0 devices, 0 schedules, 0 bedtime, 1 blocked website, and 0 visit attempts. Each profile has a "Delete" button.

| Profile name | Device | Schedules | Bedtime | Blocked websites | Visit attempts (blocked sites) | |
|----------------------|--------|-----------|---------|------------------|--------------------------------|--------|
| Home Enabled | 0 | 0 | 0 | 0 | 0 | |
| Client_1 Enabled | 1 | 2 | 3 | 4 | 0 | Delete |
| Client_2 Enabled | 1 | 1 | 2 | 1 | 0 | Delete |
| profile_3 Enabled | 0 | 0 | 0 | 1 | 0 | Delete |

5

Click a profile to configure parental control for the profile. A page displays the profile parameters.

Figure 7-42 Family profile configuration page

The screenshot shows the configuration page for the "Client_1" profile. It includes a profile icon and name, and several configuration sections: "Assigned Devices" (1 Device), "Internet Access" (Enabled for this profile, with a toggle switch), "Schedules" (None), "Bedtime" (None), and "Website blocking" (None). Each section has an edit icon.

6

Select the **Internet Access** toggle button to enable internet access.

Assign more devices

7

Assign more devices to the profile, if required:

- a. In the profile page, click the edit icon  next to **Assigned Devices** to assign devices to the profile. The *Select the devices used by <profile>* page displays.

Select the devices used by Client_1 ×

A device can only belong to one profile. Unassigned devices will be added to the "Home" profile.



| | | |
|---|---------------|---|
|  | Home |  |
|  | ONTPT_JENKINS | <input type="checkbox"/> |

- b. Select the check box next to the device to assign to the profile.
- c. Click **Save**.

Configure and enable schedules

8

Configure schedules for the profile:

- a. In the profile page, click the edit icon  next to **Schedules** to create one or more schedules for the profile to set specific days and time slots when the Internet should be turned off.
- b. Click **Create Schedule**.
- c. In the *Add a schedule* page, configure the following:

Add a schedule ✕

Name

Start time

End time


Days of the week

M TU W TH F SA SU

1. Enter the name of the schedule in the Name field.
2. Select the start time, end time, and select the days of the week on which the schedule will be in effect.
3. Click **Save**. The schedule is created and listed in the Schedules page.

9

In the *Schedules* page, select the toggle button to enable the schedule and click **Done**. To add more schedules, you can click **Add +**.



Configure and enable bedtime

10

Configure bedtime for the profile:

- In the profile page, click the edit icon  next to **Bedtime** to configure bedtime for the profile to automatically pause internet access at this time.
Only one bedtime can be assigned per day.
- Click **Create Bedtime**.
- In the *Add a bedtime* page, configure the following:

Add a bedtime ×

Bedtime

21 : 00

Wake Up

06 : 00

Days of the week

M **TU** **W** **TH** **F** SA SU

Cancel Save


-
1. Select the Bedtime, Wake Up time, and select the days of the week on which the bedtime will be in effect.
 2. Click **Save**. The bedtime is created and listed in the *Bedtime* page.
- d. In the *Bedtime* page, select the toggle button to enable the bedtime and click **Done**.

Configure website blocking

11

Configure website blocking for the profile:

- a. In the profile page, click the edit icon  next to **Website blocking** to control websites and services that devices assigned to the profile can access.
- b. Click **Continue**.
- c. In the *Website blocking* page, perform the following:



1. Select the toggle button next to **Filtering** to enable filtering to control the profile's website access.
2. Click **Add +** to add a website URL to be blocked.
3. Enter the URL in the Website URL field and click **Save**.

4. Click **Add +** to add more website URLs to be blocked or click **Done**.

END OF STEPS

7.41 Configuring DMZ and ALG

1

Click **Security**→**DMZ and ALG** in the left pane. The *DMZ and ALG* page displays.

Figure 7-43 DMZ and ALG page

Security / **DMZ and ALG**

ALG Configuration

FTP

TFTP

SIP

H323

RTSP

L2TP

IPSEC

PPTP

Save

DMZ Configuration

WAN connection list: 1_TR069_INTERNET_OTHER_R_VID_0

Enable DMZ:

DMZ IP address: Custom Settings

0.0.0.0

Save

2

Configure the following parameters:

Table 7-30 ALG Configuration parameters

| Field | Description |
|-------------------|--|
| ALG Configuration | Select the toggle button next to the protocol name to enable the protocols to be supported by ALG: <ul style="list-style-type: none"> • FTP • TFTP • SIP • H323 • RTSP • L2TP • IPSEC • PPTP |

3

Click **Save**.

4

Configure the following parameters:

Table 7-31 DMZ Configuration parameters

| Field | Description |
|---------------------|--|
| WAN connection list | Select a WAN connection from the list. |
| Enable DMZ | Select the toggle button to enable DMZ on the WAN connection. |
| DMZ IP address | Select Custom Settings and enter the DMZ IP address or select the IP address of a connected device from the list. |

5

Click **Save**.

END OF STEPS

7.42 Configuring Access Control

This procedure describes how to configure the access control level (ACL).



Note: ACL takes precedence over the firewall policy.

The trusted network will be shared for all WAN connections; it is not applied individually to a WAN connection.

1

Click **Security**→**Access control** in the left pane. The *Access control* page displays.

Figure 7-44 Access control page

Security / **Access control** ↻

WAN connection list 1_TR069_INTERNET_OTHER_R_VID_0 ▾

Enable trusted network

| WAN | | LAN | |
|--------|---------|--------|---------|
| ICMP | Allow ▾ | ICMP | Allow ▾ |
| Telnet | Deny ▾ | Telnet | Deny ▾ |
| SSH | Deny ▾ | SSH | Allow ▾ |
| HTTP | Deny ▾ | HTTP | Allow ▾ |
| TR-069 | Allow ▾ | TR-069 | Deny ▾ |
| HTTPS | Deny ▾ | HTTPS | Allow ▾ |
| SFTP | Deny ▾ | SFTP | Deny ▾ |

Save

Trusted network

Source IP start

Source IP end

Add +

2

Configure the following parameters:

Table 7-32 Access control parameters

| Field | Description |
|------------------------|--|
| WAN connection list | Select a WAN connection from the list. |
| Enable trusted network | Select the toggle button to enable a trusted network. |
| WAN | The following protocols are supported: ICMP, Telnet, SSH, HTTP, TR-069, HTTPS, SFTP. Select an access control level for each protocol: Allow, Deny, or Trusted Network Only LAN side: Allow or Deny |
| LAN | The following protocols are supported: ICMP, Telnet, SSH, HTTP, TR-069, HTTPS, SFTP. Select an access control level for each protocol: LAN side: Allow or Deny |

3

Click **Save** to save the ACL configuration.

4

If the **Enable trusted network** option is enabled, add one or more subnet trusted networks. You can add up to 32 trusted networks.

Table 7-33 Trusted Network parameters

| Field | Description |
|-----------------|--|
| Source IP start | Enter a start IP address range for the new subnet trusted network. |
| Source IP end | Enter an end IP address range for the new subnet trusted network. |

5

Click **Add +**.

END OF STEPS

Advanced Settings

7.43 Overview

This section describes the advanced settings that can be performed from the following sub-menu options under the **Advanced settings** menu:

| Sub-menu | Procedure |
|-----------------|---|
| Port forwarding | 7.44 "Configuring Port Forwarding" (p. 170) |
| Port triggering | 7.45 "Configuring Port Triggering" (p. 171) |
| DDNS | 7.46 "Configuring DDNS" (p. 173) |
| NTP | 7.47 "Configuring NTP" (p. 174) |
| USB | 7.48 "Configuring USB" (p. 176) |
| UPNP and DLNA | 7.49 "Configuring UPNP and DLNA" (p. 177) |

7.44 Configuring Port Forwarding

1

Click **Advanced settings** → **Port forwarding** in the left pane. The *Port forwarding* page displays.

Figure 7-45 Port forwarding page

Advanced settings / **Port forwarding** ↻ Save

Application name: Custom Settings

WAN port: [] - []

LAN port: [] - []

Internal client: Custom Settings []

Protocol: TCP

WAN connection list: 1_VOIP_TR069_INTERNET_R_VID_881

| Application name | Wan Connection | WAN port | LAN port | Device name | Internal client | Protocol | Status | Configuration Source | Delete |
|------------------|----------------|----------|----------|-------------|-----------------|----------|--------|----------------------|--------|
| No data | | | | | | | | | |

2

Configure the following parameters:

Table 7-34 Port forwarding parameters

| Field | Description |
|---------------------|---|
| Application name | Select an application name from the list. The default is Custom Settings . |
| WAN port | Enter the WAN port range. |
| LAN port | Enter the LAN port range. |
| Internal client | Select a connected device from the list and enter the associated IP address. The default is Custom Settings . |
| Protocol | Select the port forwarding protocol from the list: <ul style="list-style-type: none">• TCP• UDP• TCP/UDP |
| WAN connection list | Select a WAN connection from the list. Only active devices are displayed in the list. |

3

Click **Save**.

END OF STEPS

7.45 Configuring Port Triggering

1

Click **Advanced settings**→**Port triggering** in the left pane. The *Port triggering* page displays.

Figure 7-46 Port triggering page

Advanced settings / **Port triggering** Save

Application name Custom Settings

Open port -

Triggering port -

Expire time 600
Range: 1-999999 secs

Open protocol TCP

Trigger protocol TCP

WAN connection list 1_VOIP_TR069_INTERNET_R_VID_8B1

| Application name | Wan Connection | Open port | Triggering port | Expire time | Open protocol | Trigger protocol | Status | Configuration Source | Delete |
|------------------|----------------|-----------|-----------------|-------------|---------------|------------------|--------|----------------------|--------|
| No data | | | | | | | | | |

2

Configure the following parameters:

Table 7-35 Port triggering parameters

| Field | Description |
|------------------|--|
| Application name | Select an application name from the list. The default is Custom settings . |
| Open port | Enter the open port range. |
| Triggering port | Enter the triggering port range. |
| Expire time | Enter the expiration time in seconds. Allowed range: 1 to 999999 seconds |
| Open protocol | Select the open port protocol from the list: <ul style="list-style-type: none"> • TCP • UDP • TCP/UDP |

Table 7-35 Port triggering parameters (continued)

| Field | Description |
|---------------------|--|
| Trigger protocol | Select the triggering port protocol from the list: <ul style="list-style-type: none"> • TCP • UDP • TCP/UDP |
| WAN connection list | Select a WAN connection from the list. Only active devices are displayed in the list. |

3

Click **Save**.

END OF STEPS

7.46 Configuring DDNS

1

Click **Advanced settings**→**DDNS** in the left pane. The *DDNS* page displays.

Figure 7-47 DDNS page

Advanced settings / **DDNS**

WAN connection list: 1_TR069_INTERNET_OTHER_R_VID_0

Enable DDNS:

ISP: DynDNS.org

Domain Name:

Username:

Password:

Save

2

Configure the following parameters:

Table 7-36 DDNS parameters

| Field | Description |
|---------------------|--|
| WAN connection list | Select a WAN connection from the list. |
| Enable DDNS | Select the toggle button to enable DDNS on the WAN connection. |
| ISP | Select an ISP from the list. |
| Domain Name | Enter the domain name of the DDNS server. |
| Username | Enter the username. |
| Password | Enter the password. |

3

Click **Save**.

END OF STEPS

7.47 Configuring NTP

1

Click **Advanced settings**→**NTP** in the left pane. The *NTP* page displays.

Figure 7-48 NTP page

2

Configure the following parameters:

Table 7-37 NTP parameters

| Field | Description |
|---|--|
| Enable NTP service | Select the toggle button to enable the NTP service. |
| Current date & time | Displays the current local date and time. |
| Primary Time Server Secondary Time Server Third Time Server | Select a time server from the list or select Custom Settings and enter the IP address of the time server. You can select None if you do not want configure a secondary or tertiary time server. |
| Interval time | Enter the interval at which to get the time from the time server, in seconds. Allowed values: 0 to 259200 seconds |
| Time zone | Select the local time zone from the list. |

3

Click **Save**.

END OF STEPS

7.48 Configuring USB

You can connect USB storage devices and USB printers to the USB ports of the device. The USB menu enables you to configure FTP and SFTP for your USB storage devices.

The USB connected devices are shown in a table at the bottom of the *USB* page.

1

Click **Advanced settings**→**USB** in the left pane. The *USB* page displays.

Figure 7-49 USB page

2

Configure the following parameters:

Table 7-38 USB parameters

| Field | Description |
|-------------------|---|
| Enable FTP server | Select the toggle button to enable an FTP server. By default, FTP server is disabled. |

Table 7-38 USB parameters (continued)

| Field | Description |
|-------------------------------|--|
| Username | Enter the username of the FTP server. |
| Password | Enter the password of the FTP server. |
| Re-enter password | Re-enter the password of the FTP server. |
| Enable SFTP Server | Select the toggle button to enable an SFTP server. By default, SFTP server is disabled. |
| Enable SFTP for Remote Access | Select the toggle button to enable SFTP for remote access. By default, SFTP is disabled. |
| Username | Enter the username of the SFTP server. |
| Password | Enter the password of the SFTP server. |
| Re-enter password | Re-enter the password of the SFTP server. |
| Enable printer sharing | Select the toggle button to enable printer sharing. By default, printer sharing is disabled. |
| Username | Enter the username of the printer. |
| Password | Enter the password of the printer. |
| Re-enter password | Re-enter the password of the printer. |

3

Click **Save**.

A table displays the following information for each server or printer that is connected to the device through a USB port:

- Host Number: For example, Printer1, Printer2
- Device Name: Name or identifier of the device
- Format: Storage format (applies only to a USB storage device)
- Total space (applies only to a USB storage device)
- Free space (applies only to a USB storage device)


END OF STEPS

7.49 Configuring UPNP and DLNA

1

Click **Advanced settings**→**UPNP and DLNA** from the left pane. The *UPNP and DLNA* page displays.

Figure 7-50 UPNP and DLNA page



2 _____
Select the **Enable UPNP/DLNA** toggle button to enable UPNP/DLNA. If this toggle button is not enabled, the UPNP and DLNA process will not start.

3 _____
Click **Save**.

END OF STEPS _____

Maintenance

7.50 Overview

This section describes the maintenance procedures that can be performed from the following sub-menu options under the **Maintenance** menu:

| Sub-menu | Procedure |
|---------------------------|---|
| Change password | 7.51 "Configuring the Password" (p. 179) |
| Backup and restore | 7.52 "Backing Up the Configuration" (p. 181) 7.53 "Restoring the Configuration" (p. 181) |
| Firmware upgrade | 7.54 "Upgrading Firmware" (p. 182) |
| LOID config | 7.55 "Configuring LOID" (p. 184) |
| SLID configuration | 7.56 "Configuring SLID" (p. 184) |
| Device management | 7.57 "Managing the Device" (p. 185) |
| Diagnostics | 7.58 "Diagnosing WAN Connections" (p. 186) |
| Log | 7.59 "Viewing Log Files" (p. 190) |

7.51 Configuring the Password

A password must adhere to the following password rules:

- The password may consist of uppercase letters, lowercase letters, digital numbers, and the following special characters ! # + , - / @ _ : =]
- The password length must be from 8 to 24 characters
- The first character must be a digital number or a letter
- The password must contain at least two types of characters: numbers, letters, or special characters
- The same character must not appear more than 8 times in a row

When the password meets the password rules, the application displays the message "Your password has been changed successfully".

When the password does not meet the password rules, the application displays a message to indicate which password rule has not been followed, for example:

- The password is too short
- The password is too long
- The first character cannot be a special character
- There are not enough character classes

1

Click **Maintenance**→**Change password** in the left pane. The *Change password* page displays.

Figure 7-51 Change password page

Maintenance / **Change password**

Original password

New password

Letters (upper or lower case)
 Numbers
 Special characters (!#+,-./:=@_)
 At least 8 characters in length

Repeat new password

Password hint

This is the hint for your password if you forgot it.

Save

2

Configure the following parameters:

Table 7-39 Change password parameters

| Field | Description |
|---------------------|--|
| Original password | Enter the current password. |
| New password | Enter the new password as per the password rules. |
| Repeat new password | Re-enter the new password (must match the password entered above exactly). |
| Password hint | Enter the password hint message. |

3

Click **Save**.


END OF STEPS

7.52 Backing Up the Configuration

1

Click **Maintenance**→**Backup and restore** in the left pane. The *Backup and restore* page displays.

Figure 7-52 Backup and restore page



2

Click **Export** to export the current ONT configuration to your PC. The configuration filename is *config.cfg*.

END OF STEPS

7.53 Restoring the Configuration




Note: Ensure that you have a previously backed-up configuration file.

1

Click **Maintenance**→**Backup and restore** in the left pane. The *Backup and restore* page displays.

Figure 7-53 Backup and restore page



Maintenance / **Backup and restore** ↻

Select backed-up configuration file to be restored [Select](#)

No file selected

Import configuration file [Import](#)

Export configuration file [Export](#)

2 _____

Click **Select** and select the previously backed-up configuration file.

3 _____

Click **Import** to import the configuration file and restore the ONT to the backed-up configuration.

A confirmation message displays after successful restore and the ONT reboots.


END OF STEPS _____

7.54 Upgrading Firmware

1 _____

Click **Maintenance**→**Firmware upgrade** in the left pane. The *Firmware upgrade* page displays.

Figure 7-54 Firmware upgrade page



Maintenance / **Firmware upgrade** ↻

Select file [Select](#)

No file selected

[Upgrade](#)

2 Click **Select** and select the file for firmware upgrade.

3 Click **Upgrade** to upgrade the firmware. The status displays in the *Upgrade status* panel. The device reboots after firmware upgrade and displays the login page.

Figure 7-55 Example of upgrade status messages

Upgrade status

Upgrade Done!

get_cert_type_from_buildinfo NCG

Image check pass, everything is OK

Saving config files...

Performing system upgrade...

Upgrade completed

4

mkdir: can't create directory '/configs/swdl': File exists

sh: using fallback suid method

sync: using fallback suid method

date: using fallback suid method

Upgrade ok, Rebooting...


END OF STEPS

7.55 Configuring LOID

1

Click **Maintenance**→**LOID config** in the left pane. The *LOID config* page displays.

Figure 7-56 *LOID config* page



The screenshot shows the 'Maintenance / LOID config' page. It features a header with the breadcrumb 'Maintenance / LOID config' and a refresh icon. Below the header is a section titled 'LOID authentication' with a sub-instruction: 'Please enter the LOID (length < 25 characters) and password (length < 13 characters). If the password is null, leave the password field blank'. There are two input fields: 'LOID' and 'Password'. A blue 'Save' button is located at the bottom left of the form area.

2

Configure the following parameters:

Table 7-40 *LOID config* parameters

| Field | Description |
|---------------------|--|
| LOID authentication | |
| LOID | Enter the LOID. Maximum number of characters: 24 |
| Password | Enter the password. If the password is null, leave this field blank. Maximum number of characters: 12 |

3

Click **Save**.

END OF STEPS

7.56 Configuring SLID

1

Click **Maintenance**→**SLID configuration** in the left pane. The *SLID configuration* page displays.

Figure 7-57 SLID configuration page

2

Configure the following parameters:

Table 7-41 SLID configuration parameters

| Field | Description |
|----------------|---|
| Current SLID | Displays the current SLID. |
| Enter new SLID | Enter the new SLID. |
| SLID mode | Select a SLID mode from the list. The default is HEX Mode. <ul style="list-style-type: none"> • ASCII Mode • HEX Mode In ASCII Mode, the allowed characters are 0-9, a-z and the maximum number of characters is 10. Special character is not allowed. In HEX Mode, the allowed characters are 0-9, a-f, A-F and the maximum number of characters is 20. Special character is not allowed. |

3

Click **Save**.

END OF STEPS

7.57 Managing the Device

1

Click **Maintenance**→**Device management** in the left pane. The *Device management* page displays.

Figure 7-58 Device management page

Maintenance / **Device management**

Host Name: WINDOWS-3SGUFL1

MAC address: a0:d3:c1:32:67:1b

Host Alias:

Add +

2 _____
Configure the following parameters:

Table 7-42 Device management parameters

| Field | Description |
|-------------|---|
| Host Name | Select a host name from the list. Three multilingual host names can be listed. |
| MAC address | Indicates the MAC address. |
| Host Alias | Enter an alias for the selected host. Three multilingual aliases can be listed. |

3 _____
Click **Add +** to add the host. The host is added to the *Device* table.

END OF STEPS _____

7.58 Diagnosing WAN Connections

1 _____
Click **Maintenance**→**Diagnostics** in the left pane. The *Diagnostics* page displays.

Figure 7-59 Diagnostics page

2

Configure the following parameters.

Table 7-43 Diagnostics parameters

| Field | Description |
|---------------------|--|
| Protocol | Select a protocol from the list: <ul style="list-style-type: none"> • IPv4 • IPv6 |
| WAN connection list | Select a WAN connection to diagnose from the list. |
| IP or domain name | Enter the IP address or domain name. |
| Ping | Select this toggle button to enable ping. |

Table 7-43 *Diagnostics* parameters (continued)

| Field | Description |
|--------------------------|--|
| Traceroute | Select this toggle button to enable traceroute. |
| Ping try times | Enter the number of ping attempts. This field is enabled only if you select the Ping toggle button. Allowed values: 1 to 1000 Default value: 4 |
| Packet length | Enter a packet length. Allowed values: 64 to 1500 Default value: 64 |
| Max number of trace hops | Enter the maximum number of trace hops. This field is enabled only if you select the Traceroute toggle button. Allowed values: 1 to 255 Default value: 30 |

3

Click **Start test** to start the test. Results are displayed at the bottom of the page.

Figure 7-60 Example of ping results

```
PING 192.168.18.10 (192.168.18.10): 64 data bytes
72 bytes from 192.168.18.10: seq=0 ttl=64 time=49.398 ms
72 bytes from 192.168.18.10: seq=1 ttl=64 time=75.414 ms
72 bytes from 192.168.18.10: seq=2 ttl=64 time=102.160 ms

72 bytes from 192.168.18.10: seq=3 ttl=64 time=123.691 ms
```

```
--- 192.168.18.10 ping statistics ---
```

```
4 packets transmitted, 4 packets received, 0% packet loss
```

```
round-trip min/avg/max = 49.398/87.665/123.691 ms
```

Figure 7-61 Example of traceroute results

```
traceroute to 192.168.18.10 (192.168.18.10), 30 hops max, 64 byte packets
```

```
1 192.168.18.10 52.241 ms 5.023 ms 3.396 ms
```

END OF STEPS

7.59 Viewing Log Files

1

Click **Maintenance**→**Log** in the left pane. The *Log* page displays.

Figure 7-62 Log page

The screenshot shows a web interface for 'Maintenance / Log'. At the top right, there are 'Save' and 'Export log' buttons. Below, there are two dropdown menus: 'Writing level' set to 'Notice' and 'Reading level' set to 'Error'.

2

Configure the following parameters:

Table 7-44 Log parameters

| Field | Description |
|---------------|---|
| Writing level | Select a writing level from the list to determine the event types recorded in the log file: <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notice • Informational • Debug |
| Reading level | Select a reading level from the list to determine the event types displayed in the log file: <ul style="list-style-type: none"> • Emergency • Alert • Critical • Error • Warning • Notice • Informational • Debug |

3 Click **Save**. The log file is displayed at the bottom of the page.

4 Click **Export log** to download the log file to your PC. The filename of the log is *onu_info.log*.

END OF STEPS

7.60 Generating a delta configuration file

The delta CFG tool is used to generate a delta CFG file which records the parameter changes on the WebGUI. The tool also allows to merge the generated delta configuration file with a previously existing delta config file.

-
- 1** Click **Maintenance**→**Delta CFG tool** from the left pane. The Delta CFG tool page displays.
- To generate a delta CFG file without merging with a previous CFG file, go to [Step 2](#).
 - To merge delta CFG file, go to [Step 3](#).

Figure 7-63 Delta CFG Tool page



2 **Generating a delta CFG file without merging with a previous delta CFG file**

- a. Click **Start recording**.
- b. Perform the required configuration such as adding/deleting WAN connection, changing WAN connection VLAN ID, changing ACS URL and so on. If reboot is needed after modifying a parameter, for example, changing LAN port mode from route to bridge, wait until the ONT is rebooted and continue with the configuration.
- c. Click **Stop recording** to stop recording.
- d. Click **Export** to download the delta CFG file to the local computer. The delta CFG file is in plain text format with the filename *delta_config_result file*. If required, rename the file and

convert the file to .tar format before downloading it to the ONT.

i **Note:** For merging the downloaded delta config, the previously downloaded delta file must be renamed by adding “CFG” at the start of the filename and .*cfg* extension to be added to the delta config file (CFG_*.*cfg*) to upload the file successfully in Delta CFG tool page.

3

Generating a delta CFG file and merging the file with a previously generated file

This option allows a user to select a delta CFG file from the local computer which will be merged with the recorded commands. The generated delta CFG file will include the content of the selected delta CFG file and the new modifications.

- a. Click **Select file** and select an existing delta CFG file from the local computer to merge with the recorded commands.

i **Note:** Choose the delta CFG file before clicking **Start recording**. The delta CFG file chosen needs to be in plain text format and not in the .tar format.

- b. Click **Start recording**.
- c. Perform the required configuration such as adding/deleting WAN connection, changing WAN connection VLAN ID, changing ACS URL and so on. If reboot is needed after modifying a parameter, for example, changing LAN port mode from route to bridge, wait until the ONT is rebooted and continue with the configuration.
- d. Click **Stop recording** to stop recording.
- e. Click **Export** to download the delta CFG file to the local computer. The delta CFG file is in plain text format with the filename *delta_config_result file*. If required, rename the file and convert the file to .tar format before downloading it to the ONT.

i **Note:** For merging the downloaded delta config, the previously downloaded delta file must be renamed by adding “CFG” at the start of the filename and .*cfg* extension to be added to the delta config file (CFG_*.*cfg*) to upload the file successfully in Delta CFG tool page.

END OF STEPS

Troubleshooting

7.61 Troubleshooting

The Troubleshooting feature enables service providers and end users to monitor the performance of their broadband connection.

Tests are run to retrieve upstream and downstream throughput, latency, and DNS response time. The Troubleshooting page also displays upstream and downstream packet loss and Internet status.

1

Click **Troubleshooting** in the left pane. The *Troubleshooting* page displays.

Figure 7-64 Troubleshooting page

The screenshot shows the 'Troubleshooting' page with the following details:

- WAN connection list:** A dropdown menu showing 'Internet'.
- WAN status:** A status indicator showing 'Up'.
- Troubleshoot counters:**
 - US throughput: A field with a 'US speed test' button.
 - DS throughput: A field with a 'DS speed test' button.
 - US packet loss: A field showing '0'.
 - DS packet loss: A field showing '0'.
 - Latency: A field with a 'Latency test' button.
 - DNS response time: A field with a 'DNS response test' button.
- Port mirrors:**
 - Source Port: A dropdown menu showing 'WAN'.
 - Destination Port: A dropdown menu showing 'Select option'.
 - Direction: A dropdown menu showing 'Downstream'.
 - Status: A dropdown menu showing 'Enable'.
 - A 'Save' button is located at the bottom left of this section.

2

Configure the following parameters:

Table 7-45 Troubleshooting parameters

| Field | Description |
|------------------------------|--|
| WAN Connection List | Select a WAN connection from the list. |
| WAN Status | Displays the WAN status: <ul style="list-style-type: none"> • Up • Down |
| Troubleshoot counters | |
| US throughput | This test is used to determine the upstream throughput/speed. Click US speed test to specify the time for the upstream test. |
| DS throughput | This test is used to determine the downstream throughput/speed. Click DS speed test to specify the time for the downstream test. |
| US packet loss | Displays the number of upstream packages lost. |
| DS packet loss | Displays the number of downstream packages lost. |
| Latency | This test is used to determine the lowest round-trip time in milliseconds by pinging the target server multiple times. Click Latency test to specify the time for the test. |
| DNS response time | This test is used to determine the lowest round-trip time in milliseconds by sending a request to the target DNS server. Click DNS response test to specify the time for the test. |
| Port mirrors | |
| Source port | Select a source port for port mirroring from the list. |
| Destination port | Select a destination port for port mirroring from the list. |
| Direction | Select a direction from the list: <ul style="list-style-type: none"> • Upstream • Downstream |
| Status | Select a port mirroring status from the list: <ul style="list-style-type: none"> • Enable |

3

Click **Save**.

END OF STEPS

8 ONT configuration file over OMCI

8.1 Overview

8.1.1 Purpose

8.1.2 Contents

| | |
|--|-----|
| 8.1 Overview | 195 |
| 8.2 Purpose | 195 |
| 8.3 Supported configuration file types | 195 |
| 8.4 ONT configuration file over OMCI | 197 |

8.2 Purpose

This procedure describes how to use configuration files over OMCI to configure ONTs. Some advantages include:

- Flexibility to change the ONT default behavior by downloading configuration file
- Flexibility to update a deployed ONT by downloading updated parameters
- Ability to securely download any configuration file to an ONT
- Ability to avoid using embedded configuration files in ONT software

i **Note:** This feature is supported for use with the 7360 ISAM FX and the 7342 ISAM FTTU.

When ONT is deployed, it is recommended to use the following operator IDs:

- ALCO - Voice managed through OMCI (OMCIv1(nokia proprietary or OMCV2(Standard OMCI G.988 specs))
- ALCL - Voice managed through TR069

8.3 Supported configuration file types

[Table 8-1, “Supported configuration files” \(p. 196\)](#) describes the configuration file types that are supported from Nokia ONT R05.02.00 and later.

Table 8-1 Supported configuration files

| File Index | Description | Details | Supported ONTs/DPU |
|------------|------------------------------|--|---------------------------------|
| PRE | ONT pre-configuration file | <p>The XML-based PRECONFIG file controls the working mechanics of the ONT for various services. The default behavior of different ONTs may vary based on the factory settings.</p> <p>The pre-configuration file includes the factory default value for the residential gateway.</p> <p>Note: the pre-configuration file does not work with SFU ONTs; therefore, this feature applies only to Residential Gateway ONTs.</p> <p>The pre-configuration file can be used as is, but Nokia provides its customers with the flexibility to customize the pre-configuration file.</p> <p>This pre-configuration file enables operators to change the default behavior by downloading a customized pre-configuration based on customer inputs.</p> <p>This PRE XML file includes a custom OPERID.</p> <p>The Nokia defined index for the PRECONFIG file is: "PRE"</p> | All Nokia GPON and 10 GPON ONT. |
| CFG | ONT configuration delta file | <p>The XML-based CFG file updates the configurable parameters (the PRE settings) in the existing PRE file of a deployed ONT, where required.</p> <p>This configuration file enables operators to change the deployed behavior by downloading customized updates in the CFG file.</p> <p>This file is used only to modify the parameters in the PRE file; it is not used for service provisioning.</p> <p>No OPERID is required, because the update is based on the OPERID used for the PRE file.</p> <p>The Nokia defined index for the PRECONFIG DELTA file is: "CFG"</p> | All Nokia GPON and 10GPON ONT. |
| XML | Voice XML file | <p>The Voice XML file provides an alternate method for securely downloading voice parameters from the OLT, rather than using FTP (OMCIv1/OMCIv2) or HTTPS (TR-069). Downloading this file makes the applicable changes in the voice parameters.</p> <p>This file enables operators to change the voice behavior by downloading the updated voice XML file.</p> <p>Nokia recommends using this procedure, rather than embedded voice XML files.</p> <p>The Nokia defined index for the Voice XML file is: "XML"</p> | All Nokia GPON and 10 GPON ONT. |

8.3.1 Filename conventions

Nokia provides the raw configuration files, which must be saved by the operator in a TAR file to be uploaded. TAR file names must be unique.

The filenames of the raw configuration files may not adhere to the naming conventions outlined below. In this case, the files must be renamed to adhere to the naming conventions before the operator generates the TAR file. Filenames are not case-sensitive.

8.3.2 Download configuration file

The following table provides the supported download options for ONT pre-configuration file and configuration file.

Table 8-2 Download configuration files

| ONT type | Legacy method download | | Zero management download | |
|---------------------------------------|------------------------|----------|--------------------------|----------|
| | PRE file | CFG file | PRE file | CFG file |
| Broadlight (eg.I240WA-3FE54869AFGA80) | — | ✓ | — | ✓ |
| Broadcom (eg.G240WB-3FE56773BFGA07) | — | ✓ | ✓ | ✓ |
| MTK (eg.G240WF) | — | ✓ | ✓ | ✓ |
| Cortina (eg.XS-2426X-A) | — | ✓ | ✓ | ✓ |

8.4 ONT configuration file over OMCI



WARNING

Equipment Damage

Executing the following procedure will trigger the ONT to reboot, which will impact ongoing services.

Use this procedures to configure ONTs using configuration files via legacy method and OMCI.

8.4.1 Configuring an ONT using a configuration file via legacy method

- 1 _____
 Upload the ABCXXXVER TAR file to the /ONT/ directory in the OLT.
 A maximum of 250 files can be kept in the OLT file system.

- 2 _____
 Using OLT commands, download the TAR file to the ONT.
 For OLT commands, refer to the , or the **7342 ISAM FTU Operation and Maintenance Using TL1 and CLI**.
 Please note:
 - **pri-cfgfile-pland/dnload** or **sec-cfgfile-pland/dnload** can be 1 to 14 characters.
 - **pri-cfgfile-pland** and **pri-cfgfile-dnload** should be the same name.**Examples**
 Note: X can be 1 or 2 unless specified:
 - a. If **pland-cfgfileX= Disabled** and **dnload-cfgfileX= Disabled** ,

no file will be downloaded to the ONT.

- b. If **pland-cfgfileX=FILENAME1** and **dnload-cfgfileX= Disabled** ,
FILENAME1 will be downloaded and FILENAME1 will be made active. An ONT reboot is required.
- c. If **pland-cfgfileX=Disabled** and **dnload-cfgfileX= FILENAME2**
FILENAME2 will be downloaded and FILENAME2 will be made passive. An ONT reboot is not required.
- d. If **pland-cfgfileX=FILENAME3** and **dnload-cfgfileX= FILENAME 4**, the OLT reports an error because the filenames are not the same.
- e. Configure equipment interface **pland-cfgfile1=XMLXXXXX1** and **dnload-cfgfile1 XMLXXXXX1**
Configure equipment interface **pland-cfgfile2=XMLXXXXX2** and **dnload-cfgfile2 XMLXXXXX2**
Although the OLT permits the above two steps without reporting an error, Nokia does not recommend executing them, because the ONT may exhibit unexpected behavior.
- f. If **pland-cfgfileX=Auto** and **dnload-cfgfileX= Auto**
The OLT will download the XML file from "sw-ctr-list" (**configure equipment ont sw-ctrl**)

END OF STEPS

The ONT will distribute the configuration files to the different services based on the active indication from the OLT and on the Nokia defined index.

The ONT automatically reboots to apply the configuration files. After the ONT reboots and reports the active version, the OLT completes the file download procedure.

Operators must check the committed file from the OLT to verify whether the corresponding file has been applied. If an error occurs, contact Nokia for support.

8.4.2 Configuring an ONT using a configuration file via OMCI

1

Generate the TAR file to be uploaded to the OLT.

Using the raw configuration file(s) provided by Nokia, generate the TAR file as follows:

- a. On a Linux platform, rename the raw configuration file to adhere to the naming convention, as described in section 8.3 "Supported configuration file types" (p. 195).
- b. Tar the **ABCXXXXVER** raw configuration file:

```
tar -cf ABCXXXXVER.tar ABCXXXXVER
```

Where

ABCXXXXVER

Is the name of the file created in step i.

This creates two files: **ABCXXXXVER** and **ABCXXXXVER.tar**.

- c. Rename **ABCXXXVER** to **ABCXXXVER.org**
- d. Remove the “.tar” extension from **ABCXXXVER.tar** file.

2

Upload the ABCXXXVER TAR file to the /ONT/ directory in the OLT.
A maximum of 250 files can be kept in the OLT file system.

3

Using OLT commands, download the TAR file to the ONT.

For OLT commands, refer to the , or the **7342 ISAM FTTU Operation and Maintenance Using TL1 and CLI**.

Please note:

- **pri-cfgfile-pland/dnload** or **sec-cfgfile-pland/dnload** can be 1 to 14 characters.
- **pri-cfgfile-pland** and **pri-cfgfile-dnload** should be the same name.

Examples

Note: X can be 1 or 2 unless specified:

- a. If **pland-cfgfileX= Disabled** and **dnload-cfgfileX= Disabled** ,
no file will be downloaded to the ONT.
- b. If **pland-cfgfileX=FILENAME1** and **dnload-cfgfileX= Disabled** ,
FILENAME1 will be downloaded and FILENAME1 will be made active. An ONT reboot is required.
- c. If **pland-cfgfileX=Disabled** and **dnload-cfgfileX= FILENAME2**
FILENAME2 will be downloaded and FILENAME2 will be made passive. An ONT reboot is not required.
- d. If **pland-cfgfileX=FILENAME3** and **dnload-cfgfileX= FILENAME 4**, the OLT reports an error because the filenames are not the same.
- e. Configure equipment interface **pland-cfgfile1=XMLXXXXX1** and **dnload-cfgfile1 XMLXXXXX1**
Configure equipment interface **pland-cfgfile2=XMLXXXXX2** and **dnload-cfgfile2 XMLXXXXX2**
Although the OLT permits the above two steps without reporting an error, Nokia does not recommend executing them, because the ONT may exhibit unexpected behavior.
- f. If **pland-cfgfileX=Auto** and **dnload-cfgfileX= Auto**
The OLT will download the XML file from "sw-ctr-list" (**configure equipment ont sw-ctrl**)

END OF STEPS

The ONT will distribute the configuration files to the different services based on the active indication from the OLT and on the Nokia defined index.

The ONT automatically reboots to apply the configuration files. After the ONT reboots and reports the active version, the OLT completes the file download procedure.

Operators must check the committed file from the OLT to verify whether the corresponding file has been applied. If an error occurs, contact Nokia for support.